Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TechBrix GS-M8

M8 4K Retro Game Stick User Manual

HD Home Video Retro Game Console with 2 Wireless Controllers

Introduction

The M8 4K Retro Game Stick is a compact, high-definition home video game console designed to bring a vast library of retro games to your television or monitor. Featuring HDMI output for 4K compatibility and two 2.4G wireless controllers, it offers a convenient plug-and-play gaming experience. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your game stick.

Package Contents

Please verify that all the following items are included in your package:

- 1 x Game Stick
- 1 x USB Wireless Receiver
- 1 x Extension HDMI Cable
- 1 x USB Power Cable
- 1 x TF Card (pre-installed with games)
- 1 x User Manual
- 2 x 2.4G Wireless Controllers



Image: All components included in the M8 4K Retro Game Stick package.

Product Overview

Game Stick Components

The M8 Game Stick is a compact device that connects directly to your TV's HDMI port. It houses the main processing unit and the TF card slot for game storage.



Image: Various angles of the M8 4K Retro Game Stick.



Image: Detailed views of the Game Stick's ports and indicators.



Image: Design elements and wireless controller compatibility of the Game Stick.

Wireless Controllers

The console comes with two 2.4G wireless controllers, providing freedom of movement during gameplay. Each controller requires two AAA batteries (not included).



Image: Wireless controller with details on simulator support and 3D rocker.

Setup Guide

Connecting the Game Stick

1. Ensure the TF card is securely inserted into the Game Stick's TF card slot.
2. Plug the Game Stick directly into an available HDMI port on your television or monitor. If space is limited, use the included HDMI Extension Cable.
3. Connect the USB Power Cable to the Game Stick's power input port and then to a USB power source (e.g., TV USB port, USB wall adapter).
4. Turn on your television or monitor and select the correct HDMI input source. The Game Stick's interface should appear on the screen.



Image: M8 4K Retro Game Stick connected to a TV for gameplay.

Connecting the Wireless Controllers

1. Open the battery compartment on the back of each wireless controller and insert two AAA batteries, observing the correct polarity.
2. Plug the USB Wireless Receiver into the USB port on the Game Stick.
3. Press the 'MODE' button on each controller to power them on. The controllers should automatically pair with the Game Stick.

Operating Instructions

Navigating the System

Use the directional pad (D-pad) or analog stick on your wireless controller to navigate through the main menu and game

lists. The 'A' button typically confirms selections, and the 'B' button returns to the previous screen.

Selecting and Starting Games

From the main menu, select an emulator or browse the game list. Use the D-pad to highlight a game and press 'A' to launch it. The system supports game search and collection features to help you find your favorite titles quickly.

Saving and Loading Game Progress

The M8 Game Stick supports instant archive read and pause functions. During gameplay, press the 'SELECT' and 'START' buttons simultaneously to access the in-game menu. From this menu, you can save your game state, load a previous save, or exit the game.

Maintenance

To ensure the longevity and optimal performance of your M8 4K Retro Game Stick, follow these maintenance guidelines:

- Keep the device and controllers clean by wiping them with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- Store the game stick and controllers in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- Avoid dropping the device or controllers, as this can cause internal damage.
- When not in use for extended periods, remove batteries from the wireless controllers to prevent leakage.

Troubleshooting

No Signal on TV

- Ensure the Game Stick is securely plugged into the HDMI port.
- Verify that the USB Power Cable is connected and providing power to the Game Stick.
- Check that your TV is set to the correct HDMI input source.
- Try connecting the Game Stick to a different HDMI port or TV.

Controllers Not Responding

- Check if the AAA batteries in the controllers are inserted correctly and have sufficient charge. Replace if necessary.
- Ensure the USB Wireless Receiver is firmly plugged into the Game Stick's USB port.
- Press the 'MODE' button on the controllers to ensure they are powered on.
- If controllers are still unresponsive, try unplugging and re-plugging the USB Wireless Receiver.

Game Performance Issues (Lag, Freezing)

- Ensure the TF card is properly inserted and not corrupted.
- Restart the Game Stick by unplugging and re-plugging the power cable.
- Ensure there is adequate ventilation around the Game Stick to prevent overheating.

Specifications

Feature	Detail
CPU	GB2
Output	HDMI (4K compatible)
Operating System	Linux Retroarchiopen Source System
Memory Performance	DDR3 256MB
External TF Card Support	Expandable up to 128GB
Controller Frequency	2.4G Wireless
Controller Power	2 x AAA batteries per controller (Not Included)
Item Model Number	GS-M8
Product Dimensions	8 x 6 x 6 inches
Item Weight	1.1 pounds



Image: M8 4K Retro Game Stick with key specification parameters.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official TechBrix website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D62R3GHW

More documents and user manuals: **https://manuals.plus/**