Hannspree SN14TP6B

Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS User Manual

Model: SN14TP6B | Brand: Hannspree

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS tablet. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

Upon opening the package, verify that all items listed below are present and in good condition:

- Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS Tablet
- Power Adapter
- USB Charging Cable
- Quick Start Guide
- Warranty Card

Note: Specific accessories may vary by region or retailer.

3. PRODUCT OVERVIEW

Familiarize yourself with the physical components of your tablet.

Figure 3.1: The Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS tablet shown with its detachable keyboard case, viewed from an angle. The screen displays the Hannspree logo and various app icons.

Figure 3.2: The Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS tablet positioned in a stand configuration, showcasing the display with the Hannspree logo and Android interface elements.

Figure 3.3: The rear panel of the Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS tablet, displaying the Hannspree brand name and regulatory markings.

Figure 3.4: The Hannspree Tab 13.3 Zeus 3 SN14TP6B IPS tablet enclosed within its protective keyboard case, shown in a closed, folded position.

3.1. Buttons and Ports

- **Power Button:** Located on the side/top edge. Press and hold to power on/off or restart. Short press to wake/sleep the screen.
- **Volume Buttons:** Located near the power button. Press to adjust media volume or notification volume.
- **USB-C Port:** For charging the device and connecting to a computer for data transfer.
- **Headphone Jack:** Standard 3.5mm audio output for headphones or external speakers.
- **MicroSD Card Slot:** For expanding storage capacity (card not included).
- **Front Camera:** For video calls and selfies.
- **Rear Camera:** For taking photos and videos.
- **Speakers:** For audio output.

4. SETUP

4.1. Initial Charging

Before first use, fully charge your tablet. Connect the USB charging cable to the tablet's USB-C port and the power adapter. Plug the adapter into a wall outlet. The charging indicator will typically illuminate or the battery icon on the screen will show charging status.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power button until the Hannspree logo appears on the screen.
- **To Power Off:** Press and hold the Power button until a power menu appears. Select "Power off" and confirm.
- **To Restart:** Press and hold the Power button until a power menu appears. Select "Restart" and confirm.

4.3. Initial Setup

Upon first power-on, the tablet will guide you through the initial setup process. This typically includes:

1. Selecting your language.
2. Connecting to a Wi-Fi network.
3. Signing in with your Google account or creating a new one.
4. Setting up screen lock (PIN, pattern, password).
5. Reviewing and accepting terms and conditions.

5. OPERATING THE TABLET

5.1. Basic Navigation

The Hannspree Tab 13.3 Zeus 3 runs on the Android operating system. Navigation is primarily touch-based:

- **Tap:** To select an item or open an application.
- **Tap and Hold:** To access contextual menus or move icons.
- **Swipe:** To scroll through screens, lists, or pages.
- **Pinch-to-Zoom:** To zoom in or out on images and web pages.

5.2. Connecting to Wi-Fi

1. Go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list.
4. Enter the network password if prompted, then tap **Connect**.

5.3. Managing Applications

- **Install Apps:** Open the Google Play Store app, search for the desired app, and tap **Install**.
- **Uninstall Apps:** Tap and hold an app icon on the home screen or app drawer, then drag it to "Uninstall" or select "App info" and choose "Uninstall". Alternatively, go to **Settings** > **Apps** > **See all apps**, select the app, and tap **Uninstall**.

6. MAINTENANCE

6.1. Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid using harsh chemicals, abrasive materials, or excessive moisture.

6.2. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings** > **System** > **System update** to check for available updates.

6.3. Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- Do not let the battery completely drain frequently.
- Use the original charger and cable for optimal charging.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your tablet.

7.1. Tablet Does Not Power On

- Ensure the battery is charged. Connect the tablet to its charger and wait a few minutes before attempting to power it on again.
- Try a forced restart: Press and hold the Power button for approximately 10-15 seconds.

7.2. Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled in Settings.
- Restart your Wi-Fi router and the tablet.
- Forget the network in tablet settings and reconnect.
- Ensure you are within range of the Wi-Fi signal.

7.3. Applications Crashing or Freezing

- Close and reopen the application.
- Clear the app's cache: Go to **Settings** > **Apps** > **See all apps**, select the problematic app, then **Storage & cache** > **Clear cache**.
- Restart the tablet.
- Ensure the app is updated to its latest version.

8. SPECIFICATIONS

Feature	Detail
Model Name	Tab HANNspree 13,3 Zeus 3 SN14TP6B IPS

Item Model Number	SN14TP6B
Brand	Hannspree
Operating System	Android
Standing Screen Display Size	13.3 Inches
Display Resolution	1920 x 1080 pixels
Max Screen Resolution	1920x1080
Processor	2 GHz (AMD Processor Brand)
Card Description	Integrated
Wireless Standard	802.11g
Flash Memory Size	128 GB
Colour	Blue
Product Dimensions (L x W x H)	18 x 30 x 6 cm
Item Weight	2 kg
Date First Available	Aug. 15 2024

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included in your product package or visit the official Hannspree website. Keep your proof of purchase for warranty claims.

Related Documents - SN14TP6B

HANNspree SN14TP1(HSG1351) User Manual
User manual for the HANNspree SN14TP1(HSG1351) tablet, covering product overview, initial operation, Android interface, firmware updates, specifications, and troubleshooting.

	HannsNote2 SN10HR1B User Manual - HANNspree Comprehensive user manual for the HANNspree HannsNote2 (SN10HR1B) tablet. Learn about product overview, initial setup, Android interface, note-taking features, specifications, and safety guidelines.
	HANNSpad SN14TP4(HSG1416) User Manual | Hannspree This user manual provides comprehensive instructions for the Hannspree HANNSpad SN14TP4(HSG1416) tablet, covering product overview, initial setup, Android interface navigation, specifications, and troubleshooting.
	HANNspree Lumo 7.8" Reader Tablet Quick Start Guide Quick start guide for the HANNspree Lumo 7.8" Reader Tablet (HSD0005), covering system language setup and battery charging. Includes product overview and power on/off instructions.
	Hannspree HannsNote2: Eco-friendly Natural Illumination Reader User Manual and Warranty Information Comprehensive instruction manual and warranty details for the Hannspree HannsNote2, an eco-friendly natural illumination e-reader tablet featuring a 10-inch display, 4GB+64GB storage, and Bluetooth 5.0.
	Hannspree 4.3" Photo Alarm Clock Quick Start Guide Quick start guide for the Hannspree 4.3" Photo Alarm Clock, covering setup, wallpaper, date/time, alarm, photo slideshow, music playback, and FM radio functions.