## Tefal EY901850

# T-fal Dual Easy Fry XL Air Fryer 7-in-1 Instruction Manual

Model: EY901850 | Brand: Tefal

## Introduction

The T-fal Dual Easy Fry XL Air Fryer is a versatile kitchen appliance designed for effortless cooking. With its dual basket system and 8.3L total capacity, it allows for simultaneous cooking of different foods, making meal preparation efficient. This appliance features 7 pre-set cooking programs and utilizes 360° air circulation with extra-crisp technology for optimal results. The baskets and grids are dishwasher safe for easy cleaning.




*Image: Front view of the T-fal Dual Easy Fry XL Air Fryer, showcasing its dual baskets with cooked chicken and fries.*

## Important Safety Information

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the appliance on a stable, heat-resistant surface, away from walls and other heat sources.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Supervise children closely when the appliance is in use.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Do not block the air inlets or outlets during operation.
- Hot steam is released through the air outlet openings during air frying. Keep your hands and face at a safe distance.
- Always unplug the appliance after use and before cleaning. Allow it to cool down completely before handling.

## Product Components

The T-fal Dual Easy Fry XL Air Fryer consists of the following main components:

1. Main Unit with Control Panel
2. Large Cooking Basket (5.2L / 5.5 Qt)
3. Small Cooking Basket (3.1L / 3.2 Qt)
4. Removable Grids for each basket
5. Power Cord




*Image: The T-fal Dual Easy Fry XL Air Fryer with its two baskets, indicating their respective capacities of 5.2L and 3.1L.*

## Setup

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Initial Cleaning:** Before first use, wash the cooking baskets and removable grids with hot water, dish soap, and a

non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.

3. **Placement:** Place the appliance on a stable, level, and heat-resistant surface. Ensure there is adequate space around the unit for proper air circulation (at least 10 cm / 4 inches on all sides).
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

## Operating Instructions

### General Operation

1. Place the food into the desired cooking basket(s). Do not overfill.
2. Slide the basket(s) back into the main unit until they click into place.
3. Press the power button to turn on the appliance.
4. Select a pre-set program or manually set the temperature and time using the control panel.
5. Press the Start/Stop button to begin cooking.
6. During cooking, you may pull out the baskets to shake or turn food for even cooking. The appliance will pause automatically and resume when the basket is reinserted.
7. Once cooking is complete, carefully remove the baskets and transfer food to a serving dish.

### 7 Pre-set Programs

The T-fal Dual Easy Fry XL offers 7 pre-set programs for common cooking tasks:

- Air Fry
- Roast
- Bake
- Dehydrate
- Broil
- Toast
- Manual Function




*Image: Close-up of the control panel displaying the 7 pre-set cooking programs and manual controls.*

### Sync Mode

The Sync Mode allows you to cook two different foods in each basket, ensuring they finish cooking at the same time. This feature automatically adjusts the cooking time for the basket that requires less time, so both are ready simultaneously.

- Load both baskets with food.
- Select the desired program and settings for each basket independently.
- Press the "SYNC" button.
- Press Start/Stop. The air fryer will manage the cooking times to synchronize completion.

## Cooking Guide

Below is a general guide for common foods. Cooking times and temperatures may vary based on food quantity, size, and desired crispness. Always use a food thermometer to ensure food is cooked to a safe internal temperature.

| Food Item | Quantity | Temperature | Time | Notes |
|---|---|---|---|---|
| Frozen Fries | 500g - 800g | 200°C (390°F) | 15-20 min | Shake basket halfway through. |
| Chicken Wings | 500g - 1kg | 180°C (355°F) | 20-25 min | Flip halfway through. |
| Roasted Vegetables | 300g - 600g | 190°C (375°F) | 12-18 min | Toss halfway through. |
| Small Whole Chicken | Up to 1.2kg | 180°C (355°F) | 45-60 min | Ensure internal temperature reaches 74°C (165°F). |




*Image: Illustration of the 360° air circulation technology within the air fryer basket, ensuring even cooking and crispiness.*

## Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Basket and Grid Cleaning:** The cooking baskets and removable grids are dishwasher safe. For manual cleaning, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water with dish soap for about 10 minutes before cleaning.
3. **Main Unit Cleaning:** Wipe the exterior of the air fryer with a damp cloth. Never immerse the main unit in water or any other liquid. Do not use abrasive cleaning agents or scouring pads, as they can damage the surface.
4. **Interior Cleaning:** Clean the interior of the appliance with a damp cloth and mild detergent if necessary.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.




*Image: The dishwasher-safe baskets and grids of the T-fal Dual Easy Fry XL Air Fryer placed in a dishwasher rack,*

*highlighting ease of cleaning.*

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Air fryer does not turn on. | Appliance not plugged in; Power outlet not working; Basket not inserted correctly. | Ensure the power cord is securely plugged into a working outlet. Push the basket(s) fully into the unit until it clicks. |
| Food is not cooked evenly. | Too much food in the basket; Food not shaken/flipped. | Reduce the amount of food per batch. Shake or flip food halfway through cooking. |
| Food is not crispy. | Not enough oil (if applicable); Temperature too low; Cooking time too short. | Lightly coat food with oil for extra crispiness. Increase temperature or cooking time. |
| White smoke coming from appliance. | Fat residue from previous use; Cooking fatty food. | Clean the basket and grid thoroughly after each use. This is normal when cooking very fatty foods. |

## Specifications

**Brand:** Tefal

**Model Number:** EY901850

**Colour:** Black

**Product Dimensions (Approximate):** 42 cm (Width) x 30 cm (Depth) x 30.6 cm (Height)

**Total Capacity:** 8.3 Liters / 8.7 Quarts (5.2L / 5.5 Qt large basket, 3.1L / 3.2 Qt small basket)

**Power/Wattage:** 1500 watts

**Material:** Stainless Steel and durable plastic components

**Special Features:** Dual Zone Cooking, 7 Pre-set Programs (Air Fry, Roast, Bake, Dehydrate, Broil, Toast, Manual), Sync Mode, Dishwasher Safe Baskets and Grids

**Item Weight:** 6 kg




*Image: The T-fal Dual Easy Fry XL Air Fryer with visual indicators for its height (30.6 cm) and width (42 cm).*

## Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Tefal website. Keep your purchase receipt as proof of purchase for any warranty claims.
For additional recipes and cooking inspiration, you can download the T-fal app available for iPhone and Android devices.
Visit the official Tefal Store for more products and information:Tefal Store on Amazon.ca

© 2024 Tefal. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**