Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PZL HP2707

PZL Voice Replacement Remote Control for Airtel XStream Smart Stick Device HP2707 User Manual

1. Product Overview

This manual provides instructions for the PZL Voice Replacement Remote Control, model HP2707. This remote is designed as a direct replacement for the original remote control of the Airtel XStream Smart Stick Device.



Image 1: The PZL Voice Replacement Remote Control, model HP2707, shown in context with a television.

The remote control features voice search capabilities and utilizes infrared (IR) technology for communication with your device. It is constructed from durable ABS material and designed for comfortable handling.



Image 2: Key features of the remote control, including fast response and ergonomic design.

2. Setup Instructions

2.1. Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image 3: Illustration of the remote control's dimensions and the battery compartment location.

2.2. Initial Use

No programming or pairing is required for this replacement remote control. Once batteries are installed, it is ready for immediate use with your compatible Airtel XStream Smart Stick Device HP2707.

3. Operating Instructions

3.1. Basic Functions

The remote control provides precise control over distances of up to 12 meters (40 feet) with a response time of less than 0.2 seconds. The keys are designed for responsiveness and tactile feedback.

- **Power Button:** Turns the device on or off.
- **Navigation Pad (Circular):** Use to navigate menus and select items.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the main home screen.
- **Menu/Options Button:** Accesses additional options or settings.
- **Play/Pause Button:** Controls media playback.

- **Volume Buttons (+/-):** Adjusts the volume level.
- **Netflix Button:** Direct access to the Netflix application.

3.2. Voice Control

This remote control features voice search functionality. To use voice control:

1. Press and hold the dedicated Voice button (often indicated by a microphone icon).
2. Speak your command clearly into the remote control. Examples include:
    - "Show me the hot movies"
    - "TV shows"
    - "Playing the music"
    - "Look up stock prices"
    - "Muting"
3. Release the Voice button once you have finished speaking. The device will process your command.



Image 4: Demonstrating the voice control feature with various command examples.

3.3. Infrared (IR) Technology

The remote operates using advanced IR technology, providing a strong signal and multi-angle control up to 120 degrees. Ensure a clear line of sight between the remote and your Airtel XStream Smart Stick Device for optimal performance.



Image 5: Visualizing the long-range and multi-angle control capabilities of the remote's IR technology.

4. Maintenance

4.1. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

4.2. Battery Replacement

If the remote control's performance degrades or it stops responding, replace the batteries. Refer to Section 2.1 for battery installation instructions. Always replace both batteries at the same time with new AAA batteries.

4.3. Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

If you encounter issues with your PZL Voice Replacement Remote Control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries. Obstruction between remote and device. Remote out of range.	Replace batteries (see Section 2.1). Ensure clear line of sight to the Airtel XStream Smart Stick. Move closer to the device (within 12 meters/40 feet).
Voice control not working.	Voice button not pressed/held. Speaking too softly or unclear. Device not ready for voice input.	Press and hold the Voice button while speaking. Speak clearly and directly into the remote. Ensure your Airtel XStream Smart Stick is powered on and responsive.
Intermittent response.	Weak batteries. Interference from other electronic devices.	Replace batteries. Minimize interference by moving other devices or ensuring a clear path.

If the problem persists after attempting these solutions, please contact customer support as described in Section 7.

6. Product Specifications

- **Brand:** PZL
- **Model:** HP2707
- **Compatible Devices:** Airtel XStream Smart Stick Device
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Voice Control
- **Special Features:** Voice Search
- **Maximum Range:** 12 meters (40 feet)
- **Response Time:** Less than 0.2 seconds
- **Power Source:** 2 x AAA Batteries (not included)
- **Material:** ABS
- **Color:** Black

7. Warranty and Customer Support

PZL is committed to providing quality products and professional after-sales service. If you have any questions regarding your remote control, its compatibility, or require assistance, please contact customer support.
For support, please reach out to us directly. We aim to respond to inquiries within 12 hours on weekdays. Please provide your model number (HP2707) and a detailed description of your issue when contacting support.

© 2026 PZL. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6KM5WMM

More documents and user manuals: **https://manuals.plus/**