Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PINDOWS PDS-8015

PINDOWS Women's Digital Sport Watch User Manual

Model: PDS-8015
Brand: PINDOWS

Introduction

Thank you for choosing the PINDOWS PDS-8015 Women's Digital Sport Watch. This watch is designed for active lifestyles, featuring a durable build, 50M water resistance, and multiple functions including an alarm, stopwatch, and LED backlight. This manual provides detailed instructions to help you understand and utilize all the features of your new watch.

Image: Front view of the PINDOWS PDS-8015 Digital Sport Watch, showcasing its digital display and button layout.

Product Features

- **Precision Timekeeping:** Equipped with a reliable Japanese quartz movement and battery.
- **50M Water Resistance:** Suitable for swimming, showering, and daily water exposure. *Note: Do not press any buttons underwater.*
- **Multi-functional Display:** Includes Alarm Clock, Automatic Date, Stopwatch, and 12/24-hour format.
- **7-Color LED Backlight:** Provides clear visibility in low-light conditions with customizable color options.
- **Durable Construction:** Features an ABS case, PMMA dial window, and a comfortable TPU band with a pin buckle strap.
- **Pedometer & Calories:** While these features are mentioned in the product description, specific operational details are not provided in the button functions. Users should refer to the watch's display for these functions if present.

Watch Components and Buttons

Familiarize yourself with the watch's buttons and their functions:



Image: Diagram illustrating the location and names of the watch's buttons: Light, Start/Pause, Adjustment, and Mode.

- **LIGHT Button (Top Left):** Activates the LED backlight. Long press to change backlight color/pattern.
- **MODE Button (Bottom Left):** Cycles through different modes (Time, Alarm, Stopwatch).
- **START/PAUSE Button (Top Right):** Used to start/stop stopwatch, adjust values in setting mode.
- **RESET/ADJUSTMENT Button (Bottom Right):** Used to reset stopwatch, confirm settings, or adjust values.
- **Time Display:** Shows current time, date, and other mode-specific information.

Setup and Initial Use

Battery Installation (if applicable)

Your PINDOWS watch comes with a CR2032 battery pre-installed. If the display is dim or not functioning, the battery may need replacement. It is recommended to have a professional replace the battery to maintain water resistance.

Power On

The watch powers on automatically once the battery is installed. The default display is the time mode.

Operating Instructions

Setting Time and Date

1. In normal time display mode, press the **MODE** button three times to enter time setting mode. The seconds will start flashing.
2. Press the **RESET/ADJUSTMENT** button to reset seconds to zero.
3. Press the **START/PAUSE** button to move to the next setting item (Hour, Minute, Month, Date, Day of Week).
4. Use the **RESET/ADJUSTMENT** button to adjust the flashing value.
5. Continue pressing **START/PAUSE** and **RESET/ADJUSTMENT** until all desired settings are configured.
6. Press the **MODE** button once to exit setting mode and return to normal time display.

Using the Alarm Function

1. From normal time display, press the **MODE** button once to enter Alarm mode.
2. Press the **RESET/ADJUSTMENT** button to toggle the alarm ON/OFF. An alarm icon will appear/disappear.
3. To set the alarm time, press the **MODE** button twice from normal time display (or once from Alarm mode if not already there, then press MODE again). The hour digits will flash.
4. Use the **RESET/ADJUSTMENT** button to adjust the hour.
5. Press the **START/PAUSE** button to move to the minute setting.
6. Use the **RESET/ADJUSTMENT** button to adjust the minute.
7. Press the **MODE** button to exit alarm setting mode.

Using the Stopwatch

1. From normal time display, press the **MODE** button twice to enter Stopwatch mode. The display will show "00:00:00".
2. Press the **START/PAUSE** button to start the stopwatch.
3. Press the **START/PAUSE** button again to pause the stopwatch.
4. Press the **RESET/ADJUSTMENT** button to reset the stopwatch to "00:00:00".
5. Press the **MODE** button to return to normal time display.

Activating the LED Backlight

Press the **LIGHT** button (top left) to illuminate the display. The backlight will stay on for a few seconds.

Image: The PINDOWS watch display illuminated with a vibrant, multi-color LED backlight, demonstrating its visibility in low light.

Changing Backlight Color/Pattern

Long press the **LIGHT** button to cycle through different backlight colors or patterns. Release the button when your desired color/pattern is displayed.

Water Resistance (50M)

Your PINDOWS watch is rated for 50 meters (5ATM) water resistance. This means it is suitable for everyday use, including hand

washing, rain, and short periods of swimming. **IMPORTANT: Do not press any buttons while the watch is submerged in water, as this can compromise the water seal and cause damage. Avoid hot water or steam.**



Image: The PINDOWS watch partially submerged in water, illustrating its 50M water resistance capability.

Maintenance

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Avoid Chemicals:** Do not expose the watch to strong chemicals, solvents, or detergents, as these can damage the case, band, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods, as this can affect battery life and movement accuracy.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the CR2032 battery. Professional replacement is recommended.
Time is inaccurate.	Time not set correctly; battery low.	Re-set the time and date. If problem persists, replace battery.
Buttons are unresponsive.	Watch may be in a locked mode; debris under buttons.	Try pressing the MODE button to cycle modes. Clean around buttons. If submerged, ensure watch is dry.
Water inside the watch.	Water resistance compromised (e.g., buttons pressed underwater, seal damage).	Immediately take the watch to a professional for inspection and repair to prevent further damage.

Specifications



Image: Detailed diagram showing the PINDOWS watch's dimensions and material specifications, including case diameter, thickness, band width, and length.

- **Model:** PDS-8015
- **Movement:** Japanese Quartz Digital
- **Water Resistance:** 50M (5ATM)
- **Case Material:** ABS
- **Dial Window Material:** PMMA
- **Band Material:** TPU
- **Clasp Type:** Pin Buckle
- **Dial Diameter:** 1.7 inches (44 mm)
- **Case Thickness:** 0.5 inches (15 mm)
- **Band Length:** 9.45 inches (24 cm)
- **Band Width:** 0.71 inches (18 mm)
- **Weight:** 43 grams

- **Battery:** 1 x CR2032 (included)

Warranty and Support

PINDOWS provides a **12-month warranty service** for this product. For any questions, concerns, or warranty claims, please contact PINDOWS customer support through your purchase platform or the official PINDOWS website. Please retain your proof of purchase for warranty validation.

© 2024 PINDOWS. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6LLCSXT

More documents and user manuals: **https://manuals.plus/**