Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PINDOWS PDS-8015

PINDOWS Digital Sports Watch User Manual

Model: PDS-8015

1. Introduction

Thank you for choosing the PINDOWS Digital Sports Watch. This manual provides detailed instructions on how to set up, operate, and maintain your watch. Please read this manual carefully to ensure proper use and to enjoy all the features of your new timepiece.

2. Product Overview





Front view of the PINDOWS Digital Sports Watch, showcasing its digital display and button layout.

2.1. Watch Components and Buttons



Diagram illustrating the functions of each button on the PINDOWS Digital Sports Watch.

- **LIGHT Button:** Activates the LED backlight and changes backlight color/pattern.
- **START/PAUSE Button:** Starts and pauses the stopwatch; used for adjustment in setting modes.
- **RESET Button:** Resets the stopwatch; used for adjustment in setting modes.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch, Time Setting).
- **ADJUSTMENT Button:** Used to confirm settings or move to the next setting parameter.

2.2. Product Parameters

PRODUCT PARAMETERS



Weight: 43g	Band Material: TPU
Case Material: ABS	Bottom Cover Material: Stainless Steel

Case Diameter: 1.7inch/44mm

Band Width: 0.9inch/20mm

Case Thickness: 0.5inch/13.5mm

Band Length: 6.9inch - 8.9inch

Detailed diagram showing the dimensions and key parameters of the PINDOWS Digital Sports Watch.

Parameter	Value
Weight	43g
Case Material	ABS
Case Diameter	1.7 inch / 44mm
Case Thickness	0.5 inch / 13.5mm
Band Material	TPU
Bottom Cover Material	Stainless Steel
Band Width	0.9 inch / 20mm

Band Length	6.9 inch - 8.9 inch
Battery Type	1 CR2032 Battery (Included)

3. Setup

3.1. Initial Power On

Your PINDOWS watch comes with a pre-installed battery. The watch should be ready for use upon arrival. If the display is blank, ensure the battery insulation tab (if present) has been removed. The watch uses a Japanese quartz movement and Japanese battery for accurate timekeeping.

3.2. Setting Time and Date

1. From the normal time display mode, press the **MODE** button three times to enter time setting mode. The seconds will start flashing.
2. Press the **RESET** button to reset the seconds to 00.
3. Press the **START/PAUSE** button to move to the hour setting. The hour digits will flash.
4. Press the **RESET** button to adjust the hour. Pay attention to AM/PM indicators if in 12-hour format.
5. Press the **START/PAUSE** button to move to the minute setting. The minute digits will flash.
6. Press the **RESET** button to adjust the minutes.
7. Continue pressing the **START/PAUSE** button to cycle through month, date, and day of the week settings, adjusting each with the **RESET** button.
8. Once all settings are complete, press the **MODE** button to exit time setting mode and return to the normal time display.

4. Operating Instructions

4.1. Alarm Function

1. From the normal time display mode, press the **MODE** button once to enter Alarm mode.
2. Press the **START/PAUSE** button to select the hour or minute to set.
3. Press the **RESET** button to adjust the flashing digits to your desired alarm time.
4. Press the **MODE** button to confirm and exit Alarm setting mode.
5. To activate/deactivate the alarm, press the **START/PAUSE** and **RESET** buttons simultaneously in Alarm mode. An alarm icon will appear/disappear on the display.

4.2. Chronograph (Stopwatch)

1. From the normal time display mode, press the **MODE** button twice to enter Chronograph mode. The display will show 00:00:00.
2. Press the **START/PAUSE** button to start the stopwatch.
3. Press the **START/PAUSE** button again to pause the stopwatch.
4. Press the **RESET** button while paused to reset the stopwatch to 00:00:00.
5. Press the **MODE** button to exit Chronograph mode.

4.3. Hourly Chime

To activate or deactivate the hourly chime, press the **MODE** button to enter the normal time display. Then, press and hold the **RESET** button. The hourly chime icon will appear or disappear, indicating its status.

4.4. LED Backlight



The PINDOWS watch display illuminated with its 7-color LED backlight, providing clear visibility in low light conditions.

Press the **LIGHT** button to activate the LED backlight. The watch features a 7-color LED display that is bright enough to be easily visible day or night, making it ideal for outdoor activities and late-night office work. Pressing and holding the **LIGHT** button may cycle through different backlight colors or patterns.

5. Water Resistance



The PINDOWS watch demonstrating its 50M water resistance, suitable for various water-related activities.

This PINDOWS watch is designed with a 50-meter (5ATM) water resistance rating. This means it is suitable for daily use, hand washing, rain, and short periods of recreational swimming. *It is not suitable for diving, snorkeling, or high-pressure water activities.* **Important:** Do not operate any buttons while the watch is submerged in water, as this can compromise the water resistance seal.

6. Maintenance

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dirt and sweat. For stubborn dirt, a slightly damp cloth can be used, followed by drying.
- **Avoid Chemicals:** Do not expose the watch to strong chemicals, solvents, or detergents, as these can damage the case, band, or internal components.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods, as this can affect battery life and accuracy.
- **Impact:** While durable, avoid dropping the watch or subjecting it to strong impacts.
- **Battery Replacement:** When the display becomes dim or the watch stops functioning, it may be time to replace the CR2032 battery. It is recommended to have battery replacement done by a professional to ensure water resistance is

maintained.

7. Troubleshooting

Problem	Possible Cause / Solution
Watch display is blank	Battery may be depleted. Replace the CR2032 battery. Ensure any battery insulation tab is removed.
Time is inaccurate	Time may need to be reset. Follow instructions in Section 3.2. Low battery can also affect accuracy.
Buttons are unresponsive	Ensure the watch is not in a locked mode (if applicable, though this model does not have a specific lock). Try pressing the MODE button to cycle through modes. If unresponsive, battery may be very low.
Water inside the display	Water resistance may have been compromised. Avoid further water exposure and seek professional inspection.

8. Specifications

Feature	Detail
Model Number	PDS-8015
ASIN	B0D6LNL5NL
Movement	Japanese Quartz Movement
Water Resistance	50M (5ATM)
Display Type	Digital with 7-Color LED Backlight
Functions	Time, Date, Day, Alarm, Chronograph (Stopwatch), Hourly Chime
Battery	1 x CR2032 (included)
Origin	China

9. Warranty and Support

PINDOWS offers a **12-month warranty service** for this product, ensuring your satisfaction and peace of mind. This warranty covers manufacturing defects and issues arising from normal use.
If you have any questions, concerns, or require assistance with your PINDOWS Digital Sports Watch, please do not hesitate to contact our customer support. We are committed to providing the best products and services to ensure your complete satisfaction. For support, please refer to the contact information provided with your purchase or visit the official PINDOWS brand store on Amazon: PINDOWS Store

© 2024 PINDOWS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6LNL5NL

More documents and user manuals: **https://manuals.plus/**