Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Orbegozo CP126105

Orbegozo CP126105 Ceiling Fan User Manual

Model: CP126105

1. Introduction

Thank you for choosing the Orbegozo CP126105 Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.

This ceiling fan is designed to provide efficient air circulation and comfort in your home, featuring three speeds and convenient remote control operation.

2. Safety Instructions

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power supply is disconnected at the main circuit breaker before installation or maintenance.
- Installation must be performed by a qualified electrician or a competent person.
- The mounting structure must be capable of supporting the weight of the fan (minimum 15 kg).
- Ensure the fan blades are at least 2.3 meters (7.5 feet) from the floor and 0.5 meters (1.6 feet) from any wall or obstruction.
- Do not insert any objects into the path of the rotating blades.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Clean the fan only with a soft, damp cloth. Do not use abrasive cleaners or solvents.

3. Package Contents

Carefully unpack your ceiling fan and ensure all items are present and undamaged. If any parts are missing or damaged, contact your retailer immediately.

- Fan Motor Assembly
- Fan Blades (3)

- Mounting Bracket
- Downrod and Canopy
- Remote Control and Wall Mount
- Hardware Pack (screws, washers, wire nuts)
- User Manual

4. Setup and Installation

Follow these steps for proper installation. Professional installation is recommended.

4.1 Pre-Installation Check

- Turn off power at the circuit breaker.
- Identify a suitable mounting location that can support the fan's weight and allows for proper blade clearance.

4.2 Mounting the Bracket

Secure the mounting bracket to the ceiling junction box using the provided screws and washers. Ensure it is firmly attached and level.

4.3 Assembling the Fan

- Attach the downrod to the fan motor assembly.
- Carefully lift the fan assembly and hang it on the mounting bracket hook.
- Connect the electrical wires (Live, Neutral, Earth) from the fan to the house wiring using wire nuts. Ensure all connections are secure.
- Attach the fan blades to the motor housing using the provided screws. Ensure they are securely fastened.
- Slide the canopy up to cover the mounting bracket and secure it with screws.



Image: The Orbegozo CP126105 Ceiling Fan, fully assembled and ready for operation. It features a white finish, a central motor housing, and three sleek blades extending outwards.

4.4 Remote Control Setup

Insert batteries (not included, typically AAA) into the remote control. If the fan does not respond, refer to the troubleshooting section for remote pairing instructions.

5. Operating Instructions

Your Orbegozo CP126105 Ceiling Fan is operated via the included remote control.

5.1 Power On/Off

- Press the **ON/OFF** button on the remote to turn the fan on or off.

5.2 Speed Control

The fan has 3 speed settings:

- Press the **Speed 1** button for low speed.
- Press the **Speed 2** button for medium speed.
- Press the **Speed 3** button for high speed.

5.3 Directional Control (Summer/Winter Mode)

Most ceiling fans include a reversible motor for year-round use. Locate the direction switch on the fan motor housing (usually a small slide switch).

- **Summer Mode (Counter-clockwise rotation):** Pushes air downwards, creating a cooling breeze.
- **Winter Mode (Clockwise rotation):** Draws air upwards, circulating warm air trapped near the ceiling.

Note: Always turn off the fan and wait for the blades to stop completely before changing the direction switch.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

6.1 Cleaning

- Before cleaning, ensure the power is turned off at the circuit breaker.
- Use a soft, lint-free cloth to wipe down the fan blades and motor housing.
- For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, solvents, or excessive moisture.

6.2 Blade Balance

If the fan wobbles during operation, check that all blade screws are tight and that the blades are not bent or damaged. A balancing kit (often sold separately) can be used to correct minor wobbles.

6.3 Lubrication

The fan motor is permanently lubricated and does not require additional oiling.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not start	No power supply Loose wire connections Remote control issues	Check circuit breaker and wall switch. Ensure all wire connections are secure (power off first). Check remote batteries; re-pair remote if necessary.
Fan wobbles	Loose blade screws Unbalanced blades Loose mounting bracket	Tighten all blade screws. Use a blade balancing kit. Ensure mounting bracket is securely fastened to the ceiling.
Remote control not working	Dead batteries Remote not paired Obstruction	Replace batteries. Refer to remote pairing instructions (usually involves holding a button on the remote while turning on power to the fan). Ensure clear line of sight to the fan's receiver.
Noisy operation	Loose screws Motor issues Blade rubbing	Check and tighten all screws on the fan. If motor noise persists, contact customer support. Ensure blades are not touching any part of the fan housing or ceiling.

8. Specifications

Feature	Detail
Brand	Orbegozo
Model	CP126105
Type	Ceiling Fan
Power Source	Electric Corded
Dimensions (Diameter x Height)	105 cm x 51 cm
Number of Blades	3
Control Method	Remote Control
Special Features	Remote Control, 3 Speeds
Power Consumption	60W

9. Warranty and Support

Your Orbegozo CP126105 Ceiling Fan comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, spare parts, or warranty claims, please contact Orbegozo customer service or your local retailer. Keep your proof of purchase for warranty validation.
For more information, you may visit the official Orbegozo website or contact their customer support:

- Orbegozo Official Website: www.orbegozo.com

© 2024 Orbegozo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6NNRJ66

More documents and user manuals: **https://manuals.plus/**