Aspes AC2601ENFDX

Aspes AC2601ENFDX No Frost Combi Refrigerator User Manual

Model: AC2601ENFDX

1. Important Safety Information

Read all instructions carefully before using the appliance. Keep this manual for future reference.

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Keep ventilation openings clear of obstruction.
- This appliance is intended for household use only.
- Unplug the appliance before cleaning or maintenance.

2. Product Overview

The Aspes AC2601ENFDX is a No Frost combi refrigerator designed for efficient food storage. It features separate compartments for refrigeration and freezing, an LED display, and an Eco Mode for energy saving.



Figure 1: Front view of the Aspes AC2601ENFDX No Frost Combi Refrigerator. This image shows the overall design, including the door handles and the external LED display panel.

Components:

- Refrigerator Compartment (238 L net capacity)
- Freezer Compartment (98 L net capacity)
- LED Display Panel
- Adjustable Shelves
- Door Bins
- Crisper Drawer (Fresh Zone)
- No Frost System (Refrigerator and Freezer)

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any damage. Report any damage to your retailer immediately.

3.2 Placement

- Place the refrigerator on a firm, level surface.
- Ensure adequate ventilation around the appliance. Maintain a minimum distance of 10 cm from walls and other furniture.
- Avoid direct sunlight and heat sources (e.g., ovens, radiators).
- The appliance is designed for ambient temperatures between SN-T (Subnormal to Tropical) climate classes.

3.3 Electrical Connection

Connect the appliance to a properly grounded electrical outlet. Ensure the voltage matches the rating label inside the appliance. Do not use extension cords or adapters.
Warning: This model is specified as "Sin enchufe" (Without plug). Professional installation by a qualified electrician may be required to connect the appliance to the mains supply safely.

3.4 First Use

After installation, wait at least 4 hours before plugging in the appliance to allow the refrigerant to settle. Clean the interior with a damp cloth before loading food.

4. Operating Instructions

4.1 Control Panel

The appliance features an external LED touch display for temperature control and mode selection.

- **Temperature Adjustment:** Press the temperature button to cycle through available temperature settings for the refrigerator and freezer compartments.
- **Eco Mode:** Activate Eco Mode for optimized energy consumption. This mode adjusts temperatures automatically to save energy.

4.2 Refrigerator Compartment

The refrigerator compartment is suitable for storing fresh foods. The multi-airflow system ensures even cooling. Utilize the crisper drawer for fruits and vegetables.

4.3 Freezer Compartment

The freezer compartment is designed for long-term storage of frozen foods and for freezing fresh food. The No Frost system prevents ice build-up, eliminating the need for manual defrosting.

- **Freezing Capacity:** 6 kg/24h. Do not exceed this capacity when freezing fresh food.
- For best results, freeze small quantities of food at a time.

5. Maintenance and Cleaning

Regular cleaning and maintenance ensure optimal performance and longevity of your appliance.

5.1 Cleaning the Interior

- Always unplug the appliance before cleaning.
- Clean the interior with a soft cloth and a mild detergent solution.
- Rinse with clean water and dry thoroughly.
- Do not use abrasive cleaners or sharp objects.

5.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. For stainless steel finishes, use a specialized stainless steel cleaner. Avoid harsh chemicals.

5.3 Defrosting

This appliance features a No Frost system, which automatically prevents ice build-up in both the refrigerator and freezer compartments. Manual defrosting is not required.

5.4 Power Outage

In case of a power outage, keep the doors closed to maintain the internal temperature for as long as possible. The freezer can maintain food quality for several hours.

6. Troubleshooting

Before contacting customer service, refer to the following table for common issues and solutions.

Problem	Possible Cause	Solution
Appliance does not operate.	No power supply.	Check if the appliance is plugged in correctly and the circuit breaker is not tripped.
Temperature is not cold enough.	Door not closed properly; excessive door opening; warm food placed inside; temperature setting too high.	Ensure door is sealed; reduce door openings; allow hot food to cool before storing; adjust temperature setting lower.
Unusual noises.	Appliance not level; objects touching the back wall; normal operating sounds.	Level the appliance; ensure nothing is touching the back; gurgling/hissing sounds are normal for refrigerant.
Water on the floor.	Drain hole blocked (refrigerator); excessive humidity.	Clear the drain hole; ensure doors are closed properly.

7. Technical Specifications

Feature	Specification
Model	AC2601ENFDX
Total Net Capacity	336 L
Refrigerator Net Capacity	238 L
Freezer Net Capacity	98 L

Feature	Specification
Dimensions (H x W x D)	200 cm x 59.5 cm x 59 cm
Weight	159 kg
Energy Efficiency Class	E
Annual Energy Consumption	247 kWh
Noise Level	39 dB
Climate Class	SN-T
Defrost System	No Frost
Display Type	LED Touch
Door Hinge	Right
Power Plug Type	Without plug (Sin enchufe)

8. Warranty and Customer Support

For warranty information and customer support, please refer to the warranty card included with your appliance or contact your retailer. Keep your proof of purchase for any warranty claims.
For technical assistance or spare parts, please contact Aspes customer service or an authorized service center.

© 2025 Aspes. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question