Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MIUZZY M244-B

MIUZZY M244 Cordless Vacuum Battery User Manual

Model: M244-B

Introduction

This manual provides essential information for the proper use, installation, maintenance, and troubleshooting of your MIUZZY 29.6V Replacement Battery for the M244 Cordless Vacuum. Please read this manual thoroughly before using the product to ensure optimal performance and safety.

Safety Instructions

- Use only the original charger or a MIUZZY-approved charger for this battery.
- Do not expose the battery to extreme temperatures (above 60°C / 140°F or below 0°C / 32°F).
- Do not disassemble, puncture, or modify the battery.
- Keep the battery away from water and moisture.
- If the battery shows signs of damage, swelling, or leakage, discontinue use immediately and dispose of it properly.
- Keep out of reach of children.

Setup

The MIUZZY 29.6V battery is designed for easy installation into your M244 cordless vacuum.

1. Unpacking

Carefully remove the battery from its packaging. Inspect the battery for any visible damage. If damaged, do not use and contact customer support.

2. Battery Installation

1. Ensure the M244 cordless vacuum is turned off and unplugged from any power source.
2. Locate the battery compartment on your M244 vacuum. Refer to your vacuum's original manual for precise location if needed.
3. Align the battery with the compartment and slide it in until it clicks securely into place. Ensure the connectors are

properly engaged.



Image: The MIUZZY 29.6V replacement battery, showing its sleek design and connection points, ready for installation into the vacuum cleaner.

3. Initial Charging

Before first use, it is recommended to fully charge the battery. Connect the vacuum (with the new battery installed) to its charger and plug it into a power outlet. The charging indicator lights on the vacuum will typically show the charging status.

Operating the Battery

Once installed and charged, the battery powers your M244 cordless vacuum, providing extended cleaning time.

- **Extended Runtime:** This 29.6V battery offers up to 60 minutes of runtime on a single charge, allowing for thorough cleaning sessions without interruption.
- **Consistent Power:** The battery is designed to deliver consistent suction power throughout its discharge cycle, ensuring efficient performance until it needs recharging.
- **Rechargeable:** The lithium-ion battery can be recharged multiple times, providing long-term use and cost savings.



Image: A person is shown using the MIUZZY M244 cordless vacuum in a living room, demonstrating its portability and effective cleaning, highlighting the extended runtime capability of the battery.

Maintenance

Proper maintenance will prolong the life and performance of your MIUZZY battery.

- **Regular Charging:** For optimal battery health, avoid completely draining the battery before recharging. Recharge it

after each significant use.

- **Storage:** If storing the battery for an extended period (more than a month), charge it to approximately 50-60% and store it in a cool, dry place away from direct sunlight and extreme temperatures. Recharge it every 3-6 months to prevent deep discharge.
- **Cleaning Contacts:** Periodically inspect and gently clean the battery contacts on both the battery and the vacuum with a dry cloth to ensure good electrical connection.
- **Disposal:** Do not dispose of the battery with household waste. Follow local regulations for proper disposal of lithium-ion batteries. Many electronics retailers or recycling centers offer battery recycling services.

Troubleshooting

If you encounter issues with your MIUZZY battery, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Battery not charging	Charger not connected, faulty charger, dirty contacts, battery too hot/cold.	Ensure charger is properly connected. Try a different outlet. Clean battery and vacuum contacts. Allow battery to reach room temperature before charging.
Short runtime	Battery not fully charged, battery degradation, vacuum operating in high power mode constantly.	Ensure battery is fully charged. If battery is old, consider replacement. Use standard power mode for general cleaning to maximize runtime.
Vacuum not turning on with battery	Battery not properly installed, battery completely drained, faulty battery.	Re-install battery, ensuring it clicks into place. Charge the battery. If issues persist, the battery may be faulty and require replacement.

If the problem persists after trying these solutions, please contact MIUZZY customer support.

Specifications

Feature	Detail
Brand	MIUZZY
Model Number	M244-B
Voltage	29.6V
Battery Type	Lithium Ion
Estimated Run Time	Up to 60 minutes (depending on usage mode)
Compatibility	MIUZZY M244 Cordless Vacuum
Item Weight	1 pounds

Feature	Detail
Package Dimensions	3 x 2 x 1 inches
Country of Origin	China

Warranty and Support

MIUZZY stands behind the quality of its products. Specific warranty terms and conditions for your battery are typically provided with your purchase documentation or can be found on the official MIUZZY website. Please retain your proof of purchase for warranty claims.
For technical support, troubleshooting assistance beyond this manual, or warranty inquiries, please contact MIUZZY customer service through their official website or the contact information provided with your product.
You can visit the MIUZZY Store on Amazon for more information and product support.

© 2024 MIUZZY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6QQTVK3

More documents and user manuals: **https://manuals.plus/**