Ukoke 3800S

Ukoke Ultrasonic Cleaner

Model: 3800S User Manual

1. Product Overview

The Ukoke 3800S Ultrasonic Cleaner is a professional-grade device designed for effective and gentle cleaning of various items using ultrasonic sound waves. It is suitable for cleaning jewelry, eyeglasses, watches, rings, diamonds, retainers, dentures, and other small electronics and lab instruments.

The unit generates 42,000 Hz of ultrasonic sound waves, creating microscopic bubbles that dislodge dirt and grime from surfaces, providing a thorough clean without causing damage to your valuables. For enhanced cleaning results, a small amount of liquid dish soap can be added to the water.

Figure 1: Ukoke 3800S Ultrasonic Cleaner with included accessories.

2. Safety Instructions

Please read and understand all safety instructions before operating the ultrasonic cleaner to prevent injury or damage to the unit.

- Do not immerse the main unit in water or other liquids.
- Ensure the power cord and plug are not damaged before use.
- Do not operate the unit with an empty tank. Always fill with water to the MAX line before turning on.
- Keep out of reach of children.
- Unplug the unit from the power outlet when not in use or before cleaning.
- Do not disassemble or attempt to repair the unit yourself. Contact qualified service personnel.
- Avoid placing items with loose stones, soft pearls, or items that are not waterproof into the cleaner. Consult a jeweler if unsure.

3. Package Contents

Verify that all items are present in the package:

- 1 x Ukoke 3800S Ultrasonic Cleaner
- 1 x Cleaning Basket
- 1 x Watch Stand
- 1 x Power Cord
- 1 x User Manual (this document)

Figure 2: The ultrasonic cleaner and examples of items suitable for cleaning.

4. Setup

1. Place the ultrasonic cleaner on a stable, flat, and dry surface near a power outlet.
2. Open the lid and fill the stainless steel tank with tap water. Do not exceed the 'MAX' fill line. For better results, use warm water (not hot).
3. If desired, add a few drops of non-abrasive liquid dish soap or a specialized ultrasonic cleaning solution to the water.
4. Plug the power cord into a grounded electrical outlet. The digital display will illuminate.

5. Operating Instructions

1. **Prepare Items:** Place the items to be cleaned into the cleaning basket. For delicate items or watches, use the provided watch stand. Ensure items are fully submerged in the water.
2. **Place Basket:** Carefully lower the basket with items into the tank.
3. **Close Lid:** Close the transparent lid.
4. **Select Cleaning Cycle:** The unit typically has preset cleaning cycles. Press the 'SET' button to cycle through the available timer settings (e.g., 90s, 180s, 280s, 380s, 480s).
5. **Start Cleaning:** Press the 'ON/OFF' button to start the cleaning process. The timer will begin counting down, and you will hear a buzzing sound, indicating the ultrasonic waves are active.
6. **End of Cycle:** The unit will automatically shut off when the selected cycle is complete.
7. **Remove Items:** Open the lid, carefully lift out the cleaning basket, and rinse the cleaned items under running water. Dry them thoroughly with a soft cloth.
8. **Drain Water:** Unplug the unit and drain the dirty water from the tank.

6. Maintenance and Care

- After each use, unplug the unit and drain the water from the tank.
- Wipe the stainless steel tank and the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners.
- Ensure the unit is completely dry before storing.
- Store the cleaner in a cool, dry place, away from direct sunlight and moisture.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not turn on	Not plugged in; Power outlet fault; Unit fault	Ensure plug is securely inserted; Test outlet with another device; Contact support
No buzzing sound	Insufficient water; Unit fault	Ensure water level is above MIN line; Contact support
Items not cleaning effectively	Water too cold; Too many items; Items too dirty; No cleaning solution added	Use warm water; Clean fewer items at a time; Pre-rinse heavily soiled items; Add a few drops of dish soap

8. Specifications

- **Model:** 3800S
- **Ultrasonic Frequency:** 42,000 Hz
- **Tank Material:** Stainless Steel
- **Power:** (Specific power not provided, typical for similar units is 35-50W)
- **Voltage:** (Specific voltage not provided, typical for US is 110-120V)
- **Dimensions:** Approximately 9.51in (L) x 6.73in (W) x 4.72in (H)

Figure 3: Detailed dimensions of the Ukoke 3800S Ultrasonic Cleaner.

9. Warranty and Support

Ukoke provides quality products and customer support. Specific warranty details are typically included with your purchase documentation or available on the official Ukoke website. For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact Ukoke customer service.

Please retain your proof of purchase for any warranty-related inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question