COMFEE' CKE17L1HBPH

COMFEE' CKE17L1HBPH 1.7L Electric Kettle User Manual

Model: CKE17L1HBPH | Brand: COMFEE'

1. Important Safety Instructions

Please read all instructions carefully before using this electric kettle and retain them for future reference. Improper use can result in electric shock, fire, or serious injury.

- Do not immerse the kettle, power base, cord, or plug in water or other liquids.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface, away from the edge of the countertop.
- Do not operate the kettle if the power cord or plug is damaged, or if the kettle malfunctions or has been damaged in any manner.
- Always ensure the lid is securely closed during operation to prevent scalding from hot steam.
- Do not fill the kettle above the 'MAX' line or below the 'MIN' line indicated on the water level window.
- Exercise extreme caution when handling the kettle containing hot water. The exterior of the kettle may become hot during use; use the cool-touch handle.
- Unplug the kettle from the outlet when not in use and before cleaning.
- This appliance is for household use only.

2. Product Overview

The COMFEE' CKE17L1HBPH electric kettle is designed for efficient water heating with precise temperature control and safety features.



The COMFEE' CKE17L1HBPH electric kettle features a brushed stainless steel body, a clear water level window, and a black handle with digital temperature controls.

Components:

- 1.7L Stainless Steel Electric Kettle
- Digital Power Base with Cord Storage

- User Manual



This image highlights the internal construction of the kettle, confirming that all water-contacting parts, including the inner wall, lid, and spout, are made from 304 food-grade stainless steel, ensuring no plastic contact with water.

3. Setup and First Use

Unpacking:

1. Carefully remove all packaging materials from the kettle and its accessories.
2. Inspect the kettle for any signs of damage. Do not use if damaged.

Initial Cleaning:

Before first use, or if the kettle has been stored for a long period, it is recommended to clean it.

1. Fill the kettle with fresh water up to the 'MAX' line.
2. Boil the water (select 212°F).
3. Discard the boiled water.
4. Repeat this process 2-3 times to ensure thorough cleaning.

4. Operating Instructions

Filling the Kettle:

1. Ensure the kettle is unplugged from the power outlet.
2. Press the lid release button to open the lid.
3. Fill the kettle with fresh water, observing the water level window. Do not fill below the 'MIN' mark or above the 'MAX' mark.
4. Close the lid securely until it clicks into place.

Placing on Power Base:

Place the kettle firmly onto the digital power base. The kettle can be rotated 360° on the base for convenience.

Temperature Selection and Boiling:

The kettle offers six preset temperature options for various beverages.



This image illustrates the six quick temperature presets available on the kettle's handle, ranging from 104°F for baby formula to 212°F for black tea, allowing precise temperature control for various beverages.

1. Plug the power base into a standard electrical outlet.
2. Press the power button ( ) on the handle to activate the display.
3. Press the temperature selection button ( ) repeatedly to cycle through the 6 preset temperatures:

- 104°F (Baby Formula)
- 140°F (Flower Tea)
- 158°F (Green Tea)
- 176°F (Oolong Tea)
- 194°F (Coffee)
- 212°F (Black Tea / Boil)

4. Once the desired temperature is selected, the kettle will begin heating. The display will show the current water temperature.
5. The kettle will automatically shut off once the selected temperature is reached.

Keep Warm Function:

The keep warm function maintains the selected temperature for up to 1 hour.



The kettle's keep warm function maintains the desired water temperature for up to one hour, as shown by the '1H' graphic surrounding the kettle.

1. After selecting a temperature and starting the heating process, press the 'Keep Warm' button (♨) once. The kettle will heat to the selected temperature and then enter keep warm mode for 1 hour.
2. If you press the 'Keep Warm' button twice, the kettle will heat to 212°F and then maintain that temperature for 1 hour.

3. To cancel the keep warm function, press the power button () or remove the kettle from the base.

Safety Features:



The kettle incorporates multiple safety features, including automatic shutdown upon reaching temperature, dry burn protection to prevent operation without water, and a cool-touch handle for safe pouring.

- **Automatic Shut-Off:** The kettle automatically turns off once the water reaches the selected temperature.

- **Boil-Dry Protection:** If the kettle is accidentally switched on without water or with insufficient water, it will automatically shut off to prevent damage.
- **Cool-Touch Handle:** The handle remains cool to the touch for safe pouring.

5. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle and ensure optimal performance.

Exterior Cleaning:

1. Unplug the kettle and allow it to cool completely before cleaning.
2. Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can scratch the stainless steel finish.
3. Ensure the power base and electrical connections remain dry.

Interior Descaling:

Mineral deposits (limescale) can build up inside the kettle, especially in hard water areas. Descaling regularly is important for efficiency and hygiene.

1. Fill the kettle with a solution of white vinegar and water (1:2 ratio) or a commercially available descaling solution.
2. Allow the solution to soak for at least 30 minutes, or boil the solution if the buildup is severe.
3. Empty the kettle and rinse thoroughly with fresh water several times.
4. For stubborn deposits, gently scrub the interior with a soft brush or sponge.
5. Boil and discard fresh water 2-3 times after descaling to remove any residual cleaning solution.

6. Troubleshooting

If you encounter issues with your kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	No power, kettle not properly seated on base, or boil-dry protection activated.	Check power outlet and plug. Ensure kettle is correctly placed on the base. If boil-dry protection activated, allow kettle to cool down before refilling.
Water not heating.	Kettle not switched on, or insufficient water.	Press the power button. Ensure water level is above the 'MIN' mark.
Kettle switches off before boiling/reaching target temperature.	Limescale buildup, or boil-dry protection activated.	Descale the kettle (see Maintenance section). Ensure sufficient water is in the kettle.
Water has an unusual taste or odor.	New kettle odor, or limescale buildup.	Perform initial cleaning steps (boil and discard water several times). Descale the kettle.
Lid does not close properly.	Obstruction or damage.	Check for any obstructions. If damaged, do not use and contact customer support.

7. Specifications

Brand	COMFEE'
Model Name	CKE17L1HBPH
Capacity	1.7 Litres (1.8 Quarts)
Power	1500W
Material	304 Food-Grade Stainless Steel
Special Features	Automatic Shut-Off, Boil Dry Protection, Digital Control, 6 Temperature Presets, 1-Hr Keep Warm
Product Dimensions	8.67"L x 5.9"W x 9.58"H
Item Weight	2.1 Pounds
Included Components	1.7L electric kettle, digital base, user manual
UPC	840296516089, 840296510582

8. Warranty and Support

Warranty Information:

COMFEE' provides a 1-year manufacturer warranty with your purchase. This warranty covers defects in materials and workmanship under normal use.
Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact COMFEE' customer service:

- **Website:** www.comfee.com
- **Email:** support@comfee.com
- **Phone:** (Please refer to your regional COMFEE' website for local contact numbers)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question