TechBrix GS-X2Plus

X2 Plus 4K Retro Game Stick

User Manual

Model: GS-X2Plus | Brand: TechBrix

Introduction

Thank you for purchasing the TechBrix X2 Plus 4K Retro Game Stick. This device is designed to provide a comprehensive retro gaming experience with its extensive library of built-in games and easy connectivity. This manual will guide you through the setup, operation, and maintenance of your new game console.

Key features include 4K HD HDMI output, over 30,000 built-in retro games, support for game search, collection, instant archiving, and pause functions. It also supports over 50 emulators and comes with two 2.4G wireless controllers for an immersive gaming experience.



Image: The compact X2 Plus Game Stick, designed for portability and ease of use.

What's in the Box

Please verify that all components are present in your package:

- 1 x Game Stick (X2 Plus Console)
- 1 x USB Wireless Receiver
- 1 x Extension HDMI Cable
- 1 x USB Power Cable
- 1 x TF Card (Pre-installed with games)
- 1 x User Manual (This document)
- 2 x 2.4G Wireless Controllers



Image: All components included in the X2 Plus Game Stick package, laid out for inspection.

Setup Guide

1. **Connect the Game Stick:** Insert the X2 Plus Game Stick directly into an available HDMI port on your TV, monitor, or projector. If space is limited, use the provided Extension HDMI Cable.
2. **Connect Power:** Connect the USB Power Cable to the Game Stick's power input port. Plug the other end of the USB Power Cable into a USB port on your TV or a 5V/1A USB power adapter (not included).
3. **Insert Wireless Receiver:** Plug the USB Wireless Receiver into the USB port on the Game Stick. This receiver enables communication with the wireless controllers.
4. **Prepare Controllers:** Each 2.4G Wireless Controller requires two AAA batteries (not included). Open the battery compartment on the back of each controller and insert the batteries, observing polarity.
5. **Power On:** Turn on your TV/monitor and select the correct HDMI input source corresponding to where the Game Stick is connected. The Game Stick will power on automatically when connected to power.
6. **Pair Controllers:** The controllers should automatically pair with the Game Stick once powered on and the receiver is connected. If they do not connect, press the 'MODE' button on the controller to initiate pairing.



Image: The X2 Plus Game Stick plugged into a television's HDMI port, ready for use with its wireless controllers.



Image: Illustration demonstrating the HDMI output connection from the game stick to a display, highlighting its 1080P HDMI capability.

Operating Instructions

Once the Game Stick is set up and powered on, you will see the main menu on your screen.

- **Navigation:** Use the directional pad (D-pad) on your wireless controller to navigate through the menu options and game lists.
- **Select/Confirm:** Press the 'A' or 'X' button (depending on controller layout) to select an option or confirm an action.
- **Back/Exit:** Press the 'B' or 'O' button to go back to the previous screen or exit a menu.
- **Starting a Game:** Browse the game library, select your desired game, and press the 'A' or 'X' button to start.
- **Game Functions:**
  - **Game Search:** Use the search function (usually accessible from the main menu) to quickly find specific games.
  - **Game Collection:** Add your favorite games to a 'Collection' for easy access.
  - **Instant Archive/Save State:** During gameplay, you can typically press a combination of buttons (refer to on-

screen prompts or specific emulator instructions) to save your game progress at any point.
    - **Load State:** Load previously saved game states to resume your game from where you left off.
    - **Pause:** Most games can be paused using the 'START' or 'PAUSE' button on the controller.
- **Emulators:** The system supports over 50 emulators, allowing access to a vast array of retro games. Specific emulator settings or controls may vary.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the Game Stick and controllers. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **TF Card Handling:** The TF card contains all game data. Avoid removing it frequently. If you need to remove it, ensure the device is powered off to prevent data corruption. Handle the card by its edges to avoid damaging the contacts.
- **Battery Replacement:** Replace controller batteries when performance degrades. Always use new AAA batteries and dispose of old batteries responsibly.

Troubleshooting

Problem	Possible Cause / Solution
No display on TV / "No Signal"	Ensure the Game Stick is fully inserted into the HDMI port. Verify the USB Power Cable is securely connected and receiving power. Check that your TV is set to the correct HDMI input source. Try a different HDMI port on your TV. Ensure the TF card is properly inserted into the Game Stick.
Controllers not responding	Check if batteries are correctly inserted and have sufficient charge. Replace if necessary. Ensure the USB Wireless Receiver is securely plugged into the Game Stick. Try pressing the 'MODE' button on the controller to re-initiate pairing. Move closer to the Game Stick to ensure a strong wireless signal.
Games not loading or missing	Ensure the TF card is properly inserted and not corrupted. Do not remove the TF card while the device is powered on. If the TF card was missing upon arrival, contact the seller immediately.
Poor audio quality or no sound	Check your TV's audio settings and volume level. Ensure the HDMI connection is secure. Some older retro games may naturally have lower fidelity audio.
Device freezes or overheats	Ensure the Game Stick has adequate ventilation. Do not place it in enclosed spaces. Avoid prolonged continuous use. Allow the device to cool down if it feels warm. Ensure the USB power source provides sufficient and stable power (5V/1A recommended).

Specifications

Feature	Detail
CPU	GB6
Output	HDMI (4K HD compatible)
Operating System	Emuelec4.3
External TF Card Support	Expandable up to 256GB (128GB included)
Controller Type	2.4G Wireless (Button Control)
Controller Power	2 x AAA batteries per controller (not included)
Pre-installed Games	30,000+
Supported Emulators	50+
Product Dimensions	5.91 x 2.76 x 2.76 inches
Item Weight	1.1 pounds
Material	Plastic
Model Number	GS-X2Plus

Warranty and Support

The TechBrix X2 Plus 4K Retro Game Stick comes with a standard manufacturer's warranty. Please refer to the specific warranty terms provided at the time of purchase or contact your retailer for details.
For technical support, troubleshooting assistance, or warranty claims, please contact the seller or manufacturer directly through the platform where you purchased the product. Provide your order number and a detailed description of the issue for prompt assistance.
Manufacturer: TechBrix

© 2024 TechBrix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question