PKSTVB Pixel 39 Sets Sound Effects

PKSTVB Darksaber Lightsaber User Manual

Model: Pixel 39 Sets Sound Effects

Introduction

This manual provides comprehensive instructions for the safe and effective use of your PKSTVB Black Metal Handle Darksaber Lightsaber. This advanced lightsaber features Pixel Lightsabers, motion control, 39 distinct sound effects, and 12 vibrant color changes, making it suitable for cosplay, display, or as a gift.

Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

What's in the Box

Verify that all components are present upon unboxing:

- 1 x Metal Handle
- 1 x Sturdy Blade
- 1 x User Manual
- 1 x Toolkit (including Allen Key)
- 1 x USB Charging Cable



Image: The Darksaber package contents, including the main box, metal handle, blade, and accessories.

Safety Information

Warning: Small parts may be generated. This product is recommended for individuals aged 14 years and up. Adult supervision is advised for younger users.

Do not expose the lightsaber to extreme temperatures or direct sunlight for prolonged periods. Avoid striking hard surfaces or other objects with excessive force, as this may damage the blade or internal components.

Setup

Assembly of your Darksaber is quick and straightforward:

1. Locate the two set screws on the side of the metal handle.
2. Using the provided Allen key from the toolkit, loosen these two set screws.
3. Carefully slide the blade into the opening of the metal handle. Ensure the connection chip on the blade aligns

properly with the internal mechanism of the handle.

4. Once the blade is fully inserted and seated, tighten the two set screws firmly to secure the blade in place. Do not overtighten.



Image: The fully assembled Darksaber Lightsaber.



Image: Detailed view of the Darksaber's hilt and blade, showcasing its advanced features.

Operating Instructions

Your Darksaber features intuitive motion control and button functions:

- **Power On/Off:** To activate the blade, simply twist your wrist while holding the hilt. To power off, repeat the twisting motion. The blade will extend or retract with a visual and auditory effect.
- **Sound Effects:** The lightsaber comes with 39 high-quality sound effects. These include smooth swing hums and motion-activated sounds. A quick press of the main button will trigger specific sound effects.
- **Color Change:** To change the blade color, press and hold the main button while twisting your wrist. The lightsaber supports 12 RGB colors. Release the button when your desired color is displayed.
- **Motion Control:** The lightsaber is equipped with sensitive motion control, allowing for dynamic sound and light responses during movement, including clash effects.



Image: The 12 RGB color options available for the Darksaber blade.



Image: Two Darksabers demonstrating dueling capabilities and various features.

Charging Instructions

The Darksaber is powered by a 2600mAh rechargeable lithium-ion battery.

1. To charge, locate the charging port at the base of the metal handle. This may require unscrewing the end cap.
2. Connect the provided USB charging cable to the lightsaber's Type-C charging port.
3. Connect the other end of the USB cable to a 5V1A charger.
4. Charging typically takes 3-4 hours for a full charge.

Important: Only use a 5V1A charger for charging. Using higher power currents can damage the circuit board and void the warranty.

CHARGING INSTRUCTIONS



Image: Charging port location and recommended charger specifications.

Maintenance

To ensure the longevity and optimal performance of your Darksaber:

- Keep the lightsaber clean by wiping it with a soft, dry cloth.
- Avoid exposing the lightsaber to water or excessive moisture.
- Store the lightsaber in its original packaging or a protective case when not in use to prevent damage.
- Ensure the set screws securing the blade are always tightened before use.

Troubleshooting

If you encounter any issues with your Darksaber, consider the following common solutions:

- **Lightsaber not turning on:**
  - Ensure the battery is fully charged. Refer to the "Charging Instructions" section.
  - Verify the blade is securely attached and the set screws are tightened.
- **Sound effects or colors not changing:**
  - Ensure you are performing the correct motion or button press as described in "Operating Instructions".

- Recharge the battery, as low power can affect advanced functions.

- **Blade flickering or uneven lighting:**
  - Check the connection between the blade and the hilt. Re-seat the blade if necessary.
  - Ensure the battery is adequately charged.

If problems persist after attempting these steps, please contact customer support.

Specifications

Feature	Detail
Product Dimensions	32 x 1.5 x 1.5 inches
Item Weight	2.2 pounds
Manufacturer Recommended Age	14 years and up
Battery Type	1 D battery required (included), 2600mAh rechargeable lithium-ion
Sound Effects	39 sets
Color Changes	12 RGB colors
Control Features	Motion control, smooth swing hum

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official PKSTVB website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 PKSTVB. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I have the hilt of this PKSTVB Darksaber Lightsaber, but I need the blade. Are there blades available?

The PKSTVB Darksaber Lightsaber user manual states that the product comes with "1 x Sturdy Blade" in the box. However, the manual does not provide information on where to purchase replacement blades separately. For...

Read full answer