Sogo FRE-SS-10895

Sogo FRE-SS-10895 Double 10.5L Hot Air Fryer Instruction Manual

1. Introduction

Thank you for choosing the Sogo FRE-SS-10895 Double 10.5L Hot Air Fryer. This appliance is designed to provide a healthier way to cook your favorite meals, utilizing hot air circulation to achieve crispy results with significantly less oil. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new air fryer. Please read it thoroughly before first use and keep it for future reference.

2. Safety Instructions

To ensure safe operation and prevent damage to the appliance or injury to yourself, please observe the following safety precautions:

- Always place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper ventilation.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation.
- Do not touch hot surfaces. Use the cool-touch handle when operating the baskets.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool down completely before handling.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- The appliance features overheat protection. If it overheats, it will automatically shut off.
- The non-slip feet ensure stability during use.
- Do not block the air inlet or outlet vents.

3. Product Overview

3.1 Components

- Main Unit with Digital Control Panel
- Dual Frying Baskets (10.5L total capacity)
- Food Rack
- Separator (for cooking two different dishes simultaneously)
- BPA-free Silicone Tab

3.2 Control Panel

The Sogo FRE-SS-10895 features an intuitive LED digital display and touch panel for precise control over cooking settings.



Figure 1: Front view of the Sogo FRE-SS-10895 Double Hot Air Fryer, showing the digital control panel at the top and the two cooking compartments with viewing windows below. The control panel features temperature and time displays, along with various function icons and power buttons.

The control panel allows you to:

- Adjust temperature from 50°C to 200°C (Dehydrator function: 30°C to 80°C).
- Set the timer from 1 to 60 minutes (Dehydrator function: 30 minutes to 24 hours).
- Select from 10 preset cooking functions.
- Utilize 'Smart Finish' for synchronized cooking of different dishes.
- Utilize 'Match Cook' for cooking large quantities across both baskets.
- Receive an automatic shake reminder during cooking.

4. Setup

Before using your air fryer for the first time:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wipe the exterior of the appliance with a damp cloth.
3. Wash the frying baskets, food rack, separator, and silicone tab with hot, soapy water. Rinse thoroughly and dry completely.
4. Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is adequate space (at least 10 cm) around the appliance for proper air circulation.
5. Insert the frying baskets into the main unit.

5. Operating Instructions

5.1 Basic Operation

1. Plug the power cord into a grounded electrical outlet. The appliance will beep, and the display will illuminate briefly.
2. Press the power button to turn on the air fryer.
3. Place your food into the frying baskets. Do not overfill.
4. Select your desired cooking temperature using the temperature controls (50°C - 200°C). For dehydration, the range is 30°C - 80°C.
5. Set the cooking time using the timer controls (1 - 60 minutes). For dehydration, the range is 30 minutes - 24 hours.
6. Press the start/pause button to begin cooking.
7. During cooking, the appliance may prompt you to shake the food for even results.
8. Once the timer expires, the air fryer will automatically stop. Carefully remove the baskets using the cool-touch handles.

5.2 Preset Functions

The air fryer includes 10 preset functions for common dishes. Refer to the digital cookbook for specific instructions and recommended settings for each preset.

5.3 Smart Finish

The 'Smart Finish' system allows you to cook two different dishes simultaneously, ensuring they finish cooking at the same time, even if they require different temperatures and durations. Follow the on-screen prompts to set individual cooking parameters for each basket.

5.4 Match Cook

The 'Match Cook' function is ideal for preparing large quantities of the same food. It synchronizes the settings for both baskets, ensuring consistent cooking results across the entire 10.5L capacity.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. The stainless steel internal cavity is designed for easy cleaning. Wipe it with a damp cloth after each use.
3. Wash the frying baskets, food rack, separator, and silicone tab with hot, soapy water. These accessories are

also dishwasher safe.

4. Do not use abrasive cleaning materials or harsh detergents, as they can damage the non-stick coating and surfaces.
5. Wipe the exterior of the appliance with a soft, damp cloth.
6. Ensure all parts are thoroughly dry before storing or next use.

7. Troubleshooting

If you encounter any issues with your Sogo FRE-SS-10895 Air Fryer, please refer to the following common problems and solutions:

- **Appliance does not turn on:** Check if the power cord is securely plugged into a working outlet.
- **Food is not cooked evenly:** Ensure the baskets are not overfilled. Use the shake reminder function or manually shake/flip food halfway through cooking.
- **White smoke coming from the appliance:** This may indicate excessive fat from food dripping onto the heating element. Clean the basket and bottom of the appliance thoroughly.
- **Appliance stops unexpectedly:** The overheat protection may have activated. Unplug the appliance and let it cool down for at least 30 minutes before restarting.

If the problem persists, please contact customer support.

8. Specifications

- **Model Number:** FRE-SS-10895
- **Brand:** SOGO
- **Power:** Max. 2600W
- **Capacity:** 10.5 Liters
- **Temperature Range:** 50°C - 200°C (Dehydrator: 30°C - 80°C)
- **Timer Range:** 1 - 60 minutes (Dehydrator: 30 minutes - 24 hours)
- **Dimensions (W x D x H):** 400 mm x 360 mm x 320 mm
- **Weight:** 7.8 kg
- **Internal Cavity Material:** Stainless Steel

9. Warranty and Support

The Sogo FRE-SS-10895 Air Fryer comes with a warranty period of at least 2 years from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

- **Spare Parts Availability:** 1 Year
- **Software Updates:** Information not available
- **Manufacturer:** SOGO Human Technology

For technical support, service, or spare parts inquiries, please contact your retailer or the manufacturer directly. Do not attempt to repair the appliance yourself.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question