Calvin Klein 25200298

Calvin Klein 25200298 Men's Watch Instruction Manual

Introduction

Thank you for choosing the Calvin Klein 25200298 Men's Watch. This manual provides essential information for the proper setup, operation, maintenance, and care of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

Your Calvin Klein watch features a precise quartz movement, an analog display, and a chronograph function, designed for daily wear with water resistance.



Front view of the Calvin Klein 25200298 Men's Watch, showcasing the dial, hands, subdials, crown, and pushers.

Setup

1. Setting the Time

1. Pull the crown (B) out to position 2.
2. Rotate the crown (B) clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown (B) back into position 0.

2. Setting the Date

1. Pull the crown (B) out to position 1.
2. Rotate the crown (B) clockwise to advance the date. Continue rotating until the correct date is displayed in the date window.
3. Once the date is set, push the crown (B) back into position 0.
4. *Note: Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism.*

3. Adjusting the Strap

The leather strap is equipped with a traditional buckle clasp. Adjust the strap length by inserting the pin into the desired hole for a comfortable and secure fit on your wrist.

Operating

1. Reading the Time

The watch displays time using traditional hour, minute, and second hands on an analog dial.

2. Using the Chronograph Function

Your watch is equipped with a chronograph (stopwatch) function, controlled by the two pushers (A and C) located on either side of the crown.

- **Start/Stop:** Press pusher A (top pusher) to start the chronograph. Press pusher A again to stop it.
- **Reset:** While the chronograph is stopped, press pusher C (bottom pusher) to reset all chronograph hands to their zero positions.
- **Reading:** The subdials measure elapsed seconds, minutes, and potentially hours, depending on the specific movement. Refer to the markings on the subdials for precise readings.

3. Water Resistance

This watch is rated for 3 meters (3 ATM) of water resistance, indicated as "Daily Water Resistant." This means it is suitable for everyday use and can withstand splashes, rain, or brief immersion in water. It is **not** suitable for swimming, showering, diving, or any water sports. Always ensure the crown is fully pushed in before any contact with water.

Maintenance

1. Cleaning

- **Case and Crystal:** Wipe regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth with mild soap, then wipe dry immediately.
- **Leather Strap:** Avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean with a dry, soft cloth. If it gets wet, allow it to air dry naturally, away from direct heat.

2. Battery Replacement

The watch is powered by a Silver Oxide battery. When the watch stops or the second hand begins to jump irregularly (indicating a low battery), it is time for a battery replacement. We recommend having the battery replaced by a qualified watchmaker or authorized service center to ensure the water resistance seals are properly maintained.

3. Water Resistance Seals

The water resistance of your watch is not permanent and may decrease over time due to the aging of gaskets. It is advisable to have the water resistance checked annually by an authorized service center, especially after battery replacement.

4. Storage

When not wearing your watch, store it in a dry place, away from extreme temperatures, direct sunlight, and strong magnetic fields (e.g., speakers, refrigerators, mobile phones), which can affect the accuracy of the movement.



Back view of the Calvin Klein 25200298 Men's Watch, showing the stainless steel case back with engravings.

Troubleshooting

- **Watch not running:** Check if the crown is fully pushed into position 0. If it is, the battery may need replacement.
- **Time is inaccurate:** Reset the time as per the 'Setting the Time' instructions. If inaccuracy persists, the battery may be low, or the movement may require servicing.
- **Chronograph hands not resetting to zero:** If the chronograph hands do not return to their 12 o'clock (zero) position after pressing the reset pusher, consult an authorized service center.
- **Condensation under the crystal:** This indicates moisture has entered the watch. Seek professional service immediately to prevent damage to the movement.

For any issues not covered here, please contact an authorized Calvin Klein service center or your retailer.

Specifications

Brand	Calvin Klein
Model Name	25200298
Movement	Quartz

Display Type	Analog
Case Material	Stainless Steel
Band Material	Leather
Band Width	18 Millimetres
Water Resistance Level	3 Metres (Daily Water Resistant)
Battery Cell Type	Silver Oxide
Special Features	Chronograph, Water Resistant

Warranty

Your Calvin Klein 25200298 Men's Watch comes with a**2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear of the case, crystal, or strap.

Please retain your proof of purchase, as it will be required for any warranty claims.

Support

For technical assistance, warranty service, or general inquiries regarding your Calvin Klein watch, please contact the retailer where the watch was purchased or visit the official Calvin Klein website for a list of authorized service centers in your region.

When contacting support, please have your watch model number (25200298) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question