Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy 2032349

iJoy Social Media Kit User Manual

Model: 2032349

Introduction

This user manual provides comprehensive instructions for the iJoy Social Media Kit, designed to enhance your content creation experience. The kit includes a versatile hand grip, a stable tripod, and a 360-degree rotatable clip-on ring light, enabling you to capture high-quality photos and videos with ease. Please read this manual thoroughly before using the product to ensure proper operation and longevity.

Kit Components

The iJoy Social Media Kit consists of the following main components:

- **Hand Grip:** A comfortable handle designed for stable handheld shooting.
- **Tripod:** A foldable, lightweight stand that provides a stable base for your device.
- **360-Degree Rotatable Clip-On Ring Light:** An adjustable light source to illuminate your subjects.
- **Phone Holder:** An adjustable clip integrated with the hand grip/tripod to secure your smartphone.



Figure 1: Overview of the iJoy Social Media Kit components, showing the hand grip, tripod, and clip-on ring light attached to a smartphone.



Figure 2: The adjustable tripod component, providing a stable base for your smartphone during recording or photography.



Figure 3: Close-up view of the 360-degree rotatable clip-on ring light, showing its compact design and light source.

Setup Instructions

1. **Attach Smartphone to Holder:** Gently pull open the adjustable phone holder on the hand grip/tripod and carefully

insert your smartphone. Ensure the phone is securely seated and balanced.

2. **Convert to Tripod (Optional):** If using as a tripod, unfold the legs of the hand grip until they are fully extended and stable on a flat surface.
3. **Attach Ring Light:** Clip the 360-degree rotatable ring light onto the top edge of your smartphone, ensuring it does not obstruct the camera lens. The clip is designed to securely hold the light in place.
4. **Adjust Angle:** Adjust the angle of your smartphone and the ring light as needed for optimal framing and illumination. The ring light can be rotated 360 degrees for precise positioning.



Figure 4: The hand grip in use, demonstrating how a smartphone and ring light are attached for mobile content creation.

Operating Instructions

Using the Ring Light

1. **Power On/Off:** Locate the power button on the ring light. Press and hold the button to turn the light on or off.
2. **Adjust Brightness:** Once powered on, short press the power button to cycle through different brightness levels. The ring light offers adjustable brightness settings to suit various lighting conditions.
3. **Charging:** The ring light is powered via USB. Connect the provided USB cable to the ring light's charging port and to a standard USB power source (e.g., computer, wall adapter). An indicator light will typically show charging status.

Using the Hand Grip and Tripod

- **Handheld Use:** Hold the hand grip firmly to stabilize your smartphone while recording videos or taking photos on the go.
- **Tripod Use:** Place the extended tripod on a flat, stable surface. This is ideal for stationary shots, video calls, or time-lapse photography. Ensure the tripod legs are fully spread for maximum stability.
- **Angle Adjustment:** The phone holder allows for tilting and rotating your smartphone to achieve the desired shooting angle.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the hand grip, tripod, and ring light. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the kit in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Handle all components with care to prevent damage. Avoid dropping the kit or applying excessive force to moving parts.

Troubleshooting

Problem	Possible Cause	Solution
Ring light does not turn on.	Battery is depleted or not charged.	Charge the ring light using the provided USB cable. Ensure the charging cable is securely connected.
Smartphone is not stable in the holder.	Smartphone not properly seated or holder not fully closed.	Ensure the smartphone is centered and securely gripped by the holder. Adjust the holder's grip if necessary.
Tripod is wobbly.	Legs not fully extended or placed on an uneven surface.	Ensure all tripod legs are fully extended and locked into position. Place the tripod on a flat, stable surface.

Specifications

Feature	Detail
Model Number	2032349
Product Dimensions	2.5 x 4 x 8 inches
Item Weight	5.8 ounces
Connectivity Technology	USB

Feature	Detail
Hardware Interface	USB
Flash Modes Description	Constant illumination, adjustable brightness
Has Self-Timer	No
Water Resistance Level	Not water resistant

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the manufacturer's official website or contact their customer service directly. Specific warranty details are not provided within this manual.
Manufacturer: Quest Products
Brand: iJoy

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7MY8TVL

More documents and user manuals: **https://manuals.plus/**