Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HEX BOTS 6071518

HEX BOTS Robotic Scorpion Instruction Manual

Brand: HEX BOTS | **Model:** 6071518

1. Introduction

The HEXBOTS® Scorpion is a fast-crawling robotic toy designed to mimic a vibrant scorpion with its swinging tail and movable front claws. It scurries lifelike over smooth surfaces and intelligently repels from obstacles, changing direction to continue its movement. This manual provides essential information for the safe and effective use of your Robotic Scorpion.

Key Features:

- **Creepy-Crawly Robot Scorpion:** Motorized scorpion ideal for children aged 4-6 who enjoy building and playing with robots.
- **Lifelike Scorpion Toy:** Features ricocheting claws and a bobbing tail with a stinger, creating a realistic appearance.
- **Independent Design:** Scorpions explore surfaces, encouraging imaginative play and providing sensory engagement.
- **Batteries Included:** Comes with 3 LR44 batteries for immediate use.
- **Robotic Kids Toys & Games:** A fun addition to any toy collection, designed for mechanical chaos.

2. Setup

Follow these steps to prepare your HEX BOTS Robotic Scorpion for play:

1. **Unboxing:** Carefully remove the Robotic Scorpion from its packaging.
2. **No Assembly Required:** The product comes pre-assembled and ready for use.
3. **Battery Installation:** The Robotic Scorpion comes with 3 LR44 batteries already installed. No additional battery installation is needed for initial use.
4. **Power On:** To activate the Scorpion, locate the on/off switch on the bottom of the toy and press it.



Figure 1: The HEX BOTS Robotic Scorpion in its ready-to-play state.

3. Operating Instructions

Control your Robotic Scorpion using the provided remote control:

- **Remote Control:** The compact remote features a joystick for movement and buttons for additional functions.
- **Movement:** Use the joystick to move the scorpion forward, backward, and turn left or right. The scorpion's six legs will move realistically as it scurries across smooth surfaces.
- **Lights & Sounds:** The remote control includes buttons to toggle the scorpion's lights and sound effects on or off. This allows for varied play experiences, including "stealth mode" without sounds.
- **Obstacle Avoidance:** The scorpion is designed to intelligently detect and repel from obstacles, changing its direction to continue moving.

4. Maintenance

To ensure the longevity and optimal performance of your Robotic Scorpion, follow these maintenance guidelines:

- **Cleaning:** Wipe the toy with a dry, soft cloth to remove dust and debris. Avoid using water or cleaning solutions, as this may damage electronic components.
- **Storage:** Store the Robotic Scorpion in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** While the scorpion uses LR44 batteries, which are typically not rechargeable, ensure the remote control's batteries (if applicable, usually AAA for similar toys) are replaced when power is low. For the scorpion's internal battery, if it's rechargeable via Micro USB (as indicated in some product descriptions for similar Hexbug products, though not explicitly stated as rechargeable for this specific model in the provided JSON, only that it has a Micro USB port), ensure it is charged using the provided cable and a compatible USB power source.

5. Troubleshooting

If you encounter issues with your Robotic Scorpion, refer to the following common solutions:

- **Scorpion Not Moving:**
  - Ensure the on/off switch on the bottom of the scorpion is in the "On" position.
  - Check if the LR44 batteries are depleted. Replace them if necessary.
  - Verify that the remote control batteries are fresh and correctly installed.
  - Ensure the scorpion and remote are within operating range and paired correctly (usually automatic upon power-on).
- **Intermittent Movement/Control:**
  - Check for interference from other electronic devices.
  - Ensure the play surface is smooth and free of debris that might impede leg movement.
- **Lights or Sounds Not Working:**
  - Press the respective light/sound buttons on the remote control to toggle them on.
  - Check battery levels for both the scorpion and the remote.

6. Specifications

Feature	Detail
Brand	HEX BOTS
Model Number	6071518
Product Dimensions	4.33 x 3.15 x 3.15 inches
Item Weight	3.84 ounces
Manufacturer Recommended Age	0 - 12 years (Note: Product description states 4-6 years, packaging states 8+)
Batteries	3 LR44 batteries required (included)
Release Date	July 19, 2024
Department	Kids / Unisex
Manufacturer	HEX BOTS

7. Warranty and Support

For warranty information, technical support, or replacement parts, please contact HEX BOTS customer service through their official website or the retailer where the product was purchased. Keep your proof of purchase for warranty claims.

© 2024 HEX BOTS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7WF7M1C

More documents and user manuals: **https://manuals.plus/**