Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TACTACAM RV-TC-XPRO3

TACTACAM Reveal Pro 3.0 Cellular Trail Camera

Model: RV-TC-XPRO3

1. Introduction

The TACTACAM Reveal Pro 3.0 Cellular Trail Camera is a state-of-the-art device designed for remote monitoring and scouting. It offers multi-cellular network capabilities, allowing you to receive instant photo and video deliveries directly to your mobile device from virtually any location. Engineered for durability, this camera performs reliably in extreme weather conditions, making it an ideal tool for outdoor enthusiasts and property surveillance.

Key features include a 2-inch LCD screen for easy setup and viewing, no-glow infrared technology for discreet night captures, Wi-Fi connectivity, and the ability to capture high-definition photos and 1080p videos. Its fast trigger speed ensures you capture every moment, and the long battery life provides extended operational periods.

2. Setup Guide

Setting up your Reveal Pro 3.0 camera is designed to be quick and user-friendly. Follow these steps to get your camera operational:

1. **Battery Installation:** Open the camera's battery compartment. Insert 12 AA batteries (not included), ensuring correct polarity. For optimal performance, use high-quality lithium batteries, especially in cold weather.
2. **SD Card (Optional):** While the Reveal Pro 3.0 features built-in storage, an optional SD card slot is available for additional storage capacity. If using an SD card, insert a Class 10, U3 rated SD card (up to 32GB recommended) into the designated slot. Ensure the card is formatted within the camera settings.
3. **SIM Card Activation:** Your camera includes a preactivated SIM card. This card will automatically connect to your mobile device via the TACTACAM REVEAL app.
4. **App Download & Account Setup:** Download the TACTACAM REVEAL app from your smartphone's app store. Create an account and follow the in-app instructions to add your camera. This process will guide you through cellular connection and initial configuration.
5. **Mounting the Camera:** Use the included tree mount to securely attach the camera to a tree or post. Position the camera to capture the desired area, ensuring a clear line of sight and optimal trigger coverage. Adjust the angle as needed.





Image: TACTACAM Reveal Pro 3.0 camera with antenna and tree mount accessory, ready for installation.



Image: A person securely attaching the TACTACAM Reveal Pro 3.0 camera to a tree using the provided strap.


RoHS
TACTACAM LLC
Made in China



Image: The TACTACAM Reveal Pro 3.0 camera with its side compartment open, revealing the 2-inch LCD screen and control buttons for easy access and configuration.

3. Operating Instructions

Once your camera is set up and connected, you can begin monitoring. The TACTACAM REVEAL app is your primary interface for managing the camera.

- **Accessing the App:** Open the TACTACAM REVEAL app on your smartphone. From here, you can view galleries, share feeds, adjust camera settings, and review critical statistics.
- **Photo and Video Capture:** The camera automatically captures HD photos and 1080p videos when motion is detected. The fast trigger speed minimizes missed events.
- **No-Glow IR Technology:** For night time captures, the integrated no-glow IR technology ensures that the camera remains virtually undetectable to humans or animals, providing clear images without spooking wildlife.
- **Burst Mode:** Utilize the 5-shot burst mode feature to capture multiple images in quick succession, increasing the chances of getting the perfect shot of fast-moving subjects.
- **GPS Functionality:** The built-in GPS allows for precise location tracking of your camera, which can be viewed within the app.
- **2-inch LCD Screen:** Use the physical buttons and the 2-inch LCD screen on the camera for direct adjustments to settings, reviewing captured media, and ensuring proper camera function in the field.



Image: The TACTACAM Reveal Pro 3.0 camera positioned on a truck bed, surrounded by hunting and outdoor gear, illustrating its

rugged design and readiness for field use.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your TACTACAM Reveal Pro 3.0 camera:

- **Battery Management:** Regularly check battery levels via the REVEAL app. Replace batteries promptly when low to avoid interruption in service. Consider using external power sources like solar panels for extended deployment.
- **Cleaning:** Periodically clean the camera lens and IR sensors with a soft, lint-free cloth to ensure clear image quality. Wipe down the camera body to remove dirt, dust, or debris.
- **Weather Protection:** Although the camera is designed to withstand extreme weather (IP54 rated), ensure it is securely mounted and not directly exposed to prolonged standing water. Clear any snow or ice accumulation from the camera.
- **SD Card Maintenance:** If using an optional SD card, format it regularly to prevent data corruption and ensure smooth operation. Back up important media before formatting.

5. Troubleshooting

If you encounter issues with your TACTACAM Reveal Pro 3.0, refer to the following common troubleshooting tips:

- **No Photos/Videos Transmitting:**
  - Check battery levels. Low batteries can affect cellular transmission.
  - Verify cellular signal strength in the camera's location via the app or LCD screen. Move the camera to an area with better coverage if needed.
  - Ensure your data plan is active and has sufficient data.
  - Confirm the camera settings in the app are configured correctly for photo/video transmission.
- **Poor Image Quality:**
  - Clean the camera lens and IR sensors.
  - Check for obstructions in front of the camera.
  - Ensure the camera is mounted securely to prevent movement that could blur images.
- **Camera Not Powering On:**
  - Ensure batteries are inserted correctly and are fully charged.
  - Try a fresh set of batteries.
- **App Connectivity Issues:**
  - Ensure your smartphone has a stable internet connection.
  - Update the TACTACAM REVEAL app to the latest version.
  - Restart both your camera and your smartphone.

For further assistance, please contact TACTACAM customer service as detailed in the Warranty and Support section.

6. Specifications

Feature	Specification
Model Name	REVEAL Pro 3.0

Feature	Specification
Item Model Number	RV-TC-XPRO3
Indoor/Outdoor Usage	Outdoor
Connectivity Protocol	Cellular, Wi-Fi
Power Source	Battery Powered
Video Capture Resolution	1080p
Alert Type	Motion Only
International Protection Rating	IP54
Item Dimensions (L x W x H)	9 x 5 x 3 inches
Item Weight	2.46 pounds
Special Features	Built-in-GPS, 2" LCD Screen, 5-Shot Burst Mode
Mounting Type	Tree Mount

7. Warranty and Support

The TACTACAM Reveal Pro 3.0 Cellular Trail Camera comes with a comprehensive one-year warranty. This warranty assures protection for your investment and peace of mind regarding the product's quality and performance.

For any questions, technical support, or warranty claims, TACTACAM provides top-notch in-house customer service. You can reach out to them through the contact information provided on the official TACTACAM website or within the TACTACAM REVEAL app.

Regularly check the TACTACAM website and the REVEAL app for firmware updates and additional support resources to ensure your camera operates with the latest features and improvements.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D849DM1K

More documents and user manuals: **https://manuals.plus/**