**realme RMX3933**

# realme C61 Safari Green User Manual

Model: RMX3933 | Brand: realme

## Product Overview

The realme C61 is a smartphone designed for reliable performance and user-friendly experience. It features a 6.67-inch IPS display with a 90 Hz Refresh Rate, a 50MP rear camera, and an 8MP front camera. Powered by a Unisoc T606 chipset, it offers smooth processing and comes with 4 GB RAM + 4 GB Virtual RAM and 64 GB inbuilt memory. The device is equipped with a 5,000 mAh battery for extended usage.




Image: Front and rear view of the realme C61 Safari Green smartphone, showcasing its camera module and display.

## What's in the Box

- realme C61 Safari Green Smartphone
- Adapter
- USB Cable
- SIM Ejector Tool
- Quick Start Guide
- Warranty Card

Note: Contents may vary slightly by region. Please check the packaging for exact inclusions.

## Setup

### 1. Initial Charging

Before first use, fully charge your realme C61 using the provided adapter and USB cable. Connect the USB cable to the phone's charging port and the adapter to a power outlet. The charging indicator will appear on the screen.

### 2. SIM Card and SD Card Installation

1. Locate the SIM card tray on the side of the phone.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray, ensuring correct orientation. The realme C61 supports Dual SIM and a Hybrid SIM Slot.
4. Carefully push the tray back into the phone until it is flush with the side.

### 3. Powering On and Initial Setup

Press and hold the Power button (located on the side) until the realme logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account setup, and security settings.

## Operating Your Device

### Basic Navigation

- **Touchscreen Gestures:** Tap to select, swipe to scroll, pinch to zoom.
- **Power Button:** Press to lock/unlock screen, press and hold to power off/restart.
- **Volume Buttons:** Adjust media volume, call volume, and ringtone volume.

### Calls and Messaging

Use the Phone app to make calls and the Messages app for SMS/MMS. Ensure your SIM card is active and has network coverage.

### Camera Usage

The realme C61 features a 50MP rear camera and an 8MP front camera. Open the Camera app to capture photos and videos. Explore different modes like Portrait, Night, and Pro for enhanced photography.

### Connectivity

- **Wi-Fi:** Connect to wireless networks via Settings > Network & internet > Wi-Fi.
- **Bluetooth:** Pair with Bluetooth devices like headphones or speakers via Settings > Connected devices > Bluetooth.
- **GPS:** Utilize location services for navigation and location-based apps.

### Battery Management

The 5000mAh battery provides long-lasting usage. To optimize battery life, reduce screen brightness, close unused apps, and enable battery saver mode when needed.

## Maintenance

### Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials. Do not expose the phone to excessive moisture.

### Software Updates

Regularly check for system updates to ensure your device has the latest features and security patches. Go to Settings > System > System update to check for and install updates.

### Battery Care

To prolong battery lifespan, avoid extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for optimal long-term health.

## Troubleshooting

| Issue | Possible Solution |
|---|---|
| Device not turning on | Ensure the battery is charged. Press and hold the Power button for at least 10-15 seconds to force restart. |
| Apps crashing or freezing | Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the device. Update the app or the system software. |
| Poor network signal | Check SIM card insertion. Try restarting the phone. Ensure you are in an area with good network coverage. Reset network settings (Settings > System > Reset options > Reset Wi-Fi, mobile & Bluetooth). |
| Battery draining quickly | Reduce screen brightness. Close background apps. Disable unnecessary features like GPS, Bluetooth, Wi-Fi when not in use. Check battery usage in settings to identify power-hungry apps. |
| Screen unresponsive | Force restart the device by holding the Power button. If the issue persists, consider a factory reset (backup data first). |

For persistent issues, contact realme customer support or visit an authorized service center. As a last resort, a factory reset can resolve many software-related problems, but it will erase all data on your device. **Backup your data before performing a factory reset.**

## Specifications

| Feature | Detail |
|---|---|
| **Brand** | realme |
| **Model Number** | RMX3933 |
| **Operating System** | Android 14 |
| **RAM** | 4 GB |
| **Internal Storage** | 64 GB |
| **Display** | 6.67-inch IPS Display, 90 Hz Refresh Rate, 180 Hz Touch Sampling Rate, 1600 x 720 Resolution |
| **Processor** | Unisoc T606 chipset |

| Feature | Detail |
| --- | --- |
| **Rear Camera** | 50MP |
| **Front Camera** | 8MP |
| **Battery** | 5000 mAh Lithium Ion (included) |
| **Connectivity** | Wi-Fi, Wi-Fi Direct, Hotspot, Bluetooth, GPS (L1, G1, B1I, E1, L1) |
| **Audio Jack** | 3.5 mm |
| **Dimensions (LxWxH)** | 16.02 x 7.33 x 0.8 cm |
| **Item Weight** | 187 g |
| **Color** | Safari Green |
| **Country of Origin** | India |

## Warranty and Support

Your realme C61 smartphone comes with a standard manufacturer's warranty. Please refer to the warranty card included in the box for specific terms and conditions, including warranty period and coverage details.
For technical support, service requests, or further inquiries, please visit the official realme support website or contact their customer service hotline. You can find contact information on the realme website or in your product documentation.
**Online Support:** realme India Support
**Manufacturer:** Realme, Oppo Mobiles India Private Limited

© 2024 realme. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question