**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Vikye Vikyeoyd4geahkz

# Vikye Rechargeable Touch Control Music Desk Lamp

User Manual

## 1. Product Overview

The Vikye Rechargeable Touch Control Music Desk Lamp is a versatile lighting solution designed for home and office environments. It combines a dimmable LED desk lamp with a built-in Bluetooth speaker, offering both illumination and audio entertainment. Its touch control interface allows for easy adjustment of light brightness, while the rechargeable battery provides portability and energy efficiency. This lamp is compatible with various audio devices, including smartphones, computers, and MP3/MP4 players, via Bluetooth or the included audio cable.





Figure 1.1: Front view of the Vikye Rechargeable Touch Control Music Desk Lamp.

## 2. Safety Information

Please read all safety instructions carefully before using the product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not expose the lamp to water or excessive moisture.
- Do not disassemble, repair, or modify the lamp yourself. Refer all servicing to qualified personnel.
- Use only the provided USB charging cable and a compatible DC 5V power source.
- Keep the lamp away from heat sources, direct sunlight, and flammable materials.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not look directly into the LED light source for extended periods, as it may cause eye strain.
- Dispose of the product and its battery responsibly according to local regulations.

## 3. Package Contents

Verify that all items listed below are included in your package:

- 1 x Music Desk Lamp
- 1 x USB Charging Cable
- 1 x Audio Cable
- 1 x User Manual





Figure 3.1: The Music Desk Lamp with its included USB charging cable and audio cable.

## 4. Setup

### 4.1 Initial Charging

Before first use, fully charge the lamp's built-in lithium battery. Connect the small end of the USB charging cable to the charging port on the lamp's base and the larger end to a DC 5V USB power adapter (not included) or a computer USB port.

- A charging indicator light (if present) will typically illuminate during charging and turn off or change color when fully charged.
- Charging time may vary.




Figure 4.1: Detail of the lamp's base, showing the power switch and charging port.

## 4.2 Positioning the Lamp

Place the lamp on a flat, stable surface. The lamp features an adjustable arm, allowing you to position the light source as needed for optimal illumination.





Figure 4.2: The lamp with its adjustable arm extended, demonstrating flexibility.

# 5. Operating Instructions

## 5.1 Powering On/Off and Light Control

1. **Power On:** Locate the power switch on the base of the lamp and slide it to the "ON" position.
2. **Turn Light On/Off:** Gently touch the designated touch control area on the lamp (usually indicated by a symbol or subtle indentation) to turn the light on or off.
3. **Adjust Brightness (Dimmable):** While the light is on, press and hold the touch control area to smoothly adjust the brightness level. Release your finger when the desired brightness is achieved.



Figure 5.1: The desk lamp in operation, providing illumination.

## 5.2 Bluetooth Speaker Operation

1. **Enable Bluetooth:** Ensure the lamp is powered on. The lamp's speaker will automatically enter Bluetooth pairing mode, indicated by an audible prompt or flashing LED.
2. **Pairing:** On your audio device (smartphone, tablet, computer), enable Bluetooth and search for available devices.

Select "Vikye Lamp" (or similar name) from the list to pair.

3. **Playback:** Once paired, you can play audio from your device, and it will output through the lamp's speaker. Control volume and track selection directly from your paired device.

### 5.3 Using the Audio Cable (AUX Mode)

For devices without Bluetooth, or if you prefer a wired connection:

1. Connect one end of the provided audio cable (3.5mm jack) to the AUX input port on the lamp's base.
2. Connect the other end of the audio cable to the headphone jack or audio output port of your audio device.
3. The lamp will automatically switch to AUX mode. Play audio from your device.



Figure 5.2: The lamp integrated into a home office environment, highlighting its functionality.

## 6. Maintenance

### 6.1 Cleaning

To clean the lamp, ensure it is powered off and unplugged. Use a soft, dry, lint-free cloth to wipe down the surfaces. Do

not use abrasive cleaners, solvents, or spray directly onto the lamp.

### 6.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the lamp regularly, even if not in frequent use, to maintain battery health.
- Store the lamp in a cool, dry place if not used for an extended period.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Lamp does not turn on. | Battery is depleted; Power switch is off; Faulty charging cable/adapter. | Charge the lamp; Ensure power switch is ON; Try a different USB cable or power adapter. |
| Light is dim or flickers. | Low battery; Incorrect brightness setting. | Recharge the lamp; Adjust brightness using touch control. |
| Bluetooth not connecting. | Lamp not in pairing mode; Device Bluetooth is off; Too far from lamp. | Ensure lamp is on and in pairing mode; Enable Bluetooth on your device; Move device closer to the lamp. |
| No sound from speaker. | Volume too low on device; Incorrect mode (Bluetooth/AUX); Loose audio cable. | Increase volume on your device; Ensure correct mode is active; Reconnect audio cable firmly. |

## 8. Specifications

| | |
|---|---|
| **Item Type** | Musical Desk Lamp |
| **Material** | Plastic |
| **Product Dimensions (Height)** | Approx. 25 cm (9.84 inches) |
| **Product Dimensions (Base Width)** | Approx. 9 cm (3.54 inches) |
| **Overall Product Dimensions** | 10.63 x 5.91 x 4.33 inches |
| **Item Weight** | 12.3 ounces |
| **Rated Voltage** | DC 5V |
| **Rated Power** | 3.5W |
| **Battery Capacity** | 1000mAh (Built-in Lithium Battery) |
| **Color Rendering Index (CRI)** | ≤70 |
| **Switching Mode** | Touch Control |
| **Manufacturer** | Vikye |
| **Model Number** | Vikyeoyd4geahkz |

## 9. Warranty and Support

Specific warranty information for this product is not provided in this manual. For details regarding warranty coverage, technical support, or service inquiries, please contact the manufacturer, Vikye, directly or refer to the product's packaging or purchase documentation.
You may also visit the official Vikye website for further assistance and updated information.

© 2024 Vikye. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B0D8521K5B**

More documents and user manuals: **https://manuals.plus/**