Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NutriChef NCVEGSLI55RED

NutriChef NCVEGSLI55RED 3-in-1 Rotary Cheese Grater Instruction Manual

Model: NCVEGSLI55RED

Introduction

This manual provides essential instructions for the safe and efficient use of your NutriChef 3-in-1 Rotary Cheese Grater. Please read all instructions carefully before initial use and retain this manual for future reference.
The NutriChef NCVEGSLI55RED is a versatile kitchen tool designed for grating and slicing various foods, including cheese and vegetables. It features a rotary handle, a strong suction base for stability, and three interchangeable drum blades to achieve different textures.

Safety Instructions

- Always keep hands and fingers away from the blades during operation and cleaning. Blades are sharp.
- Ensure the suction base is securely locked to a clean, smooth, and dry countertop surface before use.
- Use the food pusher to guide food into the drum. Never use your fingers.
- Do not attempt to grate extremely hard items that may damage the blades or the unit.
- Keep the appliance out of reach of children.
- Disassemble the unit completely before cleaning.
- Inspect the unit for any damage before each use. Do not use if any parts are broken or damaged.

Product Components

Familiarize yourself with the parts of your NutriChef Rotary Grater:

- **Main Body:** Houses the drum and handle mechanism, with a suction base.
- **Feeding Jar/Hopper:** Where food is inserted.
- **Food Pusher:** Used to press food into the drum.
- **Rotary Handle:** Attaches to the drum for manual rotation.
- **Drum Blades (3 types):** Interchangeable stainless steel blades for different textures.

- **Suction Base Lock:** Lever to secure the unit to the countertop.



Figure 1: Exploded view of the NutriChef Rotary Grater components and dimensions.



Figure 2: Key features and parts of the assembled grater.

Setup Instructions

Follow these steps to assemble your grater before first use:

1. **Secure the Suction Base:** Place the main body of the grater on a clean, smooth, and dry countertop. Push down firmly on the unit and turn the suction base lock clockwise to engage the suction cup, securing the grater to the surface.
2. **Insert the Drum Blade:** Select the desired drum blade (fine, medium, or slicing). Align the blade with the opening in the transparent barrel and slide it in until it clicks into place.
3. **Attach the Handle:** Insert the rotary handle into the side opening of the drum blade. Ensure it is fully engaged and locked.
4. **Prepare for Use:** Place the food pusher into the feeding jar. Your grater is now ready for operation.



Figure 3: Step-by-step assembly guide for the rotary grater.

Operating Instructions

Once assembled, operate your grater as follows:

1. **Prepare Food:** Cut food items into pieces that fit comfortably into the feeding jar.
2. **Insert Food:** Place the prepared food into the feeding jar.
3. **Apply Pressure and Rotate:** Place the food pusher on top of the food. With one hand, apply gentle downward pressure on the food pusher. With the other hand, turn the rotary handle clockwise to grate or slice the food.
4. **Collect Grated Food:** Grated or sliced food will exit through the angled dispenser. Place a bowl or plate underneath to collect it.
5. **Change Blades (if needed):** To change blades, unlock the handle, remove the current drum, and insert a different one following the setup instructions.



Figure 4: The grater in operation, demonstrating grating carrots.



Figure 5: The three interchangeable drum blades and their respective output textures.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your grater.

1. **Disassembly:** After each use, unlock the suction base and disassemble all parts: main body, feeding jar, food pusher, handle, and drum blade.
2. **Washing:** All parts are dishwasher safe. Alternatively, wash by hand using warm, soapy water and a non-abrasive sponge or brush. Pay special attention to the drum blades, using the included cleaning brush to remove any trapped food particles.
3. **Rinsing:** Rinse all parts thoroughly with clean water.
4. **Drying:** Allow all parts to air dry completely before reassembling or storing.
5. **Storage:** Store the clean, dry grater in a safe place.

Troubleshooting

Problem	Possible Cause	Solution
Grater does not suction to countertop.	Countertop is not clean, smooth, or dry; suction lock not engaged.	Ensure countertop is clean and dry. Press down firmly and turn the suction lock clockwise until secure.
Food is not grating effectively or gets stuck.	Food pieces are too large; insufficient pressure on food pusher; incorrect blade for food type; blade is dull or clogged.	Cut food into smaller pieces. Apply consistent downward pressure with the food pusher. Ensure the correct blade is selected. Clean the blade thoroughly.
Handle is difficult to turn.	Too much food in the hopper; food is too hard; blade or mechanism is clogged.	Reduce the amount of food. Do not force the handle. Disassemble and clean all parts. Ensure the handle is properly engaged with the drum.
Unit feels unstable during use.	Suction base is not properly secured.	Re-engage the suction base lock on a clean, dry, and smooth surface.

Specifications

- **Model Number:** NCVEGSLI55RED
- **Brand:** NutriChef
- **Color:** Red
- **Material:** Stainless Steel (blades), Plastic (body)
- **Style:** Handheld Rotary
- **Product Dimensions:** 10"L x 4.48"W x 9.17"H
- **Item Weight:** Approximately 1.01 Pounds
- **Shape:** Round
- **Dishwasher Safe:** Yes
- **UPC:** 842893165110
- **Manufacture Year:** 2024

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D85995QC

More documents and user manuals: **https://manuals.plus/**