realme C61

realme C61 4G User Manual

Model: C61 | Brand: realme

Product Overview

The realme C61 4G is a smartphone designed for everyday use, offering essential features and reliable performance. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device.



Image: Front and rear view of the realme C61 4G smartphone in Marble Black. The front displays a vibrant screen, and the rear highlights the dual camera setup and realme branding.

Setup Guide

1. Unboxing and Initial Inspection

Carefully remove all items from the packaging. Ensure the following components are present:

- realme C61 4G Smartphone
- Adapter
- SIM Ejector Tool (may be included)
- Quick Start Guide (this manual)

2. Inserting SIM Card and microSD Card

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card (for expandable storage) into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully reinsert the tray into the phone until it clicks into place.

3. Charging the Battery

Before first use, fully charge the device. Connect the provided adapter to the phone's USB port and plug it into a power outlet. The battery indicator on the screen will show charging progress.
The realme C61 4G is equipped with a 5000 Milliamp Hours battery.

4. Powering On and Initial Setup

Press and hold the Power button until the realme logo appears. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, Google account sign-in, and security settings.

Operating Instructions

1. Basic Navigation

- **Power Button:** Press to turn the screen on/off. Press and hold to power on/off or restart.
- **Volume Buttons:** Adjust media volume, call volume, or ringtone volume.
- **Touchscreen Gestures:** Tap to select, swipe to scroll, pinch to zoom.

2. Making Calls and Sending Messages

Open the Phone app to dial numbers or select contacts. Open the Messages app to compose and send text messages.

3. Camera Usage

The realme C61 4G features a Rear Camera and a Front Camera. Open the Camera app to capture photos and videos. Select modes such as Photo, Video, Portrait, etc., from the interface.

4. Connectivity

The device supports 4G, Wi-Fi, Wi-Fi Direct, Hotspot, Bluetooth, and GPS. Access these settings via the Quick Settings panel (swipe down from the top of the screen) or the Settings app.
For GPS, the device supports GPS, Beidou, Galileo, GLONASS, QZSS, NavIC, GNSS.

Maintenance and Care

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to Settings > About phone > System update.
- **Battery Care:** Avoid extreme temperatures. Do not let the battery fully drain frequently.
- **Storage Management:** Periodically clear unnecessary files and apps to free up storage space. The device has 64GB of internal storage and supports expandable storage.

Troubleshooting

Problem	Possible Solution
Device not powering on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
Apps crashing or freezing	Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the device.
Poor network signal	Check SIM card insertion. Move to an area with better coverage. Restart the device.
Battery drains quickly	Reduce screen brightness. Close background apps. Disable unnecessary connectivity features (Bluetooth, GPS).

For further assistance, refer to the official realme support website or contact customer service.

Specifications

Model: realme C61 4G

Operating System: Android 14

RAM: 4 GB

Internal Storage: 64 GB

Battery Capacity: 5000 Milliamp Hours (Li-Ion)

Product Dimensions: 16.02 x 7.33 x 0.8 cm

Item Weight: 300 g

Color: Marble Black

Connectivity: 4G, Wi-Fi, Wi-Fi Direct, Hotspot, Bluetooth, GPS (GPS, Beidou, Galileo, GLONASS, QZSS, NavIC, GNSS)

Camera Features: Rear Camera, Front Camera

Audio Jack: USB

Manufacturer: Oppo Mobiles India Private Limited

Country of Origin: India

Warranty and Support

Your realme C61 4G device comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.
For technical support, service requests, or further inquiries, please visit the official realme support website or contact their customer service hotline. Keep your purchase receipt and device serial number handy for faster service.
Manufacturer: Oppo Mobiles India Private Limited, 5th Floor, Tower-B, Building No. 8, DLF Cyber City, Gurugram, Haryana-122002, India.

© 2025 realme. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question