Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM BDCSTV2-ABW

T4TREAM Nightstand with Charging Station Instruction Manual

Model: BDCSTV2-ABW | Brand: T4TREAM

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM Nightstand with Charging Station. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: T4TREAM Nightstand with Charging Station, featuring two drawers, an open shelf, and a top-mounted charging station.

Safety Information

CAUTION:

- This product requires assembly. Use appropriate tools and follow the provided instructions carefully to avoid injury.
- Keep all components within reach but out of the way during assembly.
- Always unplug and remove any electrical components before assembly or disassembly.
- Ensure the nightstand is placed on a stable, level surface to prevent tipping.
- Do not exceed the maximum weight recommendations for the tabletop (150 lbs) and drawers/shelf (30 lbs).

2. Assembly Instructions

The T4TREAM Nightstand is designed for straightforward assembly. An assembly guide and screw pack are included. A screwdriver is the only tool recommended for assembly.

Before You Begin

- Unpack all components and verify against the parts list in the included assembly guide.
- Ensure you have a clear, spacious area for assembly.
- Keep small parts away from children.

Assembly Steps

1. Follow the step-by-step diagrams and instructions provided in the separate Assembly Guide.
2. Attach the main frame components using the designated screws and connectors.
3. Install the drawer slides and assemble the drawers according to the guide.
4. Secure the back panel and any decorative elements.
5. Carefully install the charging station unit into the designated cutout on the tabletop.
6. Once assembled, gently place the nightstand in its desired location.



Image 2.1: Dimensional diagram of the nightstand, illustrating its height, width, and depth.

3. Operating Instructions

Charging Station

Your T4TREAM Nightstand includes an integrated charging station for convenient power access.

- The charging station features **two AC outlets (125V/12A)** and **two USB ports (5V/2A)**.
- To use, plug the nightstand's power cord (4.9-FT) into a grounded 3-prong wall outlet.
- Connect your devices to the AC outlets or USB ports as needed.
- Utilize the cord management hole to keep cables organized and tidy.



Image 3.1: The integrated charging station on the tabletop, showing AC outlets and USB ports in use.

Storage Features

The nightstand offers versatile storage options:

- **Two Drawers:** Provide concealed storage for personal items.

- **Open Compartment:** Ideal for displaying decorative items or storing frequently accessed essentials.
- **18" Tabletop:** Offers ample surface area for lamps, books, and other bedside necessities.



Image 3.2: The nightstand with its two drawers pulled open, showcasing the internal storage capacity.

4. Maintenance

To maintain the appearance and longevity of your T4TREAM Nightstand, follow these simple care instructions:

- **Cleaning:** Wipe the surface with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood.
- **Placement:** Avoid placing the nightstand in direct sunlight or near heat sources to prevent warping or fading.
- **Electrical:** Ensure the charging station is unplugged before cleaning or moving the unit.

5. Troubleshooting

If you encounter any issues with your nightstand, refer to the following common troubleshooting tips:

Assembly Issues

- **Loose Parts:** Re-tighten any screws or connectors that feel loose. Do not overtighten.
- **Misaligned Components:** Disassemble the affected section and re-align according to the assembly guide. Ensure all parts are oriented correctly.

Charging Station Not Working

- **No Power:** Verify that the nightstand's power cord is securely plugged into a functional wall outlet. Test the outlet with another device.
- **Device Not Charging:** Ensure your device's charging cable is properly connected to both the device and the charging station's AC outlet or USB port. Try a different cable or device to isolate the issue.
- **Overload:** Avoid plugging in too many high-power devices simultaneously, which could trip a circuit breaker in your home.

6. Specifications

Feature	Specification
Brand	T4TREAM
Model Name	BDCSTV2-ABW
Product Dimensions	18"D x 18"W x 24"H
Material	Engineered Wood
Color	Antique Brush White
Maximum Weight Recommendation (Tabletop)	150 Pounds
Maximum Weight Recommendation (Shelf/Drawers)	30 Pounds
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Power Cord Length	4.9-FT
Number of Drawers	2
Recommended People for Assembly	1
Tools Recommended for Assembly	Screw Driver
Product Weight	39.7 pounds

7. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official T4TREAM website. Please have your model number (BDCSTV2-ABW) and purchase date available when contacting support.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D86VLG4Q

More documents and user manuals: **https://manuals.plus/**