Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KRPTQJoo RSW-9RC, RSW-12SC, RS-12UD, RSW-12RC, RS-9UB, RSW-30SC

KRPTQJoo Remote Control Instruction Manual

For Fuji RSW-9RC, RSW-12SC, RS-12UD, RSW-12RC, RS-9UB, RSW-30SC Air Conditioners

1. Introduction

This instruction manual provides essential information for the proper setup and operation of your new KRPTQJoo replacement remote control. This remote is designed to be compatible with specific Fuji air conditioner models, including RSW-9RC, RSW-12SC, RS-12UD, RSW-12RC, RS-9UB, and RSW-30SC. Please read this manual thoroughly before use to ensure optimal performance and to understand all functions.

Important Note: This remote control is a replacement unit. Some advanced features or specific button functionalities may vary or require reference to your original air conditioner's user manual. Not all buttons on this remote may be functional with every compatible air conditioner model.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect installation can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery cover. Slide the cover down to open.



Image: Battery compartment with cover removed, showing where to insert AAA batteries and polarity markings. The label indicates 'REMOTE CONTROL UNIT MODEL: AR-JE4 BATTERY: AAA/R03/LR03x2'.

3. Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.



Image: Front view of the remote control, displaying the LCD screen and all functional buttons.

3.1 Button Functions

- **ON/OFF:** Press to turn the air conditioner unit on or off.
- **MODE:** Cycles through available operating modes: **AUTO**, **COOL**, **DRY**, **FAN**.
- **SET TEMP. (Up/Down Arrows):** Adjusts the desired temperature setting. The temperature is displayed on the LCD screen, typically in Celsius.
- **FAN CONTROL:** Selects the fan speed: **AUTO**, **HIGH**, **MED**, **LOW**, **QUIET**.
- **SWING:** Activates or deactivates the automatic louver swing function.
- **SLEEP:** Engages the sleep mode, which often adjusts temperature and fan speed for comfortable sleep.
- **TIMER ON/OFF:** Sets a timer for the unit to turn on or off automatically. Use **SET** and **CANCEL** buttons to configure.
- **START/STOP:** Main button for initiating or stopping the air conditioner's operation.
- **TEST RUN:** Used for diagnostic purposes. Refer to your air conditioner's manual for specific usage.
- **ACL (Reset):** A small recessed button, typically used to reset the remote control to factory settings. Use a thin, pointed object to press.
- **MASTER CONTROL:** This button may have specific functions depending on your AC model, often related to primary control settings.

4. Maintenance

4.1 Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's range decreases or if the display becomes dim. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or malfunction.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the unit.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the air conditioner's receiver.
- **Distance:** Ensure you are within the effective operating range (up to 8 meters).

5.2 Some Buttons Have No Function

- This remote is a universal replacement for several models. It is possible that certain buttons or features on this remote are not supported by your specific air conditioner model.
- Refer to your original air conditioner's user manual to confirm which functions are available for your unit.

6. Specifications

- **Brand:** KRPTQJoo
- **Compatible AC Models:** Fuji RSW-9RC, RSW-12SC, RS-12UD, RSW-12RC, RS-9UB, RSW-30SC
- **Remote Control Unit Model (Internal):** AR-JE4, AR-JE6 (as seen on battery compartment labels)
- **Connectivity Technology:** Infrared (IR)
- **Maximum Range:** 8 Meters
- **Battery Type:** 2 x AAA batteries (not included)
- **Color:** Black (remote body is typically light beige/grey with black buttons)
- **Special Features:** Celsius Only temperature display, Cool & Heat modes (depending on AC unit).

7. Support

If you encounter any problems or have questions regarding the operation or compatibility of this remote control, please

contact the seller directly. The seller aims to respond to inquiries within 12 hours and is committed to assisting you with any issues.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D87MQWG5

More documents and user manuals: **https://manuals.plus/**