ChooChoo ET20001-1TWL-E-S

ChooChoo Farmhouse End Table with Charging Station (Set of 2)

Model: ET20001-1TWL-E-S
Brand: ChooChoo

Important Safety Information

WARNING: This product requires assembly. Follow the included instructions carefully to avoid injury. Do not expose this product to outdoor elements. Keep electrical devices away from water and do not overload outlets. Always unplug charging devices when not in use.

Product Overview

The ChooChoo Farmhouse End Table is a versatile and space-saving furniture piece designed to complement various living spaces. This set of two narrow side tables features an integrated charging station, a hidden drawer, and open shelving for convenient storage and accessibility.

- **Integrated Charging Station:** Includes 2 standard power outlets and 2 USB ports for charging electronic devices.
- **Space-Saving Design:** Narrow profile (12"D x 24"W x 24"H) ideal for small spaces.
- **Storage Solutions:** Features a hidden drawer for small items and two open shelves for books, blankets, or decorative items.
- **Durable Construction:** Made from high-quality engineered wood for stability and longevity.



Image: ChooChoo Farmhouse End Table positioned next to a sofa, highlighting its compact design and integrated charging features.

Package Contents

Please ensure all components are present before beginning assembly.

- End Table Components (Engineered Wood panels)
- Hardware (screws, dowels, cam locks, etc.)
- Power Strip with 2 AC outlets and 2 USB ports
- Assembly Instructions Manual

Assembly Instructions

Assembly is required for this product. Each piece of wood and part is numbered for easy identification. Please follow the detailed step-by-step instructions provided in the separate assembly manual included in your package. Recommended tools for assembly include an Allen Key and a Screwdriver.



Image: Dimensional diagram of the end table, illustrating its compact size and internal measurements.

Operating Instructions

Using the Charging Station

1. Ensure the end table is fully assembled and positioned in its desired location.
2. Plug the power cord from the charging station into a standard wall outlet. The cord length is approximately 6.5 feet.
3. To charge devices, insert USB cables into the available USB ports or plug standard electrical devices into the AC outlets located on the tabletop.
4. Always unplug devices when not in use to conserve energy and for safety.

Utilizing Storage Features

- **Hidden Drawer:** Use the small drawer to store remote controls, charging cables, small snacks, or other personal items to keep the tabletop clutter-free.
- **Open Shelves:** The two open shelves provide additional space for books, magazines, decorative items, or folded

blankets.



Image: End table in use, showcasing a phone charging on the built-in power station, a coffee cup, and books on the shelves.

Maintenance

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Promptly clean any spills to prevent staining, especially on the engineered wood surfaces.
- **Electrical Components:** Ensure the charging station remains dry. Do not attempt to clean the electrical outlets or USB ports with liquids.
- **Stability:** Periodically check all screws and connections to ensure the table remains stable. Tighten if necessary.

Troubleshooting

Charging Station Not Working

- **Check Power Connection:** Ensure the table's power cord is securely plugged into a functional wall outlet.
- **Test Outlet:** Try plugging another device into the wall outlet to confirm it is receiving power.
- **Device Compatibility:** Verify that your device and charging cable are compatible with the USB ports or AC outlets.
- **Overload:** Avoid overloading the charging station with too many high-power devices simultaneously.

Table Instability

- **Check Assembly:** Re-verify that all assembly steps were followed correctly and all hardware is tightened.
- **Level Surface:** Ensure the table is placed on a flat, level surface.

If you encounter issues not covered here, please contact customer service for assistance.

Specifications

Brand	ChooChoo
Model Number	ET20001-1TWL-E-S
Product Dimensions	12"D x 24"W x 24"H
Item Weight	26.78 Pounds
Frame Material	Engineered Wood
Color	Farmhouse White
Number of Drawers	1
Number of Items	2
Required Assembly	Yes
Indoor Outdoor Usage	Indoor
Tools Recommended	Allen Key, Screw Driver



Image: End table serving as a side table next to an armchair, featuring a lamp and a charging phone.

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product or contact ChooChoo customer service directly. Contact details can typically be found on the manufacturer's website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question