JVC XS-N2124PB

JVC Party XS-N2124PB

User Manual

1. Introduction

Thank you for choosing the JVC Party XS-N2124PB speaker. This powerful audio system is designed to deliver an immersive sound experience with vibrant LED lights, making it perfect for parties and gatherings. It offers versatile connectivity options including Bluetooth, AUX, FM, USB, and Micro SD, ensuring you can play your favorite music from various sources. This manual provides detailed instructions on setting up, operating, and maintaining your speaker to ensure optimal performance and longevity.

2. Safety Information

Please read all safety instructions carefully before using the product. Keep this manual for future reference.

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Do not attempt to disassemble or modify the speaker. This will void the warranty and may cause damage or injury.
- Use only the specified charging cable (Type-C) for recharging.
- Keep the speaker away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Ensure proper ventilation around the speaker during operation.
- Clean the speaker only with a dry, soft cloth.

3. Package Contents

Please check the box for the following items:

- JVC Party XS-N2124PB Speaker
- Wired Microphone
- Remote Control
- Type-C Charging Cable

- User Manual

4. Product Overview



Figure 4.1: Front view of the JVC Party XS-N2124PB speaker, showcasing its dual speaker design with integrated multicolour LED light rings. A label indicating "1200W P.M.P.O." (Peak Music Power Output) is visible in the top right corner, highlighting its powerful audio capabilities.



Figure 4.2: Side view of the JVC Party XS-N2124PB speaker, with a prominent red circle highlighting the Type-C Charging Port. This image emphasizes the modern and convenient charging solution for the device.



Figure 4.3: The JVC Party XS-N2124PB speaker displayed alongside icons representing its versatile connectivity options: Bluetooth, AUX, USB, and FM Radio. The included remote control is also shown, indicating convenient wireless operation.

5. Setup

5.1 Initial Charging

Before first use, fully charge the speaker using the provided Type-C charging cable. Connect the Type-C end of the cable to the speaker's charging port and the USB-A end to a compatible USB power adapter (not included) or a computer USB

port. The charging indicator will illuminate during charging and turn off when fully charged.

5.2 Powering On/Off

To power on the speaker, press and hold the Power button located on the control panel until the LED lights illuminate and you hear an audible prompt. To power off, press and hold the Power button again until the lights turn off.

6. Operating Instructions

6.1 Connectivity Modes

The JVC Party XS-N2124PB supports multiple audio input modes. Press the "Mode" button on the control panel or remote control to switch between Bluetooth, AUX, FM Radio, USB, and Micro SD modes.

6.1.1 Bluetooth Pairing

1. Turn on the speaker and switch to Bluetooth mode. The speaker will enter pairing mode, indicated by a flashing Bluetooth indicator.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for "JVC XS-N2124PB" in your device's Bluetooth list and select it to connect.
4. Once connected, the Bluetooth indicator will stop flashing, and you will hear a confirmation sound.

6.1.2 AUX Input

Connect an external audio device (e.g., MP3 player, laptop) to the speaker's AUX input port using a 3.5mm audio cable (not included). The speaker will automatically switch to AUX mode or can be selected via the "Mode" button.

6.1.3 USB and Micro SD Playback

Insert a USB flash drive or a Micro SD card (up to 32GB, formatted to FAT32) into the respective port. The speaker will automatically detect and play audio files (MP3, WAV, WMA formats supported). Use the playback controls to navigate tracks.

6.1.4 FM Radio

Switch to FM Radio mode. The speaker will automatically scan and save available radio stations. Use the "Previous" and "Next" buttons to navigate between saved stations.

6.2 Audio Controls

- **Volume:** Use the Volume knob on the speaker or the Volume +/- buttons on the remote control to adjust the master volume.
- **Play/Pause:** Press the Play/Pause button to pause or resume playback.
- **Previous/Next Track:** Press the Previous or Next buttons to skip to the previous or next track/station.

6.3 LED Light Control

The speaker features dynamic multicolour LED lights. Use the dedicated Light button on the control panel or remote control to cycle through different light modes or to turn the lights on/off.

6.4 Microphone Usage

Connect the wired microphone to the microphone input port on the speaker. Adjust the microphone volume using the dedicated Mic Volume knob (if available) or the main volume control. This feature is ideal for karaoke or public speaking.

6.5 Remote Control Functions

The included remote control provides convenient access to various functions from a distance. Refer to the diagram on the remote control for specific button functions, including mode selection, volume control, track navigation, play/pause, and

LED light control.

7. Maintenance

7.1 Cleaning

Wipe the speaker's exterior with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid spraying liquids directly onto the speaker.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain its health.

7.3 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker when the low battery indicator appears. Do not leave the speaker connected to power for excessively long periods after it is fully charged.

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the Type-C cable.
No sound from speaker.	Volume is too low or muted. Incorrect input mode.	Increase volume. Ensure correct input mode (Bluetooth, AUX, USB, etc.) is selected.
Bluetooth connection fails.	Speaker not in pairing mode. Device too far. Interference.	Ensure speaker is in Bluetooth pairing mode. Move device closer to speaker. Avoid obstacles. Try re-pairing.
Microphone not working.	Microphone not properly connected. Microphone volume too low.	Ensure microphone is fully plugged in. Adjust microphone volume.
USB/Micro SD playback issues.	Unsupported file format. Corrupted files. Incorrect formatting.	Ensure files are MP3/WAV/WMA. Check if USB/Micro SD is formatted to FAT32. Try different files or storage device.

9. Specifications

Feature	Detail
Brand	JVC
Model Number	XS-N2124PB
Product Dimensions (L x W x H)	21.5 x 23.1 x 54.6 cm
Item Weight	3.5 kg
Connectivity Technology	Bluetooth, AUX, USB, FM Radio, Micro SD
Colour	Black

Feature	Detail
Compatible Devices	MP3 Player, Laptop, Tablet, Smartphone
Manufacturer	JVC

10. Warranty and Support

This JVC Party XS-N2124PB speaker comes with a limited manufacturer's warranty. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, or for technical support, please refer to the warranty card included in your package or visit the official JVC website.
For further assistance, you may contact JVC customer support through their official channels. Please have your model number (XS-N2124PB) and purchase details ready when contacting support.

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question