Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Emaks HB-AX11

Emaks 7000mAh Rechargeable Battery (Model HB-AX11) for AOSU Video Doorbell V8 Series User Manual

Comprehensive instructions for installation, charging, and maintenance.

1. Introduction

This manual provides essential information for the safe and effective use of your Emaks 7000mAh rechargeable lithium-ion battery, designed as a replacement for AOSU Video Doorbell V8 series models (V8, V8S, V8P, V8P1AX11, V8S1AX11, V8 pro). This high-capacity battery ensures extended operation and reliable power for your doorbell.

2. Package Contents

Please verify that all items are present in your package:

- 1 x Emaks 7000mAh Rechargeable Battery (Model HB-AX11)
- 1 x USB-C Charging Cable
- 1 x Installation Kit (includes screwdriver and SIM ejector tool)



Image: The Emaks 7000mAh rechargeable battery (blue, cylindrical), a white USB-C charging cable, a small black screwdriver, and a silver SIM ejector tool, representing the complete package contents.

3. Compatibility

This Emaks 7000mAh rechargeable battery (Model HB-AX11) is specifically designed for the following AOSU Video Doorbell V8 series models:

- AOSU Video Doorbell V8
- AOSU Video Doorbell V8S
- AOSU Video Doorbell V8P
- AOSU Video Doorbell V8P1AX11
- AOSU Video Doorbell V8S1AX11

- AOSU Video Doorbell V8 pro



Image: A visual representation of the HB-AX11 battery alongside illustrations of the AOSU Video Doorbell Ultra V8S and Video Doorbell Pro V8P, indicating broad compatibility within the V8 series.

4. Safety Information

WARNING: To prevent injury or damage, please observe the following safety precautions:

- **DO NOT DISASSEMBLE** the battery. Disassembly can lead to electric shock, fire, or explosion.
- **DO NOT DISPOSE OF IN FIRE.** Batteries can explode when exposed to high temperatures.
- **DO NOT STORE IN TEMPERATURES OVER 60°C (140°F).** High temperatures can degrade battery performance and pose a safety risk.
- Avoid short-circuiting the battery terminals.
- Keep the battery away from water and moisture.

- If the battery appears damaged, swollen, or leaking, discontinue use immediately and dispose of it properly according to local regulations.
- Keep out of reach of children.

5. Setup and Installation

Follow these steps to replace the battery in your AOSU Video Doorbell V8 series:

1. Locate the battery compartment on your AOSU Video Doorbell. This is typically on the back or bottom of the device.
2. Use the included SIM ejector tool or a similar thin tool to gently press the release pin or tab to open the battery compartment.
3. Carefully remove the old battery from the compartment.
4. Disconnect the old battery's connector from the doorbell's internal port.
5. Connect the new Emaks HB-AX11 battery to the doorbell's internal port, ensuring the connector is securely seated.
6. Insert the new battery into the compartment. Ensure it fits snugly without forcing.
7. Close the battery compartment cover until it clicks into place.
8. Power on your doorbell and check for proper operation.



Image: A four-panel image illustrating the battery replacement process. Panel 1 shows using a tool to open the doorbell's battery compartment. Panel 2 shows using a screwdriver to remove a screw. Panel 3 shows inserting the new battery. Panel 4 shows the battery securely in place before closing the cover.

Your browser does not support the video tag.

Video: An official Emaks video demonstrating the unboxing of the battery and tools, followed by a step-by-step guide on how to remove the old battery from an AOSU Video Doorbell V8 and install the new Emaks HB-AX11 replacement battery.

6. Charging Instructions

To charge your Emaks HB-AX11 battery:

1. Connect the included USB-C charging cable to the battery's charging port.
2. Connect the other end of the USB-C cable to a compatible 5V USB power source (e.g., computer USB port, wall adapter, power bank).

3. The battery features an LED indicator to show charging status. Refer to your doorbell's manual or the battery's label for specific LED behavior (e.g., red for charging, green for fully charged).
4. Once fully charged, disconnect the battery from the power source.

Your browser does not support the video tag.

Video: An official Emaks video demonstrating the unboxing of the battery and tools, followed by a step-by-step guide on how to remove the old battery from an AOSU Video Doorbell V8 and install the new Emaks HB-AX11 replacement battery. The video also shows connecting the USB-C cable for charging.

7. Specifications

Feature	Detail
Brand	Emaks
Model Number (Battery)	HB-AX11
Battery Capacity	7000 Milliamp Hours (mAh)
Battery Cell Composition	Lithium Ion
Voltage	3.7V
Item Weight	4.9 ounces
Package Dimensions	4.29 x 3.19 x 1.38 inches
Recommended Uses	AOSU Video Doorbell V8 Series

8. Troubleshooting

If you encounter issues with your Emaks replacement battery, consider the following:

- **Battery not charging:**
  - Ensure the USB-C cable is securely connected to both the battery and the power source.
  - Try a different USB-C cable or power adapter.
  - Verify the power source is active and providing 5V output.
- **Doorbell not powering on after battery installation:**
  - Double-check that the battery connector is fully and correctly inserted into the doorbell's port.
  - Ensure the battery is fully charged.
  - Confirm the battery compartment is properly closed.
- **Shorter than expected battery life:**
  - Ensure the battery has been fully charged before first use.
  - Environmental factors (extreme cold/heat) can affect battery performance.

- High usage of doorbell features (e.g., frequent motion detection, live view) can deplete the battery faster.

9. Warranty and Support

Emaks is committed to providing exceptional customer support. If you have any questions, concerns, or require assistance with your product, please contact our customer service team. Your satisfaction is our utmost priority. For support, please refer to the contact information provided with your purchase or visit the official Emaks website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8J61YMY

More documents and user manuals: **https://manuals.plus/**