CORE 40363

CORE 13 FT x 13 FT Instant Pop Up Canopy Tent Instruction Manual

Brand: CORE | Model: 40363

Overview Safety Information Setup Operating Maintenance Troubleshooting Specifications Warranty Support

Product Overview

The CORE 13 FT x 13 FT Instant Pop Up Canopy Tent is designed for quick and easy setup, providing a portable shelter for various outdoor activities. Its robust design offers shade and protection, making it suitable for camping, beach trips, picnics, backyard gatherings, BBQs, tailgates, patios, and parties.

- **Instant Pop Up Technology:** Features a Center Push design and an extended handle for setup in approximately 2 minutes.
- **Versatile Height Adjustment:** Oversized, pinch-free buttons allow for 15 height options that automatically lock into place.
- **Sun Protection:** The 150D silver-coated canopy top is made from 50+ UV-coated fabric, offering protection against harmful UV rays.
- **Versatile Use:** Equipped with adjustable all-terrain feet to ensure stability on various surfaces.
- **Increased Ventilation:** Dual canopy vents enhance air circulation for a cooler and more comfortable environment.



Image: The CORE 13x13 Instant Pop Up Canopy Tent providing shade for a family in a grassy park setting.

Safety Information

Please read and understand all safety information before setting up or using your canopy tent.

- Always set up the canopy on a stable, flat surface.
- Keep the canopy away from heat sources and open flames.
- Use the provided stakes and guylines to secure the canopy in windy conditions.
- Do not leave the canopy unattended in high winds.
- The canopy provides sun protection but does not eliminate all UV rays; use sunscreen and protective clothing when using the canopy.

Setup Instructions

1. **Unpack the Canopy:** Remove the canopy frame and fabric from the wheeled carry bag. Lay the folded frame flat on

the ground.

2. **Extend the Frame:** With a person at each corner (or two people on opposite sides), gently pull the frame outwards, partially extending it.
3. **Engage Center Push Technology:** Stand under the canopy and locate the center push hub. Push upwards on the hub until the canopy top fully extends and locks into place. This should take approximately 2 minutes.



Image: Detailed view of the canopy's center push technology, height adjustment, all-terrain feet, and ventilation system.

4. **Adjust Leg Height:** Press the oversized, pinch-free buttons on each leg and extend the legs to your desired height. Ensure all four legs are locked at the same height for stability. There are 15 height options available.



Image: A hand demonstrating the use of the pinch-free height adjustment button on a canopy leg.

5. **Secure the Canopy:** Use the provided stakes and guylines to anchor the canopy to the ground, especially in breezy conditions. Attach guylines to the canopy corners and stake them firmly into the ground at an angle.



Image: A close-up of a canopy corner showing the attachment point for a guyline.



Image: The included stakes neatly stored in a mesh pocket within the carry bag.

6. **Adjust All-Terrain Feet:** The canopy features self-adjusting all-terrain feet for stability on uneven surfaces. Ensure they are properly seated on the ground.



Image: A close-up view of the self-adjusting all-terrain foot at the base of a canopy leg.

Operating Instructions

Height Adjustment

To adjust the height of the canopy, locate the pinch-free buttons on each leg. Press the button and slide the leg to the desired height setting. Release the button to lock the leg in place. Ensure all four legs are set to the same height for optimal stability and appearance. The canopy offers 15 distinct height adjustments.

Ventilation

The canopy is equipped with dual vents at the top to facilitate air circulation. These vents help to reduce heat buildup under the canopy, providing a cooler and more comfortable experience. No specific action is required to operate the vents as they are integrated into the canopy design.

Maintenance

- **Cleaning the Canopy Fabric:** To clean the canopy fabric, use a mild soap and water solution. Gently scrub with a soft brush or cloth. Rinse thoroughly with clean water and allow to air dry completely before packing away. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** Wipe down the metal frame with a damp cloth to remove dirt and debris. Ensure the frame is dry before storage to prevent rust. Periodically check all moving parts and connections for wear and tear.
- **Storage:** Always ensure the canopy fabric and frame are completely dry before folding and storing in the wheeled carry bag. Store the canopy in a cool, dry place away from direct sunlight to prolong its lifespan.



Image: The CORE canopy tent compactly stored in its wheeled carry bag for easy transport and storage.

Troubleshooting

Problem	Possible Cause	Solution
Canopy difficult to open/close	Frame not properly aligned or lubricated.	Ensure the frame is on a flat surface. Gently wiggle the frame while extending/retracting. Apply silicone spray to moving joints if necessary.

Problem	Possible Cause	Solution
Legs not locking into place	Button not fully depressed or debris in the locking mechanism.	Press the height adjustment button firmly. Check for any obstructions in the leg holes or button mechanism.
Canopy unstable in wind	Not properly secured with stakes and guylines.	Always use all provided stakes and guylines. For added stability in moderate winds, consider using sandbags or weights on the legs. Never leave unattended in high winds.
Water pooling on canopy top	Canopy not fully extended or set up on uneven ground.	Ensure the center push mechanism is fully engaged and locked. Verify that the canopy is set up on a level surface and all legs are at the same height.

Product Specifications



Image: Visual representation of the canopy's dimensions (13'x13' footprint, 114" height) and features like 169 sq ft shade coverage and UV protection.

Feature	Detail
Brand	CORE

Feature	Detail
Model Number	40363
Material	Polyester (Canopy), Alloy Steel (Frame)
Color	Cool Dark Gray
Item Weight	46 pounds
Dimensions (L x W x H)	156"L x 156"W x 114"H (13' x 13' x 9'6")
Shade Coverage	169 Square Feet
UV Protection	Yes (50+ UV-coated fabric)
Water Resistance Level	Water Resistant
Number of Guylines	4
UPC	810007489650

Warranty Information

Specific warranty details for the CORE 13 FT x 13 FT Instant Pop Up Canopy Tent are typically provided with the product packaging or can be found on the manufacturer's official website. Please refer to the documentation included with your purchase for the most accurate and up-to-date warranty terms and conditions. Keep your proof of purchase for any warranty claims.

Customer Support

For further assistance, replacement parts, or inquiries not covered in this manual, please contact CORE customer support. You can typically find contact information (phone number, email, or support portal) on the CORE brand website or through the retailer where you purchased the product.
When contacting support, please have your product model number (40363) and proof of purchase readily available.

© 2026 CORE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question