COLAMY DY-6870-Beige1-F-2Sets

COLAMY Wooden Dining Chairs - Instruction Manual

Model: DY-6870-Beige1-F-2Sets

1. Introduction

This manual provides detailed instructions for the assembly, use, and maintenance of your COLAMY Wooden Dining Chairs. Please read this document thoroughly before beginning assembly or use to ensure proper function and longevity of your product.



Image: COLAMY Wooden Dining Chairs in a dining room setting.

2. Important Safety Information

To prevent injury or damage to the product, please observe the following safety guidelines:

- Do not use these chairs outdoors. They are designed for indoor use only.
- Adjust the foot nails (levelers) on the chair legs to prevent floor damage and ensure stability.
- Do not exceed the maximum weight capacity of**250 pounds** per chair.
- Keep all small parts and packaging materials away from children during assembly.
- Ensure all screws and fasteners are securely tightened before each use. Periodically check and re-tighten as needed.
- Avoid standing on the chairs.

3. Package Contents

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, contact COLAMY customer service.

- 4 x Dining Chair Bodies (Upholstered Seat and Backrest)
- 1 x Hardware Pack (Includes screws, washers, and Allen wrench)
- 1 x User Manual (This document)

Note:

Your order of 4 chairs will be shipped in 2 separate packages, each containing 2 chairs. These packages may arrive on different days. Please allow up to 7 business days for all packages to arrive.



Image: Illustration of chairs being shipped in two separate boxes.

4. Assembly Instructions

Assembly is required for these dining chairs. The process is designed to be straightforward, with an estimated assembly time of 10-15 minutes per chair. No professional help is typically needed.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Separate the chair legs, seat frame, and backrest. Refer to the included hardware pack for screws and the Allen wrench.
3. **Attach Legs to Seat Frame:** Align the chair legs with the designated attachment points on the underside of the seat frame. Insert the appropriate screws and tighten them using the provided Allen wrench. Do not fully tighten all screws until all parts are loosely assembled.
4. **Secure Backrest:** Attach the backrest to the seat frame using the remaining screws. Ensure the backrest is properly aligned and secure.
5. **Final Tightening:** Once all components are in place, gradually tighten all screws firmly. Avoid over-tightening.
6. **Adjust Stability:** Place the assembled chair on a flat surface. If the chair wobbles, adjust the foot pegs at the bottom of the legs until the chair is stable.



Image: Simplified assembly diagram.

5. Operating and Intended Use

The COLAMY Wooden Dining Chairs are designed for versatile indoor use, providing comfortable and ergonomic seating. Their modern design allows them to complement various interior styles.

- **Placement:** These chairs are suitable for use in dining rooms, kitchens, living rooms, offices, bistros, cafes, and other indoor spaces.
- **Ergonomics:** The upholstered back and cushion are designed to promote good posture and reduce discomfort during extended periods of sitting.
- **Versatility:** Ideal for dining, reading, relaxing, gaming, or as additional seating in various rooms.



Image: Detailed features of the chair's construction and ergonomic design.

6. Maintenance and Care

Proper care will help maintain the appearance and extend the lifespan of your dining chairs.

- **General Cleaning:** Regularly dust the wooden frame with a soft, dry cloth.
- **Upholstery Care:** For fabric upholstery, spot clean only. Use a mild detergent solution and a damp cloth to gently blot spills or stains. Avoid rubbing vigorously.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or furniture polish on either the wood or fabric, as these can cause damage.
- **Protection:** Protect the chairs from direct sunlight, excessive heat, and moisture, which can cause fading, warping, or damage to the materials.
- **Floor Protection:** Ensure the foot pegs are always in place to prevent scratches on your flooring.

7. Troubleshooting

If you encounter any issues with your COLAMY dining chairs, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair wobbles or is unstable.	Loose screws or uneven floor.	Check and tighten all assembly screws. Adjust the foot pegs on the bottom of the chair legs to compensate for uneven surfaces.
Fabric upholstery appears dirty or stained.	Spills or general use.	Spot clean immediately with a mild detergent and a damp cloth. Do not machine wash or use harsh chemicals.
Damage to wooden frame.	Impact or excessive force.	Avoid dropping or hitting the chairs. For minor scratches, wood repair kits may be used. For significant damage, contact customer support.

If the problem persists or if you require replacement parts, please contact COLAMY customer service.

8. Product Specifications

Detailed specifications for the COLAMY Wooden Dining Chairs:

Feature	Detail
Brand	COLAMY
Model Name	DY-6870-Beige1-F-2Sets
Color	Beige
Product Dimensions (D x W x H)	20.67"D x 22.24"W x 31.89"H
Seat Height	19.29 Inches
Seat Depth	17.13 Inches
Chair Backrest Width	22.05 Inches
Maximum Weight Recommendation	250 Pounds
Materials	Rubberwood (Frame), Foam, Sponge (Fill Material), Fabric (Upholstery)
Finish Type	Unfinished Wood
Assembly Required	Yes
Unit Count	4.0 Count

Feature	Detail
Indoor/Outdoor Usage	Indoor Only



Image: Detailed product dimensions.

9. Warranty and Support

For product support, replacement parts, or warranty inquiries, please contact COLAMY customer service. Refer to your purchase documentation for specific warranty terms and contact information.

You can also visit the official COLAMY Store for additional product information and support resources.

© 2025 COLAMY. All rights reserved.