Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DURLK DURLK-TWO_WAY_RADIO

DURLK Rechargeable Walkie Talkies (Model DURLK-TWO_WAY_RADIO) User Manual

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your DURLK Rechargeable Walkie Talkies. Please read this manual thoroughly before using the product to ensure proper function and safety.



Image 1.1: Four DURLK walkie talkies in various colors, along with their charging accessories.

2. What's in the Box

Verify that all items listed below are included in your package:

- 4 x 1800mAh Rechargeable Walkie Talkies
- 2 x USB-C 2-IN-1 Charging Cables
- 1 x Charging Adapter
- Belt Clips (pre-attached)
- User Manual (this document)



Image 2.1: Visual representation of the package contents.

3. Product Overview

Familiarize yourself with the components and controls of your DURLK walkie talkie:



Image 3.1: Front and side view of the walkie talkie with labeled components.

- **Antenna:** For transmitting and receiving signals.
- **Volume/Power Knob:** Rotate to turn the unit on/off and adjust volume.
- **LED Flashlight:** Provides illumination.
- **LCD Display:** Shows channel, battery level, and other settings.
- **Menu Button:** Accesses settings and features.
- **Call Tone Button:** Sends an audible alert to other radios.
- **Microphone:** For speaking.
- **Speaker:** For listening.
- **PTT (Push-to-Talk) Button:** Press and hold to transmit, release to listen.
- **Earpiece Port:** For connecting an external earpiece (not included).
- **Flashlight Button:** Activates the LED flashlight.
- **Scan/Monitor Button:** Initiates channel scanning or monitors current channel.
- **USB-C Charging Port:** For recharging the internal battery.

4. Setup

4.1 Initial Charging

Before first use, fully charge all walkie talkies. The built-in 1800mAh lithium battery provides up to 72 hours of standby time after a full charge.

1. Connect the provided USB-C 2-in-1 charging cables to the USB-C charging port on each walkie talkie.
2. Plug the charging cables into the included charging adapter.
3. Connect the adapter to a standard wall outlet.
4. The charging indicator on the walkie talkie will show charging status. A full charge typically takes 3-4 hours.



Image 4.1: Multiple walkie talkies charging simultaneously.

5. Operating Instructions

5.1 Power On/Off and Volume

Rotate the Volume/Power knob clockwise to turn the walkie talkie on. Continue rotating to increase the volume. Rotate counter-clockwise to decrease volume and turn off the unit.

5.2 Channel Selection

Your walkie talkies operate on 22 FRS (Family Radio Service) channels with 121 privacy codes, offering 2,662 secure combinations. To communicate, all radios must be set to the same channel and privacy code.

1. Press the **MENU** button. The channel number will flash.

2. Use the **UP**/**DOWN** arrow buttons to select your desired channel (1-22).
3. Press **MENU** again. The privacy code will flash.
4. Use the **UP**/**DOWN** arrow buttons to select your desired privacy code (0-121). Code 0 means no privacy code.
5. Press **MENU** or wait a few seconds for the setting to be saved.

5.3 Push-to-Talk (PTT)

To transmit, press and hold the **PTT** button located on the side of the walkie talkie. Speak clearly into the microphone. Release the **PTT** button to listen for a response.

5.4 VOX (Voice-Activated Transmission)

VOX mode allows hands-free communication. When activated, the radio transmits automatically when it detects your voice.

1. Press the **MENU** button multiple times until the VOX icon appears on the LCD display.
2. Use the **UP**/**DOWN** arrow buttons to select the VOX sensitivity level (e.g., 1-3, with 1 being most sensitive).
3. Press **MENU** or wait for the setting to be saved.

5.5 NOAA Weather Alert

The walkie talkies feature 10 NOAA weather channels to provide real-time weather updates and alerts for severe conditions.

1. Press the dedicated **NOAA** button (often combined with Scan/Monitor) to access weather channels.
2. Use the **UP**/**DOWN** arrow buttons to cycle through the 10 NOAA channels.
3. The radio will automatically scan for active weather alerts on the selected channel.



Image 5.1: Utilizing the NOAA Weather Alert feature for outdoor safety.

5.6 LED Flashlight

To activate the built-in LED flashlight, press the dedicated**Flashlight Button**. Press it again to turn off the flashlight.



Image 5.2: Walkie talkie with activated LED flashlight.

5.7 Keypad Lock

To prevent accidental changes to settings, you can lock the keypad. Press and hold the **MENU** button until the lock icon appears on the display. Repeat the action to unlock.

5.8 Range Information

These walkie talkies typically achieve a range of 0.5-1.5 miles in urban or obstructed conditions and up to 3 miles in ideal, open conditions. Actual range is dependent on terrain, weather, and electromagnetic interference.



Image 5.3: Illustrative use of walkie talkies for long-range communication.

6. Maintenance

6.1 Cleaning

Wipe the walkie talkie with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the USB-C port cover is securely closed to prevent dust and moisture ingress.

6.2 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the units regularly, especially if they will be stored for extended periods. Store in a cool, dry place.

6.3 Storage

When not in use, store the walkie talkies in a dry environment away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the walkie talkie fully.
Cannot communicate with other radios	Different channels or privacy codes.	Ensure all radios are on the same channel and privacy code.
Poor sound quality or static	Out of range, obstacles, or low battery.	Move closer to the other radio, avoid obstructions, or recharge the battery.
VOX not activating	VOX sensitivity too low.	Adjust VOX sensitivity to a higher level in the menu.
Keypad unresponsive	Keypad is locked.	Unlock the keypad by pressing and holding the MENU button.

8. Specifications

- **Model Number:** DURLK-TWO_WAY_RADIO
- **Item Weight:** 1.28 pounds (for the set of 4)
- **Package Dimensions:** 6.77 x 4.69 x 2.83 inches
- **Battery:** 4 x 1800mAh Lithium Ion (included, built-in)
- **Number of Channels:** 22 FRS Channels
- **Privacy Codes:** 121
- **Frequency Range:** 462.5500-462.7250MHz, 462.5625-462.7125 MHz, 467.5625-467.7125MHz
- **Maximum Talking Range:** Up to 3 Miles (in ideal conditions)
- **Voltage:** 3.7 Volts
- **Special Features:** Digital Display, Emergency LED Flashlight, NOAA Weather Scan & Alert, Rechargeable, Voice Operated Exchange (VOX)
- **Water Resistance Level:** Not Water Resistant

9. Warranty and Support

9.1 Warranty Information

Your DURLK walkie talkies come with a 365-day warranty from the date of purchase, covering manufacturing defects. This warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your DURLK walkie talkies, please contact DURLK customer support through the retailer's platform or the official DURLK website. Please have your model number and

purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8Q4794B

More documents and user manuals: **https://manuals.plus/**