Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Loakdsa RG10A1(B2S)/BGEF, RG10A(B2S)/BGEFU1, RG10L1(2HS)/BGEF, RG10L1(C2HS)/BGEF, RG10A(B2S)/BGEF

User Manual

New Remote Control for Midea AC Air Conditioner

Model: RG10A1(B2S)/BGEF, RG10A(B2S)/BGEFU1, RG10L1(2HS)/BGEF, RG10L1(C2HS)/BGEF, RG10A(B2S)/BGEF
Brand: Loakdsa

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your new Loakdsa remote control for Midea AC Air Conditioners. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

Product Overview



Figure 1: Front View of the Remote Control. This image displays the front of the remote control, featuring the LCD screen at the top, a circular navigation pad with 'SET' and 'OK' buttons, and various function buttons such as Power, Mode, iEco/Gear, Fan, Swing, Human Sensor, Boost, LED, and Clean.



Figure 2: Back View of the Remote Control. This image shows the back of the remote control, including the battery compartment cover and a label with product specifications: "TYPE: RG10A(B2S)/BGEF", "Rated voltage: 3VDC", and a note to remove batteries when not in use for a long time.

Setup

The remote control is designed for immediate use with compatible Midea AC Air Conditioners. No programming or complex setup is required.

1. **Battery Installation:**

   Locate the battery compartment on the back of the remote control. Slide the cover down to open. Insert two new AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment. Close the battery cover securely.

   Note: *AAA batteries are required and are not included with the remote control.*

2. **First Use:**

After installing the batteries, the remote control is ready for operation. Point the remote control directly towards the signal receiving window of your Midea AC Air Conditioner.

Operating Instructions

Familiarize yourself with the buttons on your remote control to effectively manage your air conditioner's functions.

- **Power Button ( ):** Press to turn the air conditioner On or Off.
- **Mode Button:** Cycles through operating modes such as Cool, Dry, Fan, Heat (if applicable), and Auto.
- **Temperature Adjustment (▲ / ▼):** Use the Up and Down arrows within the circular pad to increase or decrease the set temperature.
- **OK Button:** Confirms selections or settings.
- **SET Button:** Used for advanced settings or timer functions. Refer to your AC unit's manual for specific uses.
- **iEco/Gear Button:** Activates energy-saving modes or adjusts fan gear settings.
- **Fan Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button:** Controls the vertical or horizontal swing of the air deflector.
- **Human Sensor Button:** Activates or deactivates the human presence detection feature (if supported by AC unit).
- **Boost Button:** Initiates a rapid cooling or heating function for quick temperature changes.
- **LED Button:** Toggles the display light on the indoor unit.
- **Clean Button:** Activates the self-cleaning function of the indoor unit (if supported).

Note: *Not all functions may be available on every Midea AC model. Refer to your specific air conditioner's user manual for detailed information on compatible features.*

Maintenance

Proper care will extend the life of your remote control.

- **Battery Replacement:** Replace batteries when the remote's range decreases or the display becomes dim. Always replace both batteries at the same time with new ones.
- **Long-Term Storage:** If the remote control will not be used for an extended period (e.g., several months), remove the batteries to prevent leakage and potential damage to the remote.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the surface or internal components.
- **Avoid Exposure:** Keep the remote control away from direct sunlight, high temperatures, and high humidity.

Troubleshooting

If you encounter issues with your remote control, try the following steps:

- **Remote Not Responding:**
  - Ensure the remote is pointed directly at the AC unit's receiver.
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote and the AC unit.
- **Limited Range:**
  - Replace the batteries.
  - Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the infrared signal.
- **Specific Functions Not Working:**
  - Verify that your Midea AC model supports the specific function you are trying to use. Refer to your AC unit's manual.

If the problem persists after trying these steps, please refer to the "Support" section for further assistance.

Specifications

Attribute	Detail
Brand	Loakdsa
Compatible Models	Midea RG10A1(B2S)/BGEF, RG10A(B2S)/BGEFU1, RG10L1(2HS)/BGEF, RG10L1(C2HS)/BGEF, RG10A(B2S)/BGEF
Connectivity Technology	Infrared
Compatible Devices	Air Conditioner
Max Number of Supported Devices	1
Special Feature	No Programming Required
Batteries Required	AAA batteries (2)
Rated Voltage	3VDC

Warranty Information

Specific warranty details for this product are not provided in this manual. Please refer to the product packaging or contact the seller directly for information regarding warranty coverage and terms.

Support

For any questions, concerns, or issues not covered in this manual, please contact the seller or manufacturer directly. They are committed to customer satisfaction and will assist you with your inquiries.

Seller Contact: Please refer to your purchase platform or order details for direct contact information for the seller, A-HONGZHOU98.

Typically, inquiries are responded to within 24 hours.

© 2024 Loakdsa. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8RLQPHP

More documents and user manuals: **https://manuals.plus/**