innioasis R1

Innioasis R1 Digital Voice Recorder User Manual

Model: R1

Brand: innioasis

1. Introduction

Thank you for choosing the Innioasis R1 Digital Voice Recorder. This device is designed for high-quality audio capture with advanced features like AI intelligent transcription and Bluetooth connectivity. This manual provides detailed instructions to help you get the most out of your new voice recorder.

2. What's in the Box

- Innioasis R1 Digital Voice Recorder
- Type-C to Type-A Charging Cable

3. Product Overview

The Innioasis R1 features a 3.69-inch high-definition touchscreen for intuitive control, complemented by traditional physical buttons for user preference. It is equipped with dual microphones (high and low sensitivity) and a professional recording IC for superior audio quality.



Figure 3.1: Front and side view of the Innioasis R1, highlighting the touchscreen and physical controls.

3.1. Controls and Ports

- **Touchscreen Display:** 3.69-inch HD display for navigation and settings.
- **Physical Buttons:** REC, Play/Pause, Next, Prev, T-Mark, Vol+, Vol-.
- **Power/Lock Switch:** Located on the side for turning the device on/off and locking the screen.
- **USB Type-C Port:** For charging and data transfer.
- **SD Card Slot:** Supports external storage up to 1TB.
- **3.5mm Headphone Jack:** For audio playback.
- **Dual Microphones:** High-sensitivity and low-sensitivity microphones for optimal recording.

4. Setup

4.1. Initial Charging

Before first use, fully charge the device. Connect the provided Type-C to Type-A charging cable to the recorder's

USB-C port and a compatible 5V=1A power source (e.g., laptop USB port, smartphone charger). The device features an 1100mAh lithium battery for long battery life.



Figure 4.1: The Innioasis R1 features an 1100mAh battery for extended use.

4.2. Inserting an SD Card

The R1 uses an external SD card as its primary storage medium. To insert an SD card, locate the SD card slot on the side of the device. Gently push the SD card into the slot until it clicks into place. The device supports expandable external storage up to 1TB.

4.3. Powering On/Off

To power on the device, slide the 'Power/Lock' switch to the 'Power' position. To power off, slide the switch back to the 'Lock' position or hold it for a few seconds until the device shuts down.

5. Operating Instructions

5.1. Basic Recording

1. **Start Recording:** Hold down the 'REC' button on the side for 2 seconds. The screen will show the recording

interface, and a red indicator light will illuminate.

2. **Pause/Resume Recording:** Tap the 'Pause' button on the touchscreen during recording. Tap again to resume.
3. **Save Recording:** Tap the 'Save' button on the touchscreen. You will be prompted to name the file and choose a save location (e.g., SD card).

5.2. Multiple Recording Modes

The R1 offers various recording modes optimized for different scenarios:



Figure 5.1: Select from various recording modes to optimize audio quality for your environment.

- **General:** Standard recording mode.
- **Interview:** Optimized for two-way conversations.
- **Meeting:** Best for capturing discussions in a group setting.
- **Lecture:** Ideal for clear voice capture from a distance.
- **Pocket:** Designed for discreet recording while in a pocket or bag.
- **Scheduled Recording:** Set a specific time for the recorder to start and stop recording automatically.

- **Automatic Recording:** Voice-activated recording (VOR) to save storage space by only recording when sound is detected.

5.3. Playback and File Management

Access your recordings through the 'File Browser' option on the main menu. Tap on a file to play it back. You can adjust the volume using the physical Vol+/- buttons.

5.4. Marking Recordings (T-Mark)

During recording or playback, press the 'T-Mark' button to add a timestamp marker. This helps you quickly navigate to important sections of your audio files.

5.5. Searching Recordings

The device allows you to search for specific recordings using keywords. Navigate to the search function within the file browser and use the on-screen keyboard to enter your search terms.

5.6. Offline Speech-to-Text (STT)

The R1 features a built-in offline intelligent speech-to-text function. This allows for real-time transcription display during recording. You can also export the STT document for further use, maximizing work efficiency.



Figure 5.2: Real-time transcription is displayed on the screen during recording.

5.7. Optional Automatic Backup

To prevent loss of important files due to storage media failure, the R1 offers an optional automatic backup feature. It is recommended to enable this for critical recordings.



Figure 5.3: The automatic backup feature helps protect your valuable recordings.

5.8. Password Protection

The R1 handheld recorder offers robust 6-digit password protection. This feature helps safeguard your personal privacy and intellectual property by preventing unauthorized access to the device.



Figure 5.4: Set a 6-digit password to secure your device and recordings.

6. Maintenance

6.1. Battery Care

To prolong the life of the built-in lithium battery, avoid fully discharging it frequently. Charge the device regularly, even if not in constant use. Store the device in a cool, dry place when not in use for extended periods.

6.2. Storage Management

Regularly transfer important recordings to a computer or external storage device to free up space on the SD card and prevent data loss. Organize your files into folders for easier access.

6.3. Cleaning

Use a soft, dry, lint-free cloth to clean the device's screen and body. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.

7. Troubleshooting

7.1. Common Issues and Solutions

- **Device not powering on:** Ensure the battery is charged. Connect the charger and try again.
- **Poor recording quality:** Check the selected recording mode. Ensure microphones are not obstructed. Reduce background noise if possible.
- **Cannot save recordings:** Check if the SD card has sufficient free space. Ensure the SD card is properly inserted.
- **Touchscreen unresponsive:** Try restarting the device. If the issue persists, ensure the screen is clean and dry.
- **Transcription errors:** Ensure clear audio input. Speak clearly and at a moderate pace.

If you encounter issues not listed here or require further assistance, please contact Innioasis customer support.

8. Specifications

Feature	Detail
Model Number	R1
Product Dimensions	4.33 x 1.26 x 0.55 inches (approx. 4.3"D x 1.3"W x 0.6"H)
Item Weight	3.07 ounces (approx. 87 Grams)
Memory Storage Capacity	136 GB (Expandable up to 1TB via SD card)
Battery Type	1 Lithium Ion battery (included)
Battery Capacity	1100mAh
Charging Input	5V=1A (USB Type C)
Microphone Form Factor	Built-In
Headphones Jack	3.5 millimeters
Compatible Devices	Laptop
Country of Origin	China

9. Warranty and Support

For warranty information and customer support, please visit the official Innioasis store or contact their customer service directly. You can find more information and support resources at the Innioasis Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question