Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OCEAN WFO1061WLS

OCEAN Front Load Washing Machine User Manual

Model: WFO1061WLS

Safety Setup Operation Maintenance Troubleshooting Specifications

1. Introduction

Thank you for choosing the OCEAN WFO1061WLS Front Load Washing Machine. This manual provides essential information for the safe and efficient use of your appliance. Please read it thoroughly before installation and operation, and keep it for future reference.
This washing machine is designed for residential use, offering a 6 kg capacity and a maximum spin speed of 1000 RPM, with 15 wash programs to suit various laundry needs.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the washing machine is properly grounded.
- Do not operate the machine if the power cord is damaged.
- Keep children and pets away from the appliance during operation.
- Do not wash items that have been cleaned, washed, soaked, or spotted with combustible or explosive substances.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not open the detergent drawer or door during a wash cycle, especially when the water level is high or temperature is hot.

3. Installation and Setup

3.1 Unpacking

Carefully remove all packaging materials. Remove the transport bolts located at the rear of the machine. These bolts are crucial for securing the drum during transit and must be removed before use to prevent damage.

3.2 Positioning

Place the washing machine on a firm, level surface. Adjust the leveling feet to ensure the machine is stable and does not wobble. Proper leveling reduces vibration and noise during operation.

Image: Installation Guide with dimensions for Model WFO1061WLS. The diagram illustrates the washing machine's height (84.5 cm), width (49.7 cm), and depth (59.7 cm), crucial for proper placement and installation.

3.3 Water Connection

Connect the inlet hose to a cold water tap with a 3/4-inch thread. Ensure all connections are tight to prevent leaks. Do not overtighten.

3.4 Drainage Connection

Position the drain hose into a standpipe or over the edge of a sink. Ensure the drain hose is securely fixed to prevent it from dislodging during the wash cycle. The height of the drain hose should be between 60 cm and 100 cm from the floor.

3.5 Electrical Connection

Plug the power cord into a grounded 220V electrical outlet. Ensure the outlet is easily accessible. Do not use extension cords or adapters.

4. Operating Instructions

4.1 Control Panel Overview

The washing machine features an LCD touch screen display and a program selection knob. The display shows program information, cycle status, and error codes.

4.2 Loading Laundry

Open the door and load the laundry into the drum. Do not overload the machine; ensure there is enough space for clothes to tumble freely. Close the door firmly.



Image: The OCEAN washing machine positioned next to a laundry basket, illustrating typical laundry preparation before loading.

4.3 Adding Detergent

Pull out the detergent drawer. Add the appropriate amount of detergent and fabric softener to their respective compartments. Refer to your detergent packaging for recommended dosages.

4.4 Selecting a Program

Turn the program selection knob to choose one of the 15 available wash programs. The selected program will be displayed on the LCD screen. You can adjust additional options like temperature or spin speed using the touch controls, if available for the chosen program.

4.5 Starting a Wash Cycle

Press the Start/Pause button to begin the wash cycle. The machine will automatically fill with water and start the selected program.

4.6 Ending a Wash Cycle

Once the program is complete, the machine will signal with an audible alert or a message on the display. The door will unlock automatically after a short cooling period. Open the door and remove your laundry.

5. Wash Programs

The OCEAN WFO1061WLS offers 15 standard wash programs designed for various fabric types and soil levels. Consult the detailed program table in your printed manual for specific temperature, spin speed, and duration settings for each program. Common programs include:

- Cotton
- Synthetics
- Delicates
- Wool
- Quick Wash
- Rinse & Spin
- Drain
- Spin

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

6.1 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6.2 Cleaning the Detergent Drawer

Remove the detergent drawer and rinse it under running water to remove any detergent residue. Clean the drawer housing with a brush if necessary.

6.3 Cleaning the Drum

Periodically run a maintenance wash cycle (e.g., a hot wash with no laundry and a descaling agent) to clean the drum and remove any buildup.

6.4 Cleaning the Drain Filter

Locate the drain filter, usually at the bottom front of the machine. Place a shallow container underneath to catch any water. Unscrew the filter slowly, allow water to drain, and remove any lint or foreign objects. Clean the filter and screw it

back in securely.

7. Troubleshooting

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Machine does not start	No power; Door not closed; Program not selected	Check power supply; Close door firmly; Select a program and press Start
Water not filling	Water tap closed; Inlet hose kinked; Water pressure too low	Open water tap; Straighten hose; Check water supply
Machine vibrates excessively	Transport bolts not removed; Machine not level; Uneven load	Remove transport bolts; Adjust leveling feet; Redistribute laundry
Water not draining	Drain hose kinked; Drain filter blocked; Drain pump fault	Straighten hose; Clean drain filter; Contact service if pump fault

8. Specifications

Feature	Detail
Brand	OCEAN
Model	WFO1061WLS
Type	Front Load Washing Machine
Capacity	6 kg
Max Spin Speed	1000 RPM
Number of Programs	15
Control Type	Touch
Display Type	LCD
Drum Material	Stainless Steel
Color	Silver
Dimensions (H x W x D)	84.5 cm x 49.7 cm x 59.7 cm
Voltage	220 V
Item Weight	20 kg

9. Warranty and Support

For warranty information, please refer to the warranty card included with your purchase. Keep your proof of purchase for any warranty claims. For technical support or service, please contact your local OCEAN service center or authorized dealer. Do not attempt to repair the appliance yourself.

© 2024 OCEAN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8ZZ1BBG

More documents and user manuals: **https://manuals.plus/**