IBELL IBLMT500SL

IBELL Electric Chopper MT500SM User Manual

Model: MT500SM | Brand: IBELL

1. Introduction

Thank you for choosing the IBELL Electric Chopper MT500SM. This powerful and versatile kitchen appliance is designed to simplify your food preparation tasks, offering efficient chopping, slicing, and mincing of various ingredients. Please read this manual carefully before first use to ensure safe and optimal operation.



Image: The IBELL Electric Chopper MT500SM, showcasing its sleek design and the types of ingredients it can process.

2. Important Safety Instructions

- Always ensure the power supply matches the voltage specified on the appliance.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils away from the moving blades during operation. Blades are extremely sharp.
- Unplug the chopper from the power outlet before assembling, disassembling, cleaning, or when not in use.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner.

- Avoid processing excessively hard ingredients that may damage the blades or motor.
- Do not overload the bowl. Refer to the maximum capacity for ingredients.

3. Product Components

Familiarize yourself with the parts of your IBELL Electric Chopper:

- **Motor Unit:** Contains the powerful 1200W motor and control buttons.
- **Transparent Lid:** Covers the bowl during operation, allowing you to monitor the chopping process.
- **Stainless Steel Blades:** Four sharp blades designed for efficient and even chopping.
- **5L Stainless Steel Bowl:** Large capacity bowl for processing various ingredients.
- **Rubber Mat:** Provides stability and reduces vibration during operation.



Image: An exploded view illustrating the main components of the IBELL Electric Chopper: Motor Unit, Transparent Lid, Stainless Steel Blades, 5L Stainless Steel Bowl, and Rubber Mat.

4. Setup and Assembly

1. Place the rubber mat securely on a clean, flat, and stable surface.
2. Position the 5L stainless steel bowl onto the rubber mat.
3. Carefully place the stainless steel blades onto the central shaft inside the bowl. Ensure they are seated correctly.
4. Add your ingredients into the bowl. Do not exceed the maximum fill line.
5. Place the transparent lid onto the bowl, aligning it properly.
6. Position the motor unit on top of the transparent lid, ensuring it locks securely into place. The chopper will not operate if the motor unit is not correctly seated.
7. Plug the power cord into a suitable electrical outlet.

5. Operating Instructions

The IBELL Electric Chopper features a powerful 1200W motor and three-speed settings for various food types.

Speed Settings:

- **Speed 1 (Soft Food):** Ideal for softer ingredients like onions, garlic, and herbs.
- **Speed 2 (Hard Food):** Suitable for harder ingredients such as meat, nuts, and root vegetables.
- **Speed 3 (Beater/Whipping):** Use for whipping cream, beating eggs, or making purees.



Image: Visual guide demonstrating the three-speed settings for soft food (Speed 1), hard food (Speed 2), and beating/whipping (Speed 3).

Chopping Process:

1. Ensure the chopper is assembled correctly and plugged in.
2. Press and hold the desired speed button on the motor unit. The chopper will operate as long as the button is pressed.
3. For coarse chopping, use short pulses. For finer results, hold the button longer.
4. Monitor the consistency through the transparent lid.
5. Once desired consistency is achieved, release the button and unplug the appliance.
6. Wait for the blades to completely stop before removing the motor unit and lid.



Image: A visual comparison showing raw meat and vegetables before and after being processed by the IBELL Electric Chopper, demonstrating its chopping effectiveness.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your chopper.

1. Always unplug the appliance before cleaning.
2. Disassemble the chopper: remove the motor unit, then the lid, and carefully lift out the blades.
3. **Blades, Bowl, and Lid:** Wash these parts with warm, soapy water. Use a brush to safely clean the blades. Rinse thoroughly and dry immediately to prevent rust. These parts are generally dishwasher-safe, but hand-washing is recommended for blade longevity.
4. **Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse it in water or rinse it under running water.
5. Ensure all parts are completely dry before reassembling or storing.
6. Store the chopper in a dry place, away from direct sunlight and moisture.

7. Troubleshooting

Problem	Possible Cause	Solution
Chopper does not turn on.	Not plugged in; Motor unit not correctly assembled; Power outage.	Check power connection; Ensure motor unit is securely locked onto the lid; Check household power.
Ingredients not chopping evenly.	Overloaded bowl; Ingredients too large; Incorrect speed setting.	Reduce quantity; Cut ingredients into smaller pieces; Use appropriate speed setting.
Motor unit smells or overheats.	Overloading; Continuous operation for too long.	Reduce load; Allow appliance to cool down for 10-15 minutes before resuming.
Blades are stuck.	Too many ingredients; Hard ingredients.	Unplug, remove some ingredients, or cut them smaller.

8. Specifications

Feature	Detail
Model Number	MT500SM (IBLMT500SL)
Brand	IBELL
Color	Silver
Power	1200W
Bowl Capacity	5 Liters
Blade Material	Stainless Steel
Number of Blades	4
Product Dimensions	26L x 26W x 30H Centimeters
Item Weight	1 kg 900 g
Voltage	240 Volts (AC)
Country of Origin	China

9. Warranty and Support

Your IBELL Electric Chopper MT500SM comes with a**6 Month Standard Warranty**. Additionally, you can receive a**6 Month Additional Warranty** upon free registration. Registration should be completed within 30 days from the date of purchase.



Image: The IBELL Electric Chopper displaying a '1 Year Warranty' badge, representing the combined standard and extended warranty period.

Customer Support:

For any queries, service requests, or warranty registration, please contact:

Manufacturer: Innovative Technologies

Address: iBELL Fida's Building, Thottumugham P.O, Aluva, Kerala - 683105

Toll-Free Number: 1800 2020 260

Email: connect@ibellstore.com

© 2025 IBELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question