Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BIG BOOM EP-341661BIG BOOM

BIG BOOM 1.2m USB Charging Cable for Nintendo Gameboy Advance G User Manual

Model: EP-341661BIG BOOM

Introduction

This user manual provides essential information for the proper use and care of your BIG BOOM 1.2m USB Charging Cable, designed specifically for the Nintendo Gameboy Advance G. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

Product Overview

The BIG BOOM 1.2m USB Charging Cable is a dedicated power supply solution for your Nintendo Gameboy Advance G. It features a standard USB-A connector on one end and a proprietary connector for the Gameboy Advance G on the other.



Figure 1: The USB-A connector, designed to plug into a standard USB power source such as a wall adapter, computer, or power bank.



Figure 2: The proprietary connector for the Nintendo Gameboy Advance G, ensuring a secure and compatible connection to your device.



Figure 3: The complete 1.2-meter (approximately 4 feet) charging cable, showing both connectors and the cable length.

Setup

1. **Identify Power Source:** Locate a standard USB-A port on a compatible power source. This can be a USB wall adapter (5V/1A recommended), a computer's USB port, or a power bank.
2. **Connect to Power Source:** Insert the USB-A end of the BIG BOOM charging cable into the chosen USB power source.
3. **Connect to Device:** Carefully insert the proprietary connector end of the charging cable into the charging port of your Nintendo Gameboy Advance G. Ensure the connection is firm and secure.
4. **Verify Connection:** Once connected, your Gameboy Advance G should indicate that it is receiving power or charging, typically via an LED indicator on the device itself.

Operating Instructions

Once the cable is properly connected to both a power source and your Nintendo Gameboy Advance G, the device will begin to charge. The charging process is automatic. There are no additional controls on the cable itself.

- For optimal charging, ensure your Gameboy Advance G is turned off during the charging cycle.
- Monitor the device's charging indicator to determine when the battery is fully charged.
- Disconnect the cable from both the power source and the device once charging is complete.

Maintenance

- **Cleaning:** Use a soft, dry cloth to gently wipe the cable and connectors. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply to prevent internal damage.

- **Handling:** Always grasp the connector ends when plugging or unplugging the cable. Do not pull on the cable itself, as this can damage the internal wiring.

Troubleshooting

Problem	Possible Solution
Device not charging.	• Ensure both ends of the cable are securely connected. • Try a different USB power source (e.g., another wall adapter or computer port). • Verify that your Nintendo Gameboy Advance G's charging port is clean and free of debris. • Test the cable with another compatible device if available, or test another charging cable with your Gameboy Advance G to isolate the issue.
Loose connection.	• Ensure the connectors are fully inserted into their respective ports. • Avoid putting strain on the cable while charging.

Specifications

- **Product Name:** BIG BOOM 1.2m USB Power Supply Charger Charging Cable
- **Model Number:** EP-341661BIG BOOM
- **Compatibility:** Nintendo Gameboy Advance G
- **Cable Length:** 1.2 meters (approximately 4 feet)
- **Connector Type (Source):** USB-A
- **Connector Type (Device):** Proprietary Gameboy Advance G
- **Color:** Black (as shown)
- **Product Dimensions:** 15 x 5 x 10 cm (packaging/item dimensions)
- **Included Components:** 1 x Charging Cable

Disclaimer: Product color may slightly vary due to photographic lighting sources or your monitor settings.

Warranty and Support

For any queries, concerns, or support regarding your BIG BOOM 1.2m USB Charging Cable, please contact the seller directly through your purchase platform. Please refer to your purchase documentation for specific warranty details, if applicable.

© 2024 BIG BOOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9442TJV

More documents and user manuals: **https://manuals.plus/**