HONGSAMDE HSD101

HONGSAMDE HSD101 Windows 2-in-1 Tablet User Manual

Model: HSD101

1. Introduction

This manual provides essential instructions for setting up, operating, and maintaining your HONGSAMDE HSD101 Windows 2-in-1 Tablet. Please read this manual thoroughly before using the device to ensure proper functionality and longevity.

2. Package Contents

- HONGSAMDE HSD101 Windows 2-in-1 Tablet
- Detachable Keyboard
- Power Adapter
- User Manual (this document)

3. Product Overview

Familiarize yourself with the components and ports of your HONGSAMDE HSD101 tablet.



Figure 3.1: The HONGSAMDE HSD101 tablet shown with its detachable keyboard, illustrating its 2-in-1 functionality. The screen displays a vibrant image, highlighting the 10.1-inch HD IPS touch screen.



Figure 3.2: A detailed diagram showcasing the various ports and physical dimensions of the HONGSAMDE HSD101 tablet. This includes the Power ON/OFF button, Volume buttons, 3.5mm Audio Jack, Mini HDMI port, Type-C port, TF Slot, USB port, DC 12V power input, Keyboard Connect Port, and speaker locations. Front and Rear camera specifications are also indicated.

Key Components:

- **10.1" HD IPS Touch Screen:** For interactive input and clear visuals.
- **Power Button:** Located on the top edge for turning the device on/off and sleep/wake.
- **Volume Buttons:** Located on the top edge for adjusting audio output.
- **3.5mm Audio Jack:** For connecting headphones or external speakers.
- **Mini HDMI Port:** For connecting to external displays.
- **Type-C Port:** Multi-functional port for data transfer and charging.
- **TF Slot:** For expanding storage with a microSD card.
- **USB Port:** For connecting USB devices.
- **DC 12V Input:** Dedicated port for power adapter.
- **Keyboard Connect Port:** Magnetic connector for the detachable keyboard.
- **Front Camera (2.0 MP):** For video calls and selfies.
- **Rear Camera (2.0 MP):** For capturing photos and videos.

4. Setup

4.1 Initial Charging

1. Connect the power adapter to the DC 12V input port on the tablet.
2. Plug the power adapter into a wall outlet.

3. Allow the tablet to charge for at least 30 minutes before initial use, or until the battery indicator shows sufficient charge.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select "Shut down" from the options on the screen. Alternatively, go to Start > Power > Shut down.
- **Sleep Mode:** Briefly press the Power button to put the tablet into sleep mode or wake it up.

4.3 Attaching the Detachable Keyboard

The detachable keyboard connects magnetically to the tablet.

1. Align the keyboard's connector pins with the Keyboard Connect Port on the bottom edge of the tablet.
2. The magnets will guide the keyboard into place. Ensure a secure connection.
3. The keyboard will be automatically recognized by the Windows 11 Pro operating system.

5. Operating Instructions

5.1 Windows 11 Pro Overview

Your tablet runs on Windows 11 Pro, offering a familiar and powerful computing experience. Navigate using the touch screen, the detachable keyboard, or an external mouse (not included).

5.2 Touch Screen Gestures

- **Tap:** Select an item or open an application.
- **Tap and Hold:** Access contextual menus or drag items.
- **Swipe:** Scroll through content or navigate between screens.
- **Pinch-to-Zoom:** Zoom in or out on images and web pages.

5.3 Connecting to Wi-Fi

1. Click the Wi-Fi icon in the taskbar or go to Start > Settings > Network & internet > Wi-Fi.
2. Turn on Wi-Fi if it's off.
3. Select your desired network from the list and click "Connect".
4. Enter the network password if prompted.

5.4 Using External Displays (Mini HDMI)

Connect your tablet to a monitor or TV using a Mini HDMI to HDMI cable (not included).

1. Connect one end of the Mini HDMI cable to the tablet's Mini HDMI port.
2. Connect the other end to the HDMI input on your external display.
3. The tablet should automatically detect the external display. You can adjust display settings (duplicate, extend, second screen only) in Windows Display Settings.

6. Maintenance

6.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.

- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- Ensure the tablet is powered off and unplugged before cleaning.

6.2 Battery Care

- Avoid exposing the tablet to extreme temperatures.
- Do not fully discharge the battery regularly. Charge it when the battery level is low.
- If storing the tablet for an extended period, charge it to about 50% and power it off.

6.3 Software Updates

Regularly check for and install Windows updates to ensure optimal performance and security.

1. Go to Start > Settings > Windows Update.
2. Click "Check for updates" and install any available updates.

7. Troubleshooting

- **Tablet does not power on:** Ensure the tablet is charged. Connect the power adapter and try again.
- **Screen is unresponsive:** Perform a force restart by holding the Power button for approximately 10-15 seconds until the device powers off, then power it on normally.
- **Wi-Fi connection issues:** Restart your tablet and your Wi-Fi router. Ensure you are entering the correct password.
- **Keyboard not responding:** Ensure the keyboard is securely attached to the tablet's magnetic connector. Try detaching and reattaching it.
- **Slow performance:** Close unnecessary applications. Check for and install Windows updates. Consider running a disk cleanup.

8. Specifications

Feature	Detail
Model	HSD101
Operating System	Windows 11 Pro
Screen Size	10.1 Inches
Display Resolution	1280 x 800 pixels (HD IPS)
Processor	Intel N4000 (1.2 GHz)
Graphics Coprocessor	Intel UHD Graphics 600
RAM	8GB
Storage	128GB Flash Memory (expandable via TF Slot)
Wireless Standard	802.11ac
Front Camera	2.0 MP

Rear Camera	2.0 MP
Product Dimensions	60.96 x 1.02 x 35.56 cm (L x W x H)
Item Weight	1.43 kg
Color	Blackone

9. Warranty and Support

For warranty information and technical support, please refer to the documentation provided at the time of purchase or visit the official HONGSAMDE website. Keep your proof of purchase for warranty claims.

© 2025 HONGSAMDE. All rights reserved.