Starfrit 024739-001-0000

Starfrit 10-Cup Rice Cooker User Manual

Model: 024739-001-0000

Brand: Starfrit

Product Overview

The Starfrit 10-Cup Rice Cooker with Ceramic Coating is designed for effortless meal preparation, offering a generous capacity and intuitive one-step control for consistently perfect results. This appliance features a PTFE/APFO and PFAS-free ceramic cooking pot, promoting healthy cooking practices with a durable, eco-friendly non-stick surface. It is versatile, capable of cooking various types of rice, quinoa, and steaming vegetables or proteins.



Image: The Starfrit 10-Cup Rice Cooker in grey, shown with a clear glass lid and a bowl of cooked rice inside. Beside it, a plate holds cooked salmon, rice, and broccoli, illustrating a complete meal prepared with the cooker.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before use.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
13. Do not use appliance for other than intended use.
14. This appliance is for household use only.

Components

Familiarize yourself with the parts of your Starfrit Rice Cooker:



Image: An exploded view of the Starfrit 10-Cup Rice Cooker components. From left to right, it shows the ceramic cooking pot with a steaming basket inside, a measuring cup, a serving spoon, the main rice cooker unit, and the clear glass lid.

- **Main Unit:** The primary housing for the heating element and controls.
- **Ceramic Cooking Pot:** The removable non-stick pot where rice and other foods are cooked.

- **Clear Glass Lid:** Allows for monitoring of the cooking process.
- **Steaming Basket:** For steaming vegetables, fish, or other foods above the cooking rice.
- **Measuring Cup:** Used for accurate measurement of rice and water.
- **Serving Spoon:** A non-scratch spoon for serving cooked rice.

Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and components from the box.
2. **Clean:** Before first use, wash the ceramic cooking pot, glass lid, steaming basket, measuring cup, and serving spoon in warm, soapy water. Rinse thoroughly and dry completely. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, level, heat-resistant surface, away from walls or cabinets to allow for proper ventilation. Ensure it is out of reach of children and pets.
4. **Power Connection:** Ensure the power cord is not damaged and the voltage matches your household supply (120 Volts AC).

Operating Instructions

Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. One full measuring cup typically yields about 2 cups of cooked rice.
2. **Rinse Rice (Optional):** For best results and to remove excess starch, rinse the rice under cold water until the water runs clear.
3. **Add Rice to Pot:** Place the rinsed rice into the ceramic cooking pot.
4. **Add Water:** Add the appropriate amount of water. A general guideline is 1.5 to 2 cups of water for every 1 cup of uncooked rice, depending on the type of rice and desired consistency. Refer to the table below for common rice types.
5. **Place Pot in Cooker:** Ensure the exterior of the ceramic cooking pot is dry, then place it into the main unit of the rice cooker.
6. **Cover:** Place the glass lid securely on the rice cooker.
7. **Plug In:** Plug the power cord into a standard 120V AC electrical outlet. The "WARM" indicator light will illuminate.
8. **Start Cooking:** Press the "COOK" switch down. The "COOK" indicator light will illuminate, and cooking will begin.
9. **Automatic Keep Warm:** Once the rice is cooked, the cooker will automatically switch to the "WARM" setting, and the "WARM" indicator light will illuminate. This function keeps the rice warm and ready to serve without overcooking.
10. **Resting Period:** For optimal results, allow the rice to rest on the "WARM" setting for 5-10 minutes after cooking is complete. This allows the moisture to distribute evenly.
11. **Serve:** Use the provided serving spoon to fluff and serve the rice.
12. **Unplug:** Always unplug the rice cooker from the outlet when not in use.



Image: A close-up view of the Starfrit Rice Cooker's control panel, highlighting the "COOK" and "WARM" indicator lights and the cooking switch.

Rice to Water Ratio Guide

Rice Type	Rice (Measuring Cups)	Water (Measuring Cups)	Approx. Cook Time
White Rice	1	1.5 - 2	15-20 min
Brown Rice	1	2 - 2.5	30-40 min
Quinoa	1	2	15-20 min

Note: These are general guidelines. Adjust water amounts based on desired texture and specific rice variety.

Steaming Food

The included steaming basket allows you to steam vegetables, fish, or other foods while your rice cooks below.

1. **Prepare Rice:** Follow steps 1-5 for cooking rice.
2. **Prepare Food for Steaming:** Wash and cut vegetables or other foods into uniform pieces.
3. **Place in Basket:** Arrange the food in the steaming basket. Do not overfill.
4. **Insert Basket:** Place the steaming basket on top of the ceramic cooking pot inside the rice cooker.
5. **Cover and Cook:** Place the glass lid securely on the cooker and press the "COOK" switch.
6. **Monitor:** Steaming times vary by food type. Monitor the food and remove the steaming basket when done. Be careful of hot steam when removing the lid.



Image: The Starfrit Rice Cooker with its lid removed, showing green vegetables like broccoli and bok choy steaming in the basket above the cooking pot.

Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your rice cooker.

1. **Unplug and Cool:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Remove Components:** Remove the ceramic cooking pot, glass lid, steaming basket, measuring cup, and serving spoon.
3. **Wash Removable Parts:** Wash the ceramic cooking pot, glass lid, steaming basket, measuring cup, and serving spoon in warm, soapy water. The ceramic pot has a non-stick coating, so avoid abrasive cleaners or metal scouring pads. A soft sponge or cloth is recommended. Rinse thoroughly and dry completely.
4. **Clean Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid. Ensure no water enters the electrical components.
5. **Storage:** Once all parts are clean and dry, reassemble the cooker or store the components neatly. Store in a cool, dry place.

Troubleshooting

If you encounter issues with your Starfrit Rice Cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard or undercooked.	Not enough water; lid not sealed properly; cooker unplugged too early.	Add more water next time; ensure lid is secure; allow cooker to complete cycle and rest on "WARM" setting.

Problem	Possible Cause	Solution
Rice is too soft or mushy.	Too much water.	Reduce water amount next time; ensure rice is not over-rinsed.
Rice sticks to the bottom of the pot.	Not enough water; pot not properly cleaned; excessive starch.	Ensure proper water ratio; clean pot thoroughly after each use; rinse rice before cooking.
Cooker does not turn on.	Not plugged in; power outlet issue; internal malfunction.	Check power cord connection; test outlet with another appliance; contact customer support if issue persists.
"WARM" light is on, but "COOK" light does not activate.	Cook switch not pressed down; cooker already in warm mode.	Ensure the cook switch is fully depressed; if rice is already cooked, it will remain in warm mode.

Specifications

Key technical specifications for the Starfrit 10-Cup Rice Cooker:



Image: The Starfrit 10-Cup Rice Cooker with its dimensions clearly marked: 8.3 inches (21.1 cm) height, 8.9 inches (22.8 cm) depth, and 10.4 inches (26.4 cm) width.

- **Model Name:** Starfrit 10-Cup Rice Cooker with ceramic coating - Grey
- **Model Number:** 024739-001-0000
- **Capacity:** 10 Cups (uncooked rice)
- **Color:** Grey
- **Material:** Ceramic (cooking pot), Glass (lid)
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (AC)
- **Wattage:** 400 watts
- **Product Dimensions:** Approximately 8.9 inches (22.8 cm) Depth x 10.4 inches (26.4 cm) Width x 8.3 inches (21.1 cm) Height
- **Item Weight:** 3.2 Pounds
- **Special Feature:** 10-cup capacity, Clear glass lid, Non-Stick ceramic coating (PFAS-Free)

- **Included Components:** Rice cooker, ceramic cooking pot, clear glass lid, measuring cup, steaming basket, serving spoon.

Warranty and Support

Starfrit products are manufactured to high quality standards. For any questions regarding your product, warranty claims, or technical support, please contact Starfrit Customer Service.

Please retain your proof of purchase for warranty purposes. Specific warranty terms and conditions may vary by region and retailer.

For further assistance, visit the official Starfrit website or refer to the contact information provided with your product packaging.

Online Resources: www.starfrit.com

© 2025 Starfrit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question