Fantovpha HTV7

Fantovpha Remote Control User Manual

Model: HTV7 - Compatible with HTV 7, H7, HTV 8, H8, and HTV Cast

Introduction

This manual provides detailed instructions for the Fantovpha replacement remote control, designed for seamless compatibility with original HTV 7, H7, HTV 8, H8, and HTV Cast devices. Crafted from durable ABS material, this lightweight remote ensures reliable performance and ease of use.
Please read this manual thoroughly before using your new remote control to ensure proper setup and operation.

Package Contents

- 1 x Fantovpha Replacement Remote Control
- *(Batteries are not included)*





Image: Front and back view of the Fantovpha remote control, shown in its packaging.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.

2. Pairing with Your Device (Bluetooth Connectivity)

This remote control utilizes Bluetooth technology for connection. The pairing process may vary slightly depending on your specific HTV device model (HTV 7, H7, HTV 8, H8, or HTV Cast). Generally, follow these steps:

1. Ensure your HTV device is powered on and visible on your TV screen.
2. Navigate to the **Settings** menu on your HTV device (you may need to use an existing remote or the device's physical controls for this initial step).
3. Look for **Bluetooth** or **Connected Devices** options.
4. Select **Add New Device** or **Pair Remote Control**.
5. On the Fantovpha remote, press and hold the **OK** button and the **Volume Down (-)** button simultaneously for 3-5 seconds until an indicator light on the remote (if present) begins to flash, signaling pairing mode.
6. Your HTV device should detect the "Fantovpha Remote" or a similar name. Select it to complete the pairing process.
7. Once paired, the indicator light on the remote will stop flashing, and a confirmation message may appear on your TV screen.

If pairing fails, ensure the remote is close to the HTV device and repeat the steps. Refer to your HTV device's specific user manual for detailed pairing instructions if needed.



Image: Visual comparison of a white remote and the black Fantovpha replacement remote, highlighting its design.

Operating Instructions

Once paired, your Fantovpha remote control functions similarly to the original remote for your HTV device. Below is a general overview of common button functions:

- **Power Button:** Turns the HTV device on or off.
- **Number Pad (0-9):** For direct channel input or specific menu selections.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the main home screen of your HTV device.
- **Volume Buttons (+/-):** Adjusts the volume.
- **Mute Button:** Mutes or unmutes audio.
- **Microphone Button:** Activates voice control (if supported by your HTV device).
- **Menu Button:** Opens context-sensitive menus.

For specific application controls, refer to the on-screen instructions provided by your HTV device.



Image: The Fantovpha remote control positioned next to an HTV8 media box, illustrating its intended use.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause / Solution
Remote not responding.	Check if batteries are correctly inserted with correct polarity. Replace old batteries with new ones. Ensure the remote is within range of the HTV device. Re-pair the remote control with your HTV device (refer to "Setup" section).
Voice control not working.	Ensure your HTV device supports voice control. Check if the remote is properly paired via Bluetooth. Verify microphone permissions on your HTV device settings.
Buttons are sticky or unresponsive.	Clean the remote control surface with a dry, soft cloth. Avoid spilling liquids on the remote.

Specifications

Model Number	HTV7
Brand	Fantovpha
Compatible Devices	HTV 7, H7, HTV 8, H8, HTV Cast (Original devices)
Connectivity Technology	Bluetooth
Max Number of Supported Devices	1
Special Feature	Lightweight design
Item Weight	1.41 ounces (approx. 40 grams)
Package Dimensions	6.18 x 1.61 x 0.98 inches

Warranty Information

Fantovpha products are manufactured to high-quality standards. For specific warranty details regarding your remote control, please refer to the warranty card included with your purchase or contact the retailer where the product was acquired. Keep your proof of purchase for any warranty claims.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact Fantovpha customer support through the retailer's platform or the contact information provided with your product. Our support team is available to assist you.

© 2024 Fantovpha. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question