SAN HIMA SH-CAM-FAN-ORG

SAN HIMA Battery Powered Camping USB Desk Fan

Model: SH-CAM-FAN-ORG

INTRODUCTION

Thank you for choosing the SAN HIMA Battery Powered Camping USB Desk Fan. This versatile fan is designed for both indoor and outdoor use, offering adjustable airflow, integrated LED lighting, and a long-lasting rechargeable battery. It features four fan speeds, three LED brightness levels, 45°/90° oscillation, and a convenient timer function. Please read this manual thoroughly before use to ensure proper operation and maintenance.

SAFETY INSTRUCTIONS

- Do not immerse the fan in water or other liquids.
- Keep out of reach of children.
- Do not insert fingers or foreign objects into the fan grille.
- Use only the provided charging cable or a certified equivalent.
- Do not attempt to disassemble or repair the fan yourself. Contact customer support if service is required.
- Avoid exposing the fan to extreme temperatures or direct sunlight for prolonged periods.
- Ensure the fan is placed on a stable surface when in use.

PACKAGE CONTENTS

- SAN HIMA Camping Fan (Model: SH-CAM-FAN-ORG)
- USB Charging Cable
- Remote Control
- User Manual

PRODUCT OVERVIEW

The SAN HIMA fan combines powerful airflow with practical lighting and charging capabilities. Its robust design makes it suitable for various environments.

Figure 1: Overall view of the SAN HIMA Camping Fan.

Figure 2: Control panel with fan speed, light, timer, and oscillation buttons.

Key Features:

- **Adjustable Airflow:** Five-bladed fan with four speed settings.
- **Integrated LED Light:** Three brightness levels for illumination.
- **Rechargeable Battery:** 20000mAh capacity for extended use, with dual USB ports for charging other devices.
- **Versatile Placement:** 270° adjustable angle, 45°/90° oscillation, handle, and 360° rotating hook for hanging.
- **Timer Function:** Set for 1, 2, 4, or 8 hours.
- **Remote Control:** For convenient operation.

SETUP

Charging the Fan:

Before first use, fully charge the fan. Connect the provided USB charging cable to the fan's charging port and a suitable USB power adapter (not included). The battery indicator lights on the control panel will show the charging progress. Once all four lights are solid, the fan is fully charged.

Figure 3: The fan can charge other devices via its USB ports.

Placement Options:

- **Freestanding:** Place the fan on any flat, stable surface.
- **Hanging:** Use the integrated 360° rotating hook to hang the fan inside a tent, from a branch, or in a vehicle.

Figure 4: Fan hanging, demonstrating adjustable angle and oscillation.

OPERATING INSTRUCTIONS

The fan can be operated using the control panel buttons on the base or the included remote control.

Power On/Off:

Press the central fan button on the control panel or the power button on the remote to turn the fan on or off.

Adjusting Fan Speed:

With the fan on, press the fan speed button (usually indicated by a fan icon or numbers 1-4) on the control panel or remote to cycle through the four available speeds. The blue indicator lights will show the current speed setting.

Figure 5: Fan speed settings and approximate runtimes.

Controlling LED Light:

Press the light button (sun icon) on the control panel or remote to turn the LED light on. Press again to cycle through the three brightness levels. Press the moon icon button to turn off the light.

Figure 6: LED light brightness levels.

Oscillation Function:

Press the oscillation button (circular arrow icon) on the control panel or remote to activate the oscillation feature. The fan will oscillate at either 45° or 90° depending on the setting. Press again to stop oscillation.

Setting the Timer:

Press the timer button (L icon) on the control panel or remote to set the fan to turn off automatically after 1, 2, 4, or 8 hours. The corresponding indicator light will illuminate.

Figure 7: Timer settings for automatic fan shut-off.

Video Demonstration:

Video 1: A demonstration of the fan's controls, including fan speed, LED light, and oscillation settings.

MAINTENANCE

- **Cleaning:** Disconnect the fan from power before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** Store the fan in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

- **Fan not turning on:** Ensure the battery is charged. If using a power adapter, check the connection.
- **LED light not working:** Check if the light function is activated. Ensure the battery has sufficient charge.
- **Remote control not working:** Check the remote's battery. Ensure there are no obstructions between the remote and the fan.
- **Reduced airflow:** Clean any dust or debris from the fan grille and blades.

If you encounter issues not covered here, please contact SAN HIMA customer support.

SPECIFICATIONS

Brand	SAN HIMA
Model Name	SH-CAM-FAN-ORG
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Number of Power Levels	4 (Fan Speeds)
LED Light Levels	3 (Brightness)
Oscillation Angles	45°, 90°
Control Method	Remote, Touch

Product Dimensions	9.05"D x 4.1"W x 10.6"H
Item Weight	2.87 Pounds
Indoor/Outdoor Usage	Outdoor
Mounting Type	Freestanding, Hanging Hook

WARRANTY AND SUPPORT

The SAN HIMA Battery Powered Camping USB Desk Fan comes with a 1-year warranty. For warranty claims, technical support, or any questions regarding your product, please refer to the contact information provided with your purchase or visit the official SAN HIMA website.