XCZAP 1720

XCZAP Outdoor Sport Watch Instruction Manual

Model: 1720

Introduction

Thank you for choosing the XCZAP Outdoor Sport Watch, Model 1720. This digital watch is designed for active individuals, offering a blend of style, durability, and essential functions. With its 5Bar water resistance, LED backlight, and comfortable silicone band, it is suitable for various outdoor and indoor activities. This manual provides detailed instructions to help you set up, operate, and maintain your watch for optimal performance.

Product Overview





Figure 1: Front view of the XCZAP Outdoor Sport Watch (A-Black-3).

The XCZAP Outdoor Sport Watch features a clear digital display and four control buttons:**LIGHT** (top left), **MODE** (bottom left), **START** (top right), and **RESET** (bottom right). The watch is encased in durable rubber with an alloy band case material and a comfortable PU band, secured by a buckle clasp.



Figure 2: Watch dimensions and weight.

The watch is lightweight at approximately 35g. Its dimensions are: Dial Diameter: 38mm (1.49in), Case Thickness: 12mm (0.47in), Band Width: 16mm (0.62in), Band Length: 225mm (8.85in).

Setup and Basic Operation

Setting Time and Date

1. Press the **MODE** button repeatedly until the time setting mode is displayed (usually indicated by flashing digits).
2. Use the **RESET** button to select the digit you wish to adjust (hours, minutes, year, month, day).
3. Press the **START** button to increase the selected digit. Hold to rapidly advance.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to normal time display.

12/24 Hour Format

In normal time display mode, press the **START** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

Using the Backlight

Press the **LIGHT** button to illuminate the display for easy viewing in low-light conditions. The backlight will remain on for a few seconds.



Figure 3: Key features of the XCZAP watch.

Operating Functions

Alarm Clock

1. From normal time mode, press **MODE** once to enter Alarm mode.
2. Press **RESET** to select the hour or minute digits.
3. Press **START** to adjust the selected digit.
4. To activate/deactivate the alarm, press **START** while in Alarm mode (without flashing digits). An alarm icon will appear/disappear on the display.
5. Press **MODE** to return to normal time.

Stopwatch (Chronograph)

1. From normal time mode, press **MODE** twice to enter Stopwatch mode. The display will show "00:00:00".
2. Press **START** to begin timing.
3. Press **START** again to pause timing.
4. To reset the stopwatch, press **RESET** while the stopwatch is paused.
5. Press **MODE** to return to normal time.

Daily Use and Comfort



Figure 4: The soft silicone band provides skin-friendly comfort.

The watch features a high-quality lightweight resin bezel/case/strap design with a stainless steel back cover, ensuring comfort and preventing skin irritation. Its simple appearance and large dial design make it easy to read the LED backlight display, day or night.

Your browser does not support the video tag.

Video 1: Demonstration of the XCZAP watch features and wearability. This video showcases the watch's design, various functions like timer and backlight, and its comfortable fit on the wrist.

Water Resistance

The XCZAP Outdoor Sport Watch is rated for 3ATM (30 meters) water resistance. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion such as hand washing. It is **not recommended** for showering, swimming, diving, or any prolonged water activities, especially in hot water, as steam can penetrate the seals and cause damage.



Figure 5: The watch is suitable for daily water exposure like hand washing.

Maintenance

Cleaning

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and components. Ensure the watch is dry before storing.

Battery Replacement

The watch uses a standard button cell battery (CR2025, as indicated on the back). When the display dims or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage

Store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. If storing for an extended period, consider removing the battery to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery (CR2025).

Problem	Possible Cause	Solution
Time is inaccurate.	Incorrect setting; low battery.	Re-set the time; replace the battery if issue persists.
Buttons are unresponsive.	Moisture inside; physical damage.	Ensure watch is dry. If water damage is suspected, seek professional repair. Avoid pressing buttons underwater.
Alarm does not sound.	Alarm not activated; incorrect time set.	Verify alarm is turned ON in Alarm mode. Check alarm time setting.
Water inside the watch.	Exceeded water resistance limits (e.g., swimming, hot shower).	Immediately stop using the watch and seek professional repair. Water damage is typically not covered under warranty.

Specifications

Feature	Detail
Gender	Women
Style	Fashion & Casual, Sport
Movement	Digital
Case Material	Rubber
Band Case Material	ALLOY
Clasp Type	Buckle
Band Material Type	PU
Dial Diameter	38mm / 1.49in
Case Thickness	12mm / 0.47in
Band Width	16mm / 0.62in
Band Length	225mm / 8.85in
Water Resistance Depth	30M (3ATM)
Functions	LED Light, Chronograph, Alarm, 12/24 Hour, Date, Week, Stopwatch
Item Model Number	1720
Manufacturer	XCZAP
Date First Available	November 28, 2024

Warranty and Support

This XCZAP product is manufactured with high-quality materials and undergoes strict quality control. For information regarding warranty coverage and terms, please refer to the product packaging or contact your retailer. For technical support or inquiries,

please reach out to XCZAP customer service through the contact information provided on the official brand website or your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question