Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TwoOases TC-SC-001

TwoOases Upgraded 2500W Handheld Steam Cleaner Instruction Manual

Model: TC-SC-001 | Brand: TwoOases

Introduction

The TwoOases Upgraded 2500W Handheld Steam Cleaner is designed for effective cleaning using high-temperature and high-pressure steam. With a powerful 2500W heating element, it generates 221°F (105°C) steam at 3 Bar pressure within 15 seconds, capable of dissolving stubborn dirt, grime, and stains. Its portable design and various attachments make it suitable for a wide range of household cleaning tasks.

Included Components

The package contains the following items:

- 1 x Steam Cleaner Machine
- 1 x 1.5M Power Cord
- 1 x Extension Tube
- 2 x Steel Brushes
- 2 x Plastic Brushes
- 1 x Round Plastic Brush
- 1 x Bent Nozzle
- 1 x Window Squeegee
- 1 x Ironing Brush
- 5 x Ironing Brush Cloths
- 2 x Sealing Rings
- 1 x Glove
- 1 x User Manual



Figure 1: All components included with the TwoOases Handheld Steam Cleaner.

Safety Information

- Every steam cleaner is tested before leaving the factory, so water marks may be present on the water inlet hose. This is normal.
- There is no control unit on the spray gun. To stop steaming, turn off the switch power on the machine's body.
- Do not touch the metal nozzle or the steam directly. Avoid spraying at humans, pets, or the device itself.
- Always confirm the position of the gasket to prevent air and water leakage.
- Use the included glove to protect yourself from hot steam and surfaces.

Setup

1. Fill Water Tank

Ensure the steam cleaner is unplugged before filling the water tank. Open the water inlet and carefully pour up to 1100ml of water into the tank. Do not overfill. The 1100ml tank allows for approximately 30 minutes of continuous use.



Figure 2: Filling the water tank. Ensure the device is unplugged.

2. Attach Accessories

Select the appropriate brush head or nozzle for your cleaning task. Attach it directly to the spray gun or use the extension tube for hard-to-reach areas. The accessories are designed for plug-and-play installation.



Figure 3: Selection of 6-in-1 steam cleaner accessories.



Figure 4: Attaching a brush head to the extension tube.

3. Power On

Plug the power cord into a suitable electrical outlet. Short press the power button on the unit. The steam cleaner will heat up in approximately 15 seconds.



Figure 5: Powering on the steam cleaner and its quick heat-up time.

Operating Instructions

1. Adjust Steam Output

The steam cleaner features 6 adjustable gears. Use the '+' or '-' buttons to adjust the steam output and humidity according to your cleaning needs. The screen will display the real-time gear setting.



Figure 6: Adjusting steam output levels.

2. General Usage

Once the unit is heated, hold the spray gun and aim the steam at the dirty surface. Use the appropriate brush or nozzle for optimal cleaning. The closer the nozzle is to the surface, the higher the temperature of the steam.

3. Application Examples

The steam cleaner is versatile for various applications:

- **Kitchen:** Ideal for cleaning stoves, sinks, and range hoods.
- **Bathroom:** Effective on tiles, grout, faucets, and toilets.
- **Windows:** Use the window squeegee attachment for streak-free glass.
- **Upholstery & Fabrics:** The ironing brush and cloth can be used for freshening sofas and other fabric surfaces.
- **Car Interiors:** Various brushes can tackle dirt and grime in car interiors.



Figure 7: Examples of specific brush uses for different cleaning tasks.

Video 1: Demonstrating steam cleaning in the kitchen, including stove and sink areas.

Video 2: Cleaning a sink and faucet with high-temperature steam.

Video 3: Handheld steam cleaner in use for bathroom cleaning.

Video 4: Demonstrating steam cleaning on tiles.

Video 5: Steam cleaning a window for a clear finish.

Video 6: Portable steamer used for cleaning a grill.

Maintenance

1. Draining Water

After each use, ensure the unit is unplugged and cooled down. Locate the stopper under the tank and pull it out to empty any remaining water. Dispose of the water properly.



Figure 8: Draining the water tank after use.

2. Cleaning Accessories

Clean all brush heads and nozzles with water after use. The ironing brush cloths are washable and reusable.

Troubleshooting

- **No Steam/Low Steam:** Ensure the water tank is adequately filled and the unit has fully heated up (approx. 15 seconds). Check that the gasket is properly positioned to prevent air leakage.
- **Water Leakage:** Verify that all attachments are securely fastened and the sealing rings are correctly in place.
- **Stopping Steam:** Remember there is no trigger on the spray gun. To stop steam, turn off the main power switch on the machine's body.

Specifications

Brand	TwoOases
Model Name	Handheld Steam Cleaner (TC-SC-001)
Wattage	2500 watts
Item Weight	3.8 Pounds
Tank Volume	1100 Milliliters
Heat Time	15 Seconds
Maximum Temperature	221 Degrees Fahrenheit (105 Degrees Celsius)
Product Dimensions	5.7"D x 7.9"W x 5.2"H

Warranty and Support

The TwoOases Handheld Steam Cleaner comes with a 1-year warranty. For any questions or support needs, please contact our customer service. We are committed to providing satisfactory after-sales service and will assist you in resolving any issues.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9BN8V7X

More documents and user manuals: **https://manuals.plus/**