Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KRPTQJoo Joo4476

KRPTQJoo Replacement Remote Control User Manual

Model: Joo4476

Introduction

This manual provides comprehensive instructions for the KRPTQJoo replacement infrared remote control. Designed for ease of use, this remote control is compatible with a range of Bauhn TV models, offering a direct replacement without the need for complex programming.
Important Note: This remote control is a direct replacement and does not require pairing or programming. Some advanced functions may depend on your specific TV model's capabilities. Refer to your television's original manual for specific feature support.

Compatible Bauhn TV Models

This remote control is compatible with the following Bauhn TV models:

- ATV32H-014
- ATV32H-1215
- ATV40-014
- ATV50-715
- ATV50F-415
- AT24C-815
- ATV55UHD-1217
- ATV58UHD-0718
- ATV215C-0217
- ATV75UHD-0618
- ATV24C-0617

Ensure your TV model is listed above for full compatibility.

Setup

1. Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the remote control, illustrating the location of the battery compartment.

2. Initial Use

Once batteries are installed, the remote control is ready for use. Point the remote directly at your Bauhn TV and press the **STANDBY** button to power on the television.

Operating Instructions

This section details the functions of the buttons on your KRPTQJoo replacement remote control.



Image: Front view of the remote control, displaying the layout of all control buttons.

Button Functions Overview

- **STANDBY**: Powers the TV on or off.
- **TV/RADIO**: Switches between TV and Radio modes.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **SLEEP**: Sets a sleep timer for the TV.
- **MUTE**: Mutes or unmutes the TV audio.
- **PMODE**: Cycles through picture modes.
- **SMODE**: Cycles through sound modes.
- **0-9 (Number Buttons)**: Directly selects channels or inputs numerical values.
- **-/--**: Toggles between single and double-digit channel input.
- **TEXT DISPLAY**: Activates or deactivates Teletext display.
- **MENU**: Opens the TV's main menu.
- **EXIT**: Exits the current menu or function.
- **TITLE**: Accesses title-related functions (if supported by TV).
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **VOL+/-**: Adjusts the volume level.

- **CH+/-**: Changes the channel up or down.
- **GOTO**: Jumps to a specific time or chapter (if supported by media playback).
- **ANGLE REPEAT**: Controls angle or repeat functions (if supported by media playback).
- **A-B**: Sets A-B repeat points (if supported by media playback).
- **HOLD**: Holds the current Teletext page.
- **SIZE**: Adjusts Teletext display size.
- **SUBTITLE**: Toggles subtitles on or off.
- **AUDIO**: Selects audio tracks or languages.
- **LANG**: Changes language settings.
- **FREEZE**: Freezes the current image.
- **ZOOM**: Zooms in on the picture.
- **INDEX**: Accesses Teletext index.
- **MEDIA**: Opens the media player.
- **EPG**: Displays the Electronic Program Guide.
- **FAV**: Accesses favorite channels list.
- **Color Buttons (Red, Green, Yellow, Blue)**: Functions vary depending on the TV menu or interactive services.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Previous, Stop, Next, Record)**: Controls media playback functions.

Note: The functionality of some buttons may vary or be unavailable depending on your specific Bauhn TV model and its features.

Maintenance

Cleaning the Remote Control

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, alcohol, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote control is not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the operating range (up to 8 meters) and pointing the remote directly at the TV.
- **Some buttons do not work:**
  - Verify that your specific Bauhn TV model supports the function associated with the button. Refer to your TV's original

user manual.
    - This remote is a replacement; some advanced or model-specific functions may not be supported if your TV's original remote had unique features.
- **Remote control works intermittently:**
    - This often indicates low battery power. Replace the batteries.
    - Ensure there is no strong light source (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.

Specifications

Brand	KRPTQJoo
Model Number	Joo4476
Compatible Devices	Bauhn Televisions (specific models listed in "Compatible Bauhn TV Models" section)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Maximum Range	8 Meters
Color	Black

Support

For any issues or questions regarding your KRPTQJoo remote control, please contact the seller directly. They are committed to providing assistance and resolving any concerns you may have.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9C1NTZ3

More documents and user manuals: **https://manuals.plus/**