Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Razee Y-13 Natural

Razee Kids Play Tent User Manual

Model: Y-13 Natural

1. Introduction

Thank you for choosing the Razee Kids Play Tent. This manual provides essential information for the safe assembly, operation, and maintenance of your new play tent. Designed for both indoor and outdoor use, this sturdy and spacious playhouse offers a fun and imaginative space for children.



Image 1.1: The Razee Kids Play Tent, fully assembled and decorated with colorful pennant banners, ready for play.

2. Safety Information

WARNING: Adult supervision is required at all times when children are using the play tent.

- Keep all packaging materials (plastic bags, ties, etc.) away from children to prevent suffocation.
- Ensure the tent is assembled on a flat, stable surface to prevent tipping.
- Do not use the tent near open flames, heaters, or any heat sources. The fabric is not fireproof.
- Regularly inspect the tent for any damage, loose parts, or wear and tear. Discontinue use if damaged.
- This product is intended for play and should not be used as a substitute for a crib or bed.
- Recommended for children aged 12 months and up.

3. Package Contents

Please check the package to ensure all components are present and undamaged:

- Play Tent Fabric (1 pc)
- Frame Poles (various lengths, quantity as per assembly diagram)
- Connectors (various types, quantity as per assembly diagram)
- Pennant Banners (1 set)
- Storage Bag (1 pc)

If any parts are missing or damaged, please contact customer support.

4. Setup and Assembly

Assembly is required. It is recommended that an adult performs the assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Base Frame:** Identify the longest poles and the appropriate connectors to form the rectangular base of the tent. Connect them securely.
3. **Construct Vertical Supports:** Attach the vertical poles to the corners of the base frame using the designated connectors.
4. **Form Roof Structure:** Connect the remaining poles to create the A-frame roof structure. Ensure all connections are firm.
5. **Drape Tent Fabric:** Carefully drape the tent fabric over the assembled frame. Ensure the door opening and window align correctly with the frame.
6. **Secure Fabric:** Tie the fabric ties to the frame poles where indicated to secure the tent fabric in place.
7. **Attach Pennant Banners:** String the pennant banners along the top front edge of the tent or as desired for decoration.
8. **Final Check:** Before allowing children to play, ensure all poles are securely connected and the tent is stable.



Image 4.1: The colorful pennant banners that come with the play tent, adding a festive touch.

5. Operating Instructions

The Razee Kids Play Tent is designed for imaginative play. Here are some tips for use:

- **Indoor Use:** Place the tent on a soft, flat surface like a rug or carpet. Ensure there is enough space around the tent for safe play.
- **Outdoor Use:** The tent can be used outdoors on dry, calm days. Avoid using it in strong winds or rain. Place it on a level, clear area away from sharp objects.
- **Encourage Creativity:** The tent provides a private space for reading, playing games, or reenacting fairy tales. Encourage children to use their imagination.
- **Capacity:** The tent is spacious enough for 4-5 children to play comfortably inside.

6. Care and Maintenance

- **Cleaning Fabric:** The polyester cotton fabric can be spot cleaned with a damp cloth and mild soap. Do not machine wash or tumble dry. Allow to air dry completely.
- **Cleaning Frame:** Wipe the frame poles with a damp cloth as needed.
- **Storage:** When not in use, disassemble the tent and store it in its original storage bag in a cool, dry place away from direct sunlight. This will prolong the life of the product.
- **Regular Inspection:** Periodically check all connections and fabric for any signs of wear or damage.

7. Troubleshooting

Tent is unstable after assembly:

Ensure all poles are fully inserted into their connectors and that the fabric ties are securely fastened to the frame. Verify the tent is on a flat, level surface.

Fabric does not fit the frame correctly:

Check that the frame has been assembled according to the instructions and that the fabric is oriented correctly (e.g., door opening aligned). Some stretching may be required to fit snugly.

Poles are difficult to connect/disconnect:

Apply gentle, even pressure. Do not force connections. If poles are stuck, try twisting slightly while pulling/pushing. Ensure no debris is in the connectors.

8. Specifications

Model Number	Y-13 Natural
Material	Cotton Polyester (Fabric), Aluminum (Frame)
Color	Light Beige
Product Dimensions (L x W x H)	125.73 x 90.17 x 125.73 cm (49.5 x 35.5 x 49.5 inches)
Item Weight	2.97 kg
Recommended Age	12 months and up
Assembly Required	Yes



Image 8.1: Visual representation of the play tent's dimensions: 49.5 inches height, 35.5 inches depth, and 49.5 inches width.

9. Warranty and Support

Razee products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For product support, missing parts, or any inquiries, please contact your retailer or the manufacturer directly through their official website or customer service channels. Please have your model number (Y-13 Natural) and purchase details ready when contacting support.

© 2024 Razee. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9HB7CZJ

More documents and user manuals: **https://manuals.plus/**