Vigosit B0D9JN8M8M

Vigosit Gaming Chair Instruction Manual

Model: B0D9JN8M8M (Cat Pink)

1. Introduction

Thank you for choosing the Vigosit Gaming Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.



Image: The Vigosit Gaming Chair, featuring a pink and white design with cat ears and a paw-shaped lumbar cushion, set up in a pink-themed gaming room.

2. Important Safety Information

WARNING: Exceeding the maximum weight capacity or using non-certified components may result in chair instability or damage. For safe operation, follow all instructions and guidelines provided.

- Always ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the chair.
- Do not use the chair if any parts are missing, damaged, or worn. Contact customer support for replacement parts.
- Keep small parts away from children to prevent choking hazards during assembly.
- Use the chair on a flat, stable surface.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or defective, please contact Vigosit customer service.



Image: An exploded diagram illustrating all individual parts included with the Vigosit Gaming Chair for assembly.

Typical components include:

- Backrest
- Seat Cushion with Armrests
- Base (Star Base)
- Casters (Wheels)
- Gas Lift Cylinder
- Mechanism Plate
- Lumbar Support Pillow (Paw-shaped)
- Headrest Pillow
- Cat Ears (Removable)

- Hardware (Screws, Washers, Allen Key)

4. Assembly Instructions

Assembly typically takes about 15 minutes. For detailed visual guidance, refer to the included installation manual or video provided by Vigosit.

1. **Attach Casters to Base:** Insert the casters into the holes at the end of each leg of the star base until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled base.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Secure it with the provided screws. Ensure the front of the mechanism faces the front of the seat.
4. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.
5. **Attach Backrest to Seat:** Align the backrest with the mounting brackets on the seat cushion. Secure with screws on both sides.
6. **Install Pillows and Accessories:** Attach the headrest pillow and the paw-shaped lumbar support pillow using their straps. The decorative cat ears can be attached to the top of the backrest.
7. **Final Check:** Verify all connections are secure and the chair is stable before first use.

5. Operating Instructions

Your Vigosit Gaming Chair is designed for personalized comfort and ergonomic support. Familiarize yourself with its adjustable features:



Image: A visual representation of the chair's ergonomic features, including tilt range, cushion thickness, sitting height adjustment, and maximum load capacity.

- **Height Adjustment:** Locate the lever on the right side, under the seat. Pull the lever up while seated to lower the chair, or pull it up while standing to raise it. Release the lever at your desired height. The sitting height is adjustable by approximately 3.6 inches.
- **Recline Function:** Use the lever on the left side, under the seat, to adjust the backrest angle. Lean back to your desired position (90-155 degrees tilt) and push the lever down to lock it in place. Pull the lever up to unlock and return the backrest to an upright position.
- **Footrest:** Pull out the retractable footrest located beneath the seat. Extend it fully for leg support and push it back in when not in use.
- **Lumbar Support Pillow:** The paw-shaped lumbar pillow provides adjustable support for your lower back. Adjust its position by sliding it up or down along the backrest straps to find optimal comfort.
- **Headrest Pillow:** The headrest pillow can be moved up and down to the correct position for neck support.
- **Removable Cat Ears:** The decorative cat ears are removable and can be reattached as desired.



Image: A detailed view highlighting the chair's aesthetic elements: removable cat ears, the soft paw-shaped lumbar support, the headrest, and the embroidered cat head logo.



Image: A close-up demonstrating the chair's thick, full, and skin-friendly cotton filling, emphasizing its soft and comfortable texture.

6. Maintenance and Care

Proper care will extend the life and appearance of your Vigosit Gaming Chair.

- **Cleaning:** For general cleaning, wipe the chair's surface with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Casters:** Periodically clean hair and debris from the casters to ensure smooth rolling.
- **Fasteners:** Check all screws and bolts every few months and re-tighten them if they have loosened.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the material to fade or crack.

7. Troubleshooting

If you encounter any issues with your Vigosit Gaming Chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair wobbles or feels unstable	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the chair is on a flat surface.
Chair does not adjust height	Gas lift malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact customer support.
Casters do not roll smoothly	Debris caught in casters or damaged casters.	Remove any hair or debris from the caster wheels. If damaged, replace the casters.
Backrest does not recline or lock	Recline mechanism jammed or damaged.	Ensure the recline lever is fully engaged. Check for any obstructions. If damaged, contact customer support.

If you experience any issues not listed here, or if the suggested solutions do not resolve the problem, please contact Vigosit customer service for assistance.

8. Product Specifications

Feature	Detail
Brand	Vigosit
Model	B0D9JN8M8M (Cat Pink)
Product Dimensions (D x W x H)	17.7"D x 18.9"W x 40"H
Max Load Capacity	310 lbs
Recommended Height	4'7" - 5'9"
Recommended Weight	80-180 lbs
Reclining Angle	90-155 degrees
Cushion Thickness	3.5 inches
Sitting Height Adjustment	3.6 inches
Fill Material	Sponge
Base Material	Nylon
UPC	702571475149



Image: A detailed graphic displaying the chair's dimensions, recommended user height and weight, and maximum load capacity.

9. Warranty and Support

Your Vigosit Gaming Chair comes with a**1-year warranty** from the date of purchase, covering manufacturing defects. For any questions, concerns, or warranty claims, please do not hesitate to contact our customer service team. We are committed to responding to your inquiries within 24 hours.

Contact Information:

Seller: VIGOSIT US

For support, please refer to the contact details provided with your purchase or visit the official Vigosit store on Amazon.

© 2025 Vigosit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question