Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KROQO KROQO-EU608

KROQO Steam Cleaner Model KROQO-EU608 Instruction Manual

Important safety information and operating instructions for your KROQO Steam Cleaner.

1. Important Safety Instructions

Please read all instructions carefully before using the KROQO Steam Cleaner. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Always ensure the power cord is undamaged and connected to a grounded outlet. Do not operate with a damaged cord or plug.
- **Hot Steam Hazard:** The steam generated by this appliance reaches temperatures up to 320°F (160°C). Avoid direct contact with steam. Keep hands and face away from the nozzle during operation.
- **Child Safety:** This appliance is equipped with a child safety lock on the handle. Always engage the safety lock when the device is not in use to prevent accidental activation and potential burns. Keep the appliance out of reach of children.
- **Handling Hot Surfaces:** The body surfaces of the steam cleaner can become hot during use. Use the provided insulated glove when handling the hot parts of the appliance or accessories to avoid burns.
- **Water Tank:** Only use clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank, as this can damage the appliance and void the warranty.
- **Maintenance:** Always unplug the appliance and allow it to cool completely before performing any maintenance or cleaning.

2. Product Overview

Components and Features

Familiarize yourself with the main parts of your KROQO Steam Cleaner:



Image: Overview of the KROQO Steam Cleaner highlighting its portable handgrip, safety valve, bobbin winder for cord storage, and 360-degree rotating wheels.

- **Portable Handgrip:** Designed for convenient carrying and maneuverability.
- **Safety Valve:** Ensures the tank remains tightly closed during operation. Can only be opened after the unit has cooled down.
- **Bobbin Winder:** Integrated storage for the power cord, keeping it tidy when not in use.
- **360° Rotating Wheels:** Allows for effortless movement of the steam cleaner around your home.
- **Water Tank:** Located on the main unit, with a capacity of 1.5 liters (53oz).
- **Steam Hose and Handle:** Connects the main unit to various cleaning attachments. The handle includes steam activation and safety lock.

Package Contents (23 Accessories)

Your KROQO Steam Cleaner comes with a comprehensive set of 23 accessories for various cleaning tasks:



Image: A visual representation of all 23 accessories included with the steam cleaner, such as cleaning wipes, gloves, hot head towel balls, measuring cup, funnel, accessory bag, microfibre mop cloth, extension poles, accessory adaptor, mop adaptor, wire winding stand, elbow nozzle, small nylon brushes, mop brush, glass brush, ironing head, large nylon brushes, large wire brush, and small wire brush.

- Cleaning Wipes (x1)
- Glove (x1)
- Hot Head Towel Ball (x2)
- Measuring Cup (x1)
- Funnel (x1)
- Accessory Bag (x1)
- Microfibre Mop Cloth (x1)
- Extension Pole (x2)
- Accessory Adaptor (x1)
- Mop Adaptor (x1)
- Wire Winding Stand (x1)

- Elbow Nozzle (x1)
- Small Nylon Brush (x2)
- Mop Brush (x1)
- Glass Brush (x1)
- Ironing Head (x1)
- Large Nylon Brush (x2)
- Large Wire Brush (x1)
- Small Wire Brush (x1)

3. Setup

Before First Use

- Unpack all components and ensure all 23 accessories are present.
- Read the safety instructions carefully.

Filling the Water Tank

1. Ensure the steam cleaner is unplugged and cool.
2. Unscrew the safety valve counter-clockwise.
3. Using the provided measuring cup and funnel, carefully pour up to 46oz (approximately 1.36 liters) of clean tap water into the tank. **Do not overfill the water tank beyond 46oz, even though the tank capacity is 53oz.**
4. Screw the safety valve clockwise until it is securely tightened.

Attaching Accessories

Select the appropriate accessory for your cleaning task. Attach it firmly to the steam handle or extension poles until it clicks into place. Ensure all connections are secure before use.

4. Operating Instructions

Powering On and Warm-up

1. Plug the power cord into a grounded electrical outlet (220V).
2. Turn on the power switch. The indicator light will illuminate.
3. Allow approximately 8 minutes for the unit to warm up and generate steam. The indicator light may change or turn off when ready.
4. When starting, the nozzle may initially spray condensed water that has accumulated in the hose. This is normal.

Adjusting Steam Volume

The steam handle features an adjustable steam volume control. Rotate the dial to select between minimum (MIN) and maximum (MAX) steam output, depending on the cleaning task and surface.



Image: The steam handle with a dial for adjusting steam volume from MIN to MAX, and a switch for the child safety lock. Also shows the steam cleaner in use and with the safety lock engaged.

Cleaning Surfaces

Direct the steam nozzle or attached accessory towards the surface to be cleaned. Move the accessory slowly over the surface to allow the steam to penetrate and loosen dirt. The KROQO Steam Cleaner uses high-temperature steam for chemical-free cleaning and disinfection.



Image: Examples of the steam cleaner's versatile applications, including floor cleaning with mop and extension poles, tile cleaning with nylon brush, stove cleaning with steel brush, toilet cleaning with jet nozzle, window cleaning with glass brush, and upholstery cleaning with ironing brush and cloth.

The 53oz water tank allows for continuous cleaning for up to 35 minutes, reducing the need for frequent refills during larger cleaning tasks.

Child Safety Lock

To prevent accidental steam release, especially when children are present, engage the child safety lock switch located on the steam handle. This locks the steam trigger, preventing operation.

5. Maintenance

After Each Use

- Unplug the appliance and allow it to cool completely.

- Carefully unscrew the safety valve and empty any remaining water from the tank.
- Clean accessories with water and mild soap if necessary, then allow them to air dry.
- Wipe the exterior of the steam cleaner with a damp cloth.

Descaling

Depending on water hardness, mineral deposits may build up in the tank over time. To descale, follow these steps:

1. Ensure the unit is unplugged and cool.
2. Mix a solution of equal parts white vinegar and water.
3. Pour the solution into the water tank (do not exceed 46oz).
4. Allow the solution to sit in the tank for several hours or overnight.
5. Empty the tank and rinse thoroughly with fresh water several times.
6. Operate the steam cleaner with a full tank of fresh water to flush out any remaining vinegar.

Storage

Store the steam cleaner in a cool, dry place. Use the integrated bobbin winder to neatly store the power cord. Keep all accessories organized in the provided accessory bag.

6. Troubleshooting

If you encounter issues with your KROQO Steam Cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or weak steam.	Water tank is empty. Unit not fully heated. Safety valve not fully closed. Mineral buildup (scaling).	Refill water tank. Allow 8 minutes for warm-up. Ensure safety valve is tightly closed. Perform descaling procedure (see Maintenance section).
Water spraying instead of steam.	Condensation in hose. Unit not fully heated.	This is normal at startup. Allow a few seconds for steam to stabilize. Wait for the full 8-minute warm-up time.
Steam trigger is locked.	Child safety lock engaged.	Disengage the child safety lock switch on the handle.

If the problem persists after trying these solutions, please contact KROQO customer support.

7. Specifications

Feature	Specification
Model Number	KROQO-EU608
Brand	KROQO
Voltage	220V

Feature	Specification
Water Tank Volume	1.5 Liters (53oz)
Recommended Max Fill	46oz
Warm-up Time	8 Minutes
Maximum Temperature	320°F (160°C)
Power Source	Electric Cord
Cord Length	5 meters
Included Accessories	23 pieces
Dimensions (Package)	49.5 x 32.5 x 32 cm
Weight (Package)	6.38 kg

8. Warranty and Support

KROQO products are manufactured to high-quality standards. For warranty information, technical support, or any questions regarding your KROQO Steam Cleaner, please contact KROQO customer service through the retailer where the product was purchased or visit the official KROQO website.

Please retain your proof of purchase for warranty claims.

© 2026 KROQO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9K11ZRR

More documents and user manuals: **https://manuals.plus/**