Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pemberly Row PR-4753-2797600

Pemberly Row PR-4753-2797600 Wood Tall Storage Display Cabinet User Manual

Model: PR-4753-2797600

Introduction

This manual provides essential instructions for the assembly, setup, operation, and maintenance of your Pemberly Row Wood Tall Storage Display Cabinet. Please read this manual thoroughly before beginning assembly and retain it for future reference. This cabinet is designed for displaying items and providing concealed storage in various home environments.



Image 1: Front view of the Pemberly Row Wood Tall Storage Display Cabinet with its two tempered glass doors closed. The cabinet features a rounded arched top and a light oak finish.

Safety Information

Adhere to the following safety guidelines to prevent injury or damage to the product:

- **Assembly:** Always assemble the cabinet on a soft, clean surface to prevent scratches. Ensure all hardware is securely tightened before use.
- **Stability:** This cabinet is tall. To prevent tipping, it is highly recommended to secure the cabinet to a wall using an anti-tip kit (if included or purchased separately).
- **Weight Capacity:** Do not exceed the specified weight capacities for shelves. Overloading can compromise stability and cause damage.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the cabinet.

- **Glass:** The doors feature tempered glass. Handle with care. In case of breakage, tempered glass shatters into small, less dangerous pieces.

Package Contents

Verify that all components are present before beginning assembly. Refer to the separate assembly instructions for a detailed list of parts and hardware.

- Cabinet panels (MDF and Particleboard with Wood Grain Laminate)
- Rounded Arched Top section
- Two doors with Tempered Glass windows
- Metal Ring Pull Handles (brushed gold finish)
- Soft-close hinges
- Adjustable shelves (2)
- Fixed shelf (1)
- Wood legs with non-marking felt pads
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly Instructions Manual

Assembly Instructions

Assembly of this cabinet is required. A detailed, step-by-step assembly instruction manual is included in the packaging. Please follow these instructions carefully to ensure proper construction and stability of the unit.

- **Tools Required:** Typically, a Phillips head screwdriver and a hammer are needed. Additional tools may be specified in the assembly manual.
- **Two-Person Assembly:** For safety and ease, it is recommended that two adults assemble this cabinet.
- **Hardware Check:** Before starting, lay out all hardware and compare it against the parts list in the assembly manual to ensure everything is present.
- **Sequence:** Follow the numbered steps in the assembly manual precisely. Do not skip steps.
- **Tightening:** Hand-tighten all screws initially. Once the entire section is assembled, gently tighten all screws firmly, but do not overtighten.



Image 2: Front view of the cabinet with both tempered glass doors open, showcasing the interior with two adjustable shelves and one fixed shelf, along with the bottom storage compartment.

Setup

Once assembled, follow these steps for proper placement and setup:

- **Location:** Place the cabinet on a flat, level surface. Avoid placing it in direct sunlight or near heat sources to prevent material degradation.
- **Leveling:** Check if the cabinet is level. If not, adjust the non-marking felt pads on the bottom of the legs or use shims to ensure stability. A wobbly cabinet can be a safety hazard.
- **Wall Anchoring:** For enhanced safety, especially in homes with children or pets, secure the cabinet to a wall using

an anti-tip restraint kit. Follow the instructions provided with the kit.

- **Floor Protection:** The cabinet legs are fitted with non-marking felt pads to protect your floors. Ensure these pads are intact and properly positioned.

Operating the Cabinet

This cabinet is designed for display and storage purposes.

- **Doors:** The two front doors open outwards. They are equipped with soft-close hinges for quiet operation. Use the metal ring pull handles to open and close the doors.
- **Adjustable Shelves:** The cabinet includes two adjustable shelves. To reposition a shelf, carefully remove any items, lift the shelf, and move the shelf pins to the desired height. Ensure all four pins are securely in place before placing the shelf back.
- **Fixed Shelf:** One shelf is fixed and cannot be adjusted.
- **Storage Compartment:** The lower section of the cabinet provides a concealed storage compartment behind the lower portion of the doors.
- **Arched Top Shelf:** The rounded arched top provides an additional display area.



Image 3: Side view of the Pemberly Row Wood Tall Storage Display Cabinet, highlighting its depth and the rounded arched top design.

Maintenance

Proper care will extend the life and appearance of your cabinet.

- **Cleaning Wood Surfaces:** Wipe wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the wood grain laminate finish. Dry immediately with a clean, soft cloth.
- **Cleaning Glass Doors:** Use a standard glass cleaner and a soft, lint-free cloth for the tempered glass doors. Spray cleaner onto the cloth, not directly onto the glass, to prevent overspray onto wood surfaces.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary, but do not overtighten.

- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Avoid Extreme Conditions:** Do not expose the cabinet to extreme temperature changes or high humidity, which can cause warping or cracking.

Troubleshooting

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose hardware; incorrect assembly.	Ensure cabinet is on a level surface. Adjust felt pads or use shims. Check and tighten all assembly hardware. Review assembly instructions.
Doors do not close properly or are misaligned.	Loose hinge screws; cabinet not level; hinge adjustment needed.	Check and tighten hinge screws. Ensure the cabinet is level. Hinges often have adjustment screws for vertical, horizontal, and depth alignment. Refer to hinge manufacturer's instructions if available.
Shelves are not stable.	Shelf pins not fully inserted; shelf not seated correctly.	Ensure all four shelf pins are fully inserted into the cabinet sides. Confirm the shelf is resting evenly on all pins. Do not overload shelves.
Scratches on wood surface.	Sharp objects; abrasive cleaning.	Use furniture polish or touch-up pens designed for wood laminate. Avoid placing sharp objects directly on the surface.

Specifications

Feature	Detail
Model Number	PR-4753-2797600
Brand	Pemberly Row
Material	MDF and Particleboard
Finish	Oak Wood Grain Laminate
Dimensions (Overall)	71"H x 31"W x 17"D
Item Weight	83 lbs
Leg Dimensions	7"H x 30.5"W x 13.5"D
Shelf Dimensions	9"H x 27.5"W x 13.5"D
Shelf Weight Capacity (Arched Top)	88 lbs
Shelf Weight Capacity (Adjustable & Fixed)	70 lbs each
Shelf Weight Capacity (Bottom Compartment)	84 lbs
Doors	Tempered Glass with Soft-Close Hinges
Handles	Metal Ring Pull (Brushed Gold Finish)
Assembly Required	Yes

Feature	Detail
Number of Shelves	3 (2 adjustable, 1 fixed)

Warranty and Support

For information regarding product warranty, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. For assistance with assembly, missing parts, or other product-related inquiries, please contact Pemberly Row customer support or the seller, Cymax, directly.

Seller Information:

- Seller Name: Cymax
- For support, please visit the seller's page on Amazon or contact them through your order details.

Protection plans are available for purchase separately. For details on these plans, please refer to the specific plan provider's terms and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9KXPR8Z

More documents and user manuals: **https://manuals.plus/**