Basike D91

Basike D91 Wireless Earbuds Instruction Manual

Model: D91 | Brand: Basike

Introduction

Thank you for choosing the Basike D91 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds. Please read it carefully to ensure optimal performance and longevity of your device.

What's in the Box

- Basike D91 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual

Product Overview

The Basike D91 earbuds feature an ergonomic, non-in-ear design with adjustable ear hooks for comfort during extended use. The charging case includes an LED display to show battery status.



Image: Basike D91 Wireless Earbuds resting inside their charging case, displaying the model information and battery capacity.



Image: A pair of Basike D91 Wireless Earbuds shown outside the charging case, highlighting their flexible ear hook design for secure fit.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

- Place the earbuds into the charging case.
- Connect the USB Type-C cable to the charging port on the case and a power source.
- The LED display on the case will indicate the charging status. A full charge for both the case and earbuds takes approximately 2 hours.
- The case also supports wireless magnetic charging.



Image: The Basike D91 charging case open, showing the digital power display and indicating wireless charging capability.

2. Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "Basike D91" from the list.
4. Once connected, the earbuds will indicate successful pairing.

3. Wearing the Earbuds

The Basike D91 earbuds are designed for a comfortable and secure fit. Position the ear hooks over your ears and adjust the earbuds to sit comfortably without inserting them directly into the ear canal.



Image: A visual guide demonstrating the correct steps to wear the Basike D91 earbuds, emphasizing the non-in-ear design and secure fit.

Operating Instructions

Controls

The Basike D91 earbuds feature button controls for various functions:

- **Power On/Off:** Automatically power on when removed from the case, and power off when placed back in the case.
- **Play/Pause:** Single press on either earbud.
- **Next Track:** Double press the right earbud.
- **Previous Track:** Double press the left earbud.
- **Answer/End Call:** Single press on either earbud.
- **Reject Call:** Press and hold on either earbud.
- **Activate Voice Assistant:** Triple press on either earbud.

Audio and Call Quality

The earbuds utilize Bluetooth 5.4 for a stable connection and feature Hi-Fi stereo audio with a D91 driver for clear and balanced sound. Microphones are equipped with AI noise reduction for clear communication during calls.

Your browser does not support the video tag.

Video: A short demonstration of the Basike D91 earbuds' features and design.

Maintenance

Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners or solvents.

Water Resistance

The Basike D91 earbuds are IPX5 water-resistant, protecting them from sweat and light splashes. They are not designed for submersion in water.



Image: Basike D91 earbuds depicted with a water splash, illustrating their IPX5 water resistance for sports and outdoor activities.

Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
Only one earbud working	Place both earbuds back in the case, close it, then open it again. Ensure both earbuds are charged.

Problem	Possible Solution
No sound	Check device volume. Ensure earbuds are connected. Try playing different audio.
Charging issue	Ensure the charging cable is securely connected. Try a different USB port or charger. Clean charging contacts on earbuds and case.
Poor call quality	Ensure earbuds are positioned correctly. Move closer to your connected device. Avoid noisy environments.

Specifications

- **Model Name:** FON001-D91
- **Bluetooth Version:** 5.4V
- **Bluetooth Profiles:** A2DP, HFP, HSP, AVRCP
- **Audio Decoders:** SBC, AAC
- **Wireless Range:** Up to 10 meters (33 feet)
- **Music Playtime:** Approximately 7 hours
- **Call Time:** Approximately 6 hours
- **Standby Time:** Up to 100 hours
- **Earbud Battery Capacity:** 2 * 50mAh
- **Charging Case Battery Capacity:** 600mAh
- **Earbud Charging Time:** Approximately 2 hours
- **Case Charging Time:** Approximately 2 hours
- **Water Resistance:** IPX5 (Sweat and splash resistant)
- **Control Type:** Button control
- **Weight:** 75 grams (total product)
- **Material:** Stainless steel, Plastic, Silicone
- **Compatible Devices:** Smartphones, Tablets, Laptops, Smart Speakers



Image: Infographic detailing the Basike D91's long-term durability, including 2 hours charging time, 6.5 hours single-use time, and 10m Bluetooth connection distance.

Warranty and Support

Warranty Information

The Basike D91 Wireless Earbuds come with a**1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support

For any questions, issues, or warranty claims, please contact Basike customer support. Refer to the contact information provided with your purchase or visit the official Basike website for assistance.

© 2026 Basike. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question