Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FSR177-L-W

SoBuy Slim Shoe Cabinet FSR177-L-W Instruction Manual

Brand: SoBuy | Model: FSR177-L-W

Introduction

Thank you for choosing the SoBuy Slim Shoe Cabinet FSR177-L-W. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

To ensure safe use and prevent accidents, please adhere to the following safety guidelines:

- **Anti-Tip Device:** Always secure the furniture to the wall using the provided anti-tip device. This is crucial to prevent the cabinet from tipping over, especially when fully loaded.
- **Children Safety:** Never allow children to stand, climb, or hang on drawers, doors, or shelves.
- **Drawer Use:** Do not open more than one tilt-out compartment at a time to maintain stability.
- **Weight Distribution:** Place heavier items in the lower compartments to improve stability.
- **Television Placement:** Never place a television or other heavy electronic devices on top of this furniture.



Image: Safety warning regarding furniture tip-over prevention.

Setup and Assembly

The SoBuy Slim Shoe Cabinet FSR177-L-W requires assembly. Follow the included instructions carefully for a smooth setup process.

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the instruction manual are present.
2. **Identify Parts:** The parts are numbered for easy identification. Refer to the illustrated assembly instructions.

3. **Assemble Frame:** Follow the step-by-step diagrams to assemble the main frame of the shoe cabinet.
4. **Install Tilt-Out Compartments:** Attach the 4 tilt-out compartments according to the instructions. This step may require patience.
5. **Attach Legs:** Secure the cabinet legs to the base.
6. **Wall Mounting: Crucially, secure the cabinet to a wall using the provided anti-tip hardware.** This prevents accidental tipping and ensures safety.



Image: The SoBuy Slim Shoe Cabinet FSR177-L-W fully assembled in a home environment.



Image: Detail of the cabinet's legs and base.

Operating Instructions

The SoBuy Slim Shoe Cabinet is designed for efficient shoe storage and organization.

- **Shoe Storage:** Each of the 4 tilt-out compartments can store multiple pairs of shoes, keeping them dust-free and out of sight. Gently pull the handle to open a compartment and place shoes inside. Push to close.
- **Top Surface:** The flat top surface can be used to place decorative items, keys, mail, or other small belongings, enhancing its functionality in an entryway or hallway.



Image: A tilt-out compartment open, displaying shoe storage.



Image: Detail of the cabinet's top surface, suitable for small items.

Maintenance

To maintain the appearance and longevity of your shoe cabinet:

- **Cleaning:** Wipe the surfaces clean with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which may damage the finish.
- **Dusting:** Regularly dust the cabinet to prevent buildup.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Anti-Tip Device:** Ensure the anti-tip device remains securely fastened to the wall and the cabinet.

Troubleshooting

This section addresses common issues you might encounter:

- **Cabinet Wobbles:** Ensure the cabinet is placed on a level surface. Check that all assembly screws are tightened. Verify the anti-tip device is correctly installed and secured to the wall.
- **Drawers Not Closing Smoothly:** Check for any obstructions inside the compartments. Ensure the drawer mechanisms are correctly aligned and free of debris.
- **Missing Parts:** If you find any parts missing during assembly, please contact SoBuy customer support for assistance.

Specifications

Brand	SoBuy
Model Number	FSR177-L-W
Color	White
Material	Engineered Wood, Metal
Product Dimensions (D x W x H)	19 cm x 100 cm x 91 cm
Number of Tilt-Out Compartments	4
Maximum Weight Capacity	24 kg
Item Weight	26.8 kg
Special Features	Anti-tip mechanism
Mounting Type	Wall Mount (Anti-tip)



Image: Dimensional drawing of the shoe cabinet.

Warranty Information

Specific warranty details for the SoBuy Slim Shoe Cabinet FSR177-L-W are not provided in the product information. Please refer to your purchase documentation or contact the retailer/manufacturer directly for warranty terms and conditions.

Customer Support

For any questions, missing parts, or assistance with assembly, please contact SoBuy customer service. Contact information can typically be found on the packaging, the retailer's website, or by searching for "SoBuy customer support" online.

SoBuy Commercial GmbH is based in Germany and aims to provide innovative furnishing solutions. For more information about SoBuy, you can visit their brand store on Amazon.

Visit the SoBuy Brand Store

© 2024 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9Q4YS21

More documents and user manuals: **https://manuals.plus/**