Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ninja CO905KS

Ninja CO905KS Deluxe Kitchen System Instruction Manual

Model: CO905KS | Brand: Ninja

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using your Ninja CO905KS Deluxe Kitchen System.
- To protect against electrical shock, do not immerse the motor base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by Ninja may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate the blender with the lid in place.
- Do not blend hot liquids.
- Do not overfill the containers. Refer to the MAX LIQUID line on the pitcher and cups.

What's in the Box

Your Ninja CO905KS Deluxe Kitchen System includes the following components:

- 1600-peak-watt Motor Base with Auto-IQ
- 88-oz. Total Crushing Pitcher with Lid
- Stacked Blade Assembly (for pitcher)
- 9-cup Precision Processor Bowl with Lid
- Chopping Blade Assembly (for processor bowl)

- Dough Blade Assembly (for processor bowl)
- (2) 24-oz. Single-Serve Cups
- (2) Spout Lids (for single-serve cups)
- Pro Extractor Blades Assembly (for single-serve cups)



Image: All components of the Ninja CO905KS Deluxe Kitchen System, including the motor base, large pitcher, food processor bowl, and two single-serve cups with their respective blade assemblies and lids.

Getting Started (Setup)

Before first use, wash all parts that will come into contact with food in warm, soapy water. Rinse and dry thoroughly. The motor base should be wiped clean with a damp cloth.

1. **Place the Motor Base:** Position the motor base on a clean, dry, level surface. Ensure the surface is stable and the suction cups on the bottom of the base adhere securely.
2. **Assemble the Container:**
    - **For Total Crushing Pitcher:** Place the 88-oz. pitcher onto the motor base, aligning the arrow on the pitcher with the arrow on the base. Twist clockwise until it clicks into place. Insert the Stacked Blade Assembly onto the drive gear inside the pitcher.
    - **For Precision Processor Bowl:** Place the 9-cup processor bowl onto the motor base, aligning the arrow on the bowl with the arrow on the base. Twist clockwise until it clicks into place. Insert either the Chopping Blade Assembly or Dough Blade Assembly onto the drive gear inside the bowl.
    - **For Single-Serve Cups:** Add ingredients to the 24-oz. single-serve cup. Screw the Pro Extractor Blades Assembly onto the top of the cup until tightly sealed. Invert the cup and place it onto the motor base, aligning the tabs on the cup with the slots on the base. Twist clockwise until it clicks into place.
3. **Secure the Lid:** For the pitcher and processor bowl, place the lid securely on the container and press down firmly until it clicks into place. For single-serve cups, the blade assembly acts as the lid during blending.
4. **Plug In:** Plug the power cord into a 120V AC electrical outlet. The power button will illuminate.

Operating Instructions

The Ninja CO905KS Deluxe Kitchen System features Auto-IQ programs for one-touch convenience and manual speed controls for customized blending.

Auto-IQ Programs

Auto-IQ Technology features intelligent programs that combine unique pulsing, blending, and pausing patterns that do the work for you. Once a program is selected, it will start immediately and automatically stop when complete.

- **SMOOTHIE:** For fresh or frozen fruits and liquids.
- **FROZEN:** For frozen fruits, ice, and harder ingredients.
- **EXTRACT:** For nutrient and vitamin extraction from whole fruits and vegetables (use with single-serve cups).
- **PUREE:** For smooth sauces, dips, and soups.
- **CHOP:** For consistent chopping of ingredients (use with processor bowl).
- **DOUGH:** For mixing doughs and batters (use with processor bowl).

Manual Speed Control

For manual control, turn the dial to select your desired speed:

- **LOW:** For light mixing and folding.
- **MED:** For general blending and chopping.
- **HIGH:** For heavy blending, pureeing, and crushing.
- **PULSE:** For quick bursts of power for chopping and controlled processing.

Using the 88-oz. Total Crushing Pitcher

This pitcher is ideal for large batches of smoothies, frozen drinks, and crushing ice.

1. Ensure the pitcher is securely assembled on the motor base with the Stacked Blade Assembly inserted.
2. Add ingredients, ensuring not to exceed the MAX LIQUID line.
3. Secure the pitcher lid.
4. Select an Auto-IQ program (e.g., SMOOTHIE, FROZEN) or a manual speed (LOW, MED, HIGH, PULSE).
5. The unit will blend until the program is complete or you release the manual speed.

Using the 9-cup Precision Processor Bowl

The processor bowl is perfect for chopping vegetables, pureeing sauces, or mixing dough.

1. Ensure the processor bowl is securely assembled on the motor base with the appropriate blade (Chopping or Dough) inserted.
2. Add ingredients.
3. Secure the processor bowl lid.
4. Select an Auto-IQ program (e.g., CHOP, DOUGH, PUREE) or a manual speed (LOW, MED, HIGH, PULSE).

Using the 24-oz. Single-Serve Cups

These cups are designed for individual servings of smoothies and nutrient extraction.

1. Add ingredients to the single-serve cup.
2. Screw the Pro Extractor Blades Assembly onto the cup until tightly sealed.
3. Invert the cup and place it onto the motor base, twisting clockwise until it clicks into place.

4. Select the EXTRACT Auto-IQ program or a manual speed (LOW, MED, HIGH, PULSE).
5. Once blending is complete, twist the cup counter-clockwise to remove it from the base. Remove the blade assembly and replace with a spout lid for on-the-go convenience.

Care and Maintenance

Proper care ensures the longevity and performance of your Ninja Kitchen System.

Cleaning

- **Dishwasher Safe Parts:** The pitcher, processor bowl, single-serve cups, lids, and blade assemblies are dishwasher safe. Place them on the top rack.
- **Hand Washing:** Wash containers and blade assemblies in warm, soapy water. Use a dishwashing utensil with a handle to clean the blade assemblies. Handle blades with extreme care to avoid contact with sharp edges.
- **Motor Base:** Wipe the motor base clean with a damp cloth. Do not immerse the motor base in water or any other liquid.

Storage

Store the Ninja Kitchen System upright. Place the blade assemblies inside their respective containers and secure the lids. Do not place anything on top of the containers.

Troubleshooting

If your Ninja CO905KS Deluxe Kitchen System is not functioning as expected, refer to the common issues and solutions below:

- **Unit does not turn on:**
  - Ensure the power cord is securely plugged into the outlet.
  - Check that the container is properly assembled and locked onto the motor base. The power button will illuminate when correctly assembled.
- **Ingredients are not blending or processing:**
  - Ensure the container is not overfilled. Reduce the amount of ingredients if necessary.
  - If blending thick mixtures or frozen ingredients, use the PULSE function or add more liquid.
  - For the pitcher, ensure the Stacked Blade Assembly is properly inserted and seated.
- **Lid/Blade Assembly is difficult to attach/remove:**
  - Ensure the container is correctly aligned and twisted into place on the motor base.
  - For the pitcher lid, press the RELEASE button on the handle to open.
- **Unit leaks during operation:**
  - Ensure the lid is securely fastened to the container.
  - For single-serve cups, ensure the Pro Extractor Blades Assembly is tightly screwed onto the cup.

Specifications

Brand	Ninja
Model Number	CO905KS
Product Dimensions	9.33"L x 8.78"W x 18.5"H
Item Weight	14.9 pounds
Voltage	120 Volts
Specific Uses For Product	Mix, Chop, Puree, Slice, Shred, Grate
UPC	622356611541

Warranty and Support

For warranty information or product support, please refer to the warranty card included with your purchase or visit the official Ninja website. You may also contact Ninja customer service directly for assistance with your CO905KS Deluxe Kitchen System.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9WV919N

More documents and user manuals: **https://manuals.plus/**