Gevi GECMA025AK-U

Gevi 10-Cup Drip Coffee Maker

MODEL: GECMA025AK-U USER MANUAL

Important Safeguards

Please read all instructions carefully before using this appliance. Basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The carafe is designed for use with this appliance. It must never be used on a range top.
- Do not place a hot carafe on a wet or cold surface.
- Do not use a cracked carafe or a carafe having a loose or weakened handle.
- Do not clean carafe with cleansers, steel wool pads, or other abrasive materials.

Product Overview

Components

Familiarize yourself with the parts of your Gevi Drip Coffee Maker.



Figure 1: The Gevi 10-Cup Drip Coffee Maker shown with its glass carafe. This image displays the main unit with the control panel, water reservoir, bean hopper, and the carafe placed on the warming plate.



Figure 2: A close-up view of the glass carafe, designed specifically for the Gevi GECMA025AK-U model. It features a black handle and a silver band around the base.



Figure 3: The Gevi Drip Coffee Maker on a kitchen counter, illustrating its dimensions: approximately 16.93 inches in height, 8.38 inches in width, and 12.36 inches in depth.





Figure 4: A direct front view of the Gevi Drip Coffee Maker, highlighting the control panel with its digital display, buttons for program, grind off, strength control, on/off, hour, and minute, and the Gevi logo.

Setup

Initial Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and ensure all parts are present.
2. **Clean:** Before first use, wash the carafe, lid, and reusable filter in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.
3. **First Brew Cycle (Cleaning):** Fill the water reservoir to the MAX line with fresh, cold water. Do not add coffee beans or grounds. Place the empty carafe with its lid on the warming plate. Run a full brew cycle to clean the internal components. Discard the water after the cycle. Repeat this process once more.
4. **Position:** Place the coffee maker on a flat, stable, heat-resistant surface, away from the edge of the counter.

Operating Instructions

Brewing Coffee

1. **Fill Water Reservoir:** Open the water reservoir lid and fill with fresh, cold water up to the desired number of cups indicated on the side. Do not exceed the MAX line.
2. **Add Coffee Beans/Grounds:**
    - **For Whole Beans:** Open the bean hopper lid and add whole coffee beans. Ensure the lid is securely closed.
    - **For Pre-Ground Coffee:** If using pre-ground coffee, press the "GRIND OFF" button to disable the grinder. Add the desired amount of ground coffee into the reusable filter.
3. **Place Carafe:** Ensure the glass carafe with its lid is correctly positioned on the warming plate.
4. **Select Brew Settings:**
    - **Strength Control:** Press the "STRENGTH CONTROL" button to cycle through available strength options (e.g., Mild, Medium, Strong).
    - **Grind Settings (for whole beans):** The machine offers 3 levels of grind and 8 settings. Adjust these as desired for your preferred coffee consistency.
    - **Cup Selection:** Use the "POWDER 2-10" button to select the desired number of cups (2-10). This adjusts the water-to-coffee ratio for optimal balance.
5. **Start Brewing:** Press the "ON/OFF" button to begin the brewing process. The indicator light will illuminate.
6. **Serve:** Once brewing is complete, the machine will beep. Carefully remove the carafe and pour.

Keep Warm Function

After brewing, the coffee maker automatically enters a keep warm mode. The default keep warm time is 2 hours, but you can adjust it.

- **Adjusting Keep Warm Time:** Refer to the control panel. You can typically set the keep warm duration to 0, 15, 35, 45, 60, 75, 90, 100, or 120 minutes using the appropriate buttons (e.g., "HOUR" or "MIN" in conjunction with a program button).
- The warming plate will keep your coffee at an optimal serving temperature during this period.



Figure 5: The coffee maker's warming plate keeping coffee hot, with an overlay indicating an adjustable keep warm timer from 15 to 120 minutes.

Cleaning and Maintenance

Daily Cleaning

1. **Unplug:** Always unplug the coffee maker before cleaning and allow it to cool completely.
2. **Wash Removable Parts:** Remove the carafe, carafe lid, and reusable filter. Wash them in warm, soapy water. Rinse thoroughly and dry. The reusable filter can be rinsed clean with water.
3. **Wipe Exterior:** Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
4. **Clean Warming Plate:** Wipe the warming plate with a clean, damp cloth. Do not use abrasive materials.

Descaling (Mineral Deposit Removal)

Mineral deposits (calcium) can build up in your coffee maker over time, affecting its performance. Descale regularly,

depending on water hardness and frequency of use (e.g., every 2-4 weeks).

1. **Prepare Descaling Solution:** Fill the water reservoir with a mixture of white vinegar and water (e.g., 1 part vinegar to 2 parts water).
2. **Run Brew Cycle:** Place the empty carafe on the warming plate. Run a full brew cycle with the descaling solution.
3. **Rest:** After the cycle, let the coffee maker sit for 15-30 minutes with the solution inside.
4. **Rinse Cycles:** Discard the solution. Fill the water reservoir with fresh, cold water and run 2-3 full brew cycles with only water to rinse out any remaining vinegar taste or odor.

Troubleshooting

If you encounter issues with your coffee maker, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Coffee does not brew.	No power; water reservoir empty; carafe not correctly placed.	Check power connection; fill water reservoir; ensure carafe is properly seated.
Coffee tastes weak.	Insufficient coffee; incorrect grind size; strength setting too low.	Add more coffee; adjust grind to finer setting; select a stronger brew setting.
Coffee overflows.	Too much coffee grounds; filter basket clogged; carafe removed during brewing.	Reduce coffee amount; clean filter basket; do not remove carafe during brewing.
Grinder not working.	Bean hopper empty; "GRIND OFF" button activated.	Fill bean hopper; ensure "GRIND OFF" is deactivated.
Machine leaks.	Water reservoir overfilled; parts not assembled correctly.	Do not exceed MAX fill line; reassemble all parts securely.

Specifications

Model: GECMA025AK-U

Brand: Gevi

Coffee Maker Type: Drip Coffee Machine

Capacity: 10-Cup

Included Components: Carafe, Reusable Filter

Operation Mode: Fully Automatic

Special Features: Built-in Burr Grinder, Programmable, Adjustable Keep Warm Function, Strength Control

Warranty and Support

Gevi products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Gevi website. If you require technical assistance or have questions about your product, please contact Gevi customer support through their official channels.

For further assistance, you may visit the Gevi Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question